

Motion Control Lexium 23

User manual



Contents




| | |
|--|-----------|
| About the Book | 7 |
| Safety Information | 9 |
| Chapter 1 Unpacking Check and Model Explanation | 13 |
| 1.1 Unpacking Check | 14 |
| 1.2 Model Explanation | 15 |
| 1.3 Servo Drive and Servo Motor Combinations | 18 |
| 1.4 Servo Drive Features | 19 |
| 1.5 Control Modes of Servo Drive | 21 |
| 1.6 Molded-case Circuit Breaker and Fuse Current | 22 |
| Chapter 2 Installation and Storage | 23 |
| 2.1 Installation Notes | 24 |
| 2.2 Storage Conditions | 25 |
| 2.3 Installation Conditions | 26 |
| 2.4 Installation Procedure and Minimum Clearances | 27 |
| Chapter 3 Connections and Wiring | 29 |
| 3.1 Connections | 30 |
| 3.2 Basic Wiring | 40 |
| 3.3 Input / Output Interface Connector -CN1 | 43 |
| 3.4 Encoder Connector CN2 | 62 |

| | | |
|------------------|---|------------|
| 3.5 | Serial Communication Connector CN3 | 64 |
| 3.6 | Standard Connection Example | 66 |
| Chapter 4 | Display and Operation | 71 |
| 4.1 | Description of the Digital Keypad | 72 |
| 4.2 | Display Flowchart | 73 |
| 4.3 | Status Display | 74 |
| 4.4 | General Function Operation | 76 |
| Chapter 5 | Trial Run and Tuning Procedure | 85 |
| 5.1 | Inspection without Load | 86 |
| 5.2 | Applying Power to the Drive | 88 |
| 5.3 | JOG Trial Run without Load | 92 |
| 5.4 | Speed Trial Run without Load | 94 |
| 5.5 | Position Trial Run without Load | 96 |
| 5.6 | Tuning Procedure | 99 |
| Chapter 6 | Control Modes of Operation | 113 |
| 6.1 | Control Modes of Operation | 114 |
| 6.2 | Position Control Mode | 115 |
| 6.3 | Speed Control Mode | 130 |
| 6.4 | Torque Control Mode | 148 |
| 6.5 | Control Modes Selection | 152 |
| 6.6 | Others | 153 |
| Chapter 7 | Parameters | 169 |
| 7.1 | Definition | 170 |
| 7.2 | Parameter Summary | 171 |
| 7.3 | Detailed Parameter Listings | 190 |

| | | |
|--------------------|--|------------|
| Chapter 8 | MODBUS Communications | 269 |
| 8.1 | Communication Hardware Interface | 270 |
| 8.2 | Communication Parameter Settings | 271 |
| 8.3 | MODBUS Communication Protocol | 275 |
| 8.4 | Communication Parameter Write-in and Read-out | 283 |
| Chapter 9 | Maintenance and Inspection | 285 |
| 9.1 | Basic Inspection | 286 |
| 9.2 | Maintenance | 288 |
| 9.3 | Life of Replacement Components | 289 |
| Chapter 10 | Troubleshooting | 291 |
| 10.1 | Fault Messages Table | 292 |
| 10.2 | Potential Cause and Corrective Actions | 294 |
| 10.3 | Clearing Faults | 302 |
| Chapter 11 | Specifications | 305 |
| 11.1 | Lexium 23 Series Specifications of Servo Drive | 306 |
| 11.2 | BCH servo motor specifications | 309 |
| 11.3 | BCH Servo Motor Speed-Torque Curves | 312 |
| 11.4 | Overload Characteristics | 316 |
| 11.5 | Dimensions of Servo Drive | 318 |
| 11.6 | Dimensions of BCH servo motor | 321 |
| Accessories | | 325 |

About the Book



At a Glance

Thank you very much for purchasing Schneider electric servo products. This manual will be helpful in the installation, wiring, inspection, and operation of Schneider electric servo drive and motor. Before using the product, please read this user manual to ensure correct use.

You should thoroughly understand all safety precautions (DANGERS, WARNINGS and STOPS) before proceeding with the installation, wiring and operation. If you do not understand please contact your local Schneider electric sales representative. Place this user manual in a safe location for future reference.

Using This Manual

Contents of this manual

This manual is a user guide that provides the information on how to install, operate and maintain Lexium 23C and Lexium 23M series AC servo drives, and BCH series AC servo motors. The contents of this manual are including the following topics:

- Installation of AC servo drives and motors
- Configuration and wiring
- Trial run steps
- Control functions and adjusting methods of AC servo drives
- Parameter settings
- Communication protocol
- Inspection and maintenance
- Troubleshooting
- Application examples

Who should use this manual

This user manual is intended for the following users:

- Those who are responsible for designing.
 - Those who are responsible for installing or wiring.
 - Those who are responsible for operating or programming.
 - Those who are responsible for maintaining or troubleshooting.
-

Important precautions

Before using the product, please read this user manual thoroughly to ensure correct use and store this manual in a safe and handy place for quick reference whenever necessary. Besides, please observe the following precautions:

- Do not use the product in a potentially explosive environment.
- Install the product in a clean and dry location free from corrosive and inflammable gases or liquids.
- Do not connect a commercial power supply to the U, V, W terminals of motor. Failure to observe this precaution will damage either the Servo motor or drive.

PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.

Carefully note and observe the following safety precautions when receiving, inspecting, installing, operating, maintaining and troubleshooting. The following words, DANGER, WARNING and STOP are used to mark safety precautions when using the Schneider electric's servo product. **Failure to observe these precautions may void the warranty!**

Lexium 23 series drives are open type servo drives and must be installed in an NEMA enclosure such as a protection control panel during operation to comply with the requirements of the international safety standards. They are provided with precise feedback control and high-speed calculation function incorporating DSP (Digital Signal Processor) technology, and intended to drive three-phase permanent magnet synchronous motors (PMSM) to achieve precise positioning by means of accurate current output generated by IGBT (Insulated Gate Bipolar Transistor).

Lexium 23 series drives can be used in industrial applications and for installation in an end-use enclosure that do not exceed the specifications defined in the Lexium 23 series user manual (Drives, cables and motors are for use in a suitable enclosure with a minimum of a UL Type 1 rating).

The words, DANGER, WARNING and STOP, have the following meaning:

 Warning

Install the product in a clean and dry location free from corrosive and inflammable gases or liquids.

Do not connect a commercial power supply to the U, V, W terminals of motor. Failure to observe this precaution will damage either the Servo motor or drive.

 Danger**RISK OF EQUIPMENT DAMAGE**

Ensure that the drive and motor are correctly connected to a ground. The grounding method must comply with the electrical standard of the country.

Do not disconnect the AC servo drive and motor while the power is ON.

Before starting the operation with a mechanical system connected, make sure the emergency stop equipment can be energized and work at any time.


Do not touch the drive heat sink or the servo motor during operation. Otherwise, it may result in serious personnel injury.

Failure to follow this instruction can result in injury or equipment damage.

In this manual, actual measured values are in metric units. Dimensions in (imperial units) are for reference only. Please use metric for precise measurements.

The content of this manual may be revised without prior notice. Please consult our distributors or download the most updated version at www.schneider-electric.com

Safety Information



Important Information

NOTICE

Lexium 23 series drives are open type servo drives and must be installed in an NEMA enclosure such as a protection control panel during operation to comply with the requirements of the international safety standards. They are provided with precise feedback control and high-speed calculation function incorporating DSP (Digital Signal Processor) technology, and intended to drive three-phase permanent magnet synchronous motors (PMSM) to achieve precise positioning by means of accurate current output generated by IGBT (Insulated Gate Bipolar Transistor).

Lexium 23 series drives can be used in industrial applications and for installation in an end-use enclosure that do not exceed the specifications defined in the Lexium 23 series user manual (Drives, cables and motors are for use in a suitable enclosure with a minimum of a UL Type 1 rating).

The words, DANGER, WARNING and STOP, have the following meaning:



Indicates a potentially hazardous situation and if not avoided, may result in serious injury or death.



Indicates a potentially hazardous situation and if not avoided, may result in minor to moderate injury or serious damage to the product.

Danger

DANGER indicates a dangerous situation that will result in death, serious physical injury or equipment damage.

 **Warning**

WARNING indicates a dangerous situation that can result in death, serious physical injury or equipment damage.

 **Caution**

CAUTION indicates a potentially dangerous situation that might possibly result in bodily harm or equipment damage.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

(c) 2008 Schneider Electric. All Rights Reserved.

Unpacking Check and Model Explanation



At a Glance

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|--|-------------|
| Unpacking Check | 14 |
| Model Explanation | 15 |
| Servo Drive and Servo Motor Combinations | 18 |
| Servo Drive Features | 19 |
| Control Modes of Servo Drive | 21 |
| Molded-case Circuit Breaker and Fuse Current | 22 |

1.1 Unpacking Check

After receiving the AC servo drive, please check for the following:

- Ensure that the product is what you have ordered.
Verify the part number indicated on the nameplate corresponds with the part number of your order (Please refer to Section 1.2 for details about the model explanation).
- Ensure that the servo motor shaft rotates freely.
Rotate the motor shaft by hand; a smooth rotation will indicate a good motor. However, a servo motor with an electromagnetic brake can not be rotated manually.
- Check for damage.
Inspect the unit to insure it was not damaged during shipment.
- Check for loose screws.
Ensure that all necessary screws are tight and secure.

If any items are damaged or incorrect, please inform the distributor whom you purchased the product from or your local Schneider electric sales representative. A complete and workable AC servo system should be including the following parts:

Part I : Schneider electric standard supplied parts

- (1) Servo drive
- (2) Servo motor
- (3) 5 PIN Terminal Block (for L1, L2, R, S, T) (available for 100W ~ 1.5kW models)
- (4) 3 PIN Terminal Block (for U, V, W) (available for 100W ~ 1.5kW models)
- (5) 3 PIN Terminal Block (for PA/+, PBi, PBe) (available for 100W ~ 1.5kW models)
- (6) One operating lever (for wire to terminal block insertion; available for 100W ~ 1.5kW models)
- (7) One jumper bar (for short the circuit of the terminal pins; available for 2kW ~ 4.5kW models)
- (8) Quick Start

Part II : Optional parts, not Schneider electric standard supplied part (Refer to Appendix A)


- (1) One power cable, which is used to connect servo motor and U, V, W terminals of servo drive. This power cable is with one green grounding cable. Please connect the green grounding cable to the ground terminal of the servo drive.
 - (2) One encoder cable, which is used to connect the encoder of servo motor and CN2 terminal of servo drive.
 - (3) CN1 Connector: 50 PIN Connector (3M type analog product)
 - (4) CN2 Connector: 20 PIN Connector (3M type analog product)
 - (5) CN3 Connector: 6 PIN Connector (IEEE1394 analog product)
-

1.2 Model Explanation

1.2.1 Nameplate Information


Lexium 23 Series Servo Drive

- Nameplate Explanation



BCH Series Servo Motor

- Nameplate Explanation



1.2.2 Model Name Lexium 23 Series Servo Drive

Explanation

| | L | X | M | 2 | 3 | C | U | 0 | 1 | M | 3 | X |
|--|---|---|---|---|---|---|---|---|---|---|---|---|
| LXM = Lexium Lexium Servo Drive | | | | | | | | | | | | |
| 23 = New generation compact I/O drive | | | | | | | | | | | | |
| Interface C = Normal I/O interface M = I/O interface oriented to Machine tools (1) | | | | | | | | | | | | |
| Continuous Power U01 = 0.1 kW U02 = 0.2 kW U04 = 0.4 kW U07 = 0.75 kW U10 = 1.0 kW U15 = 1.5 kW U20 = 2.0 kW U30 = 3.0 kW U45 = 4.5 kW U55 = 5.5 kW U75 = 7.5 kW | | | | | | | | | | | | |
| Mains voltage M3X = 220 VAC three phase/single phase, no EMC filter | | | | | | | | | | | | |

(1) M only for drive type which power is higher than 4.5kW, will be launched on September 2008

BCH Series Servo Motor

| | | | | | | | | | | | | |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| B | C | H | 0 | 4 | 0 | 1 | 0 | 0 | 1 | A | 1 | C |
|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

BCH = BCH servo motor series

Flange size

040 = 40 mm Flange
 060 = 60 mm Flange
 080 = 80 mm Flange
 100 = 100 mm Flange
 130 = 130 mm Flange
 180 = 180 mm Flange

Length (Number of stacks)

1 = one stack
 2 = two stacks
 3 = three stacks
 4 = four stacks
 5 = five stacks

Speed type:

M = Low Speed (1000/1500 rpm)
 N = Medium Speed (2000 rpm)
 O = High Speed (3000 rpm)

Shaft

0 = Smooth, No Oil Seal
 1 = With key, No Oil Seal
 2 = Smooth, With Oil seal
 3 = With key, With Oil Seal

Encoder

1 = Incremental encoder 2500 ppr (Only for under 3kW - C series)
 2 = High resolution incremental encoder 20 Bits (Only for above 3kW - M series)

Brake

A = w/o brake
 F = with brake (0.1kW no brake option)

Connection System

1 = Straight connector

Mount

C = Asia mechanical mounting

1.3 Servo Drive and Servo Motor Combinations

The table below shows the possible combination of Lexium 23 series servo drives and BCH series servo motors. The boxes (●) in the model names are for optional configurations. (Please refer to Section 1.2 for model explanation)

Lexium 23 Series Servo Drive

| BCH servo motor output power kW | BCH servo motor inertia (without brake) kgcm ² | Rated torque Nm | Peak stall torque Nm | Maximum speed rpm | Rated speed rpm | Combination Servo drive Reference | Servo motor Reference | Motor type |
|--|--|--------------------|-------------------------|----------------------|--------------------|--------------------------------------|-----------------------|-------------------|
| Single phase: 220...255 V ~ 50/60 Hz or three phase : 170...255 V ~ 50/60 Hz | | | | | | | | |
| 0.1 | 0.037 | 0.32 | 0.96 | 5000 | 3000 | LXM23CU01M3X | BCH0401O●1A1C | ultra low inertia |
| 0.2 | 0.177 | 0.64 | 1.92 | 5000 | 3000 | LXM23CU02M3X | BCH0601O●1●1C | ultra low inertia |
| 0.3 | 8.17 | 2.86 | 8.59 | 2000 | 1000 | LXM23CU04M3X | BCH1301M●1●1C | medium inertia |
| 0.4 | 0.277 | 1.27 | 3.82 | 5000 | 3000 | LXM23CU04M3X | BCH0602O●1●1C | ultra low |
| 0.4 | 0.68 | 1.27 | 3.82 | 5000 | 3000 | LXM23CU04M3X | BCH0801O●1●1C | low inertia |
| 0.5 | 8.17 | 2.39 | 7.16 | 3000 | 2000 | LXM23CU04M3X | BCH1301N●1●1C | medium inertia |
| 0.6 | 8.41 | 5.73 | 17.19 | 2000 | 1000 | LXM23CU07M3X | BCH1302M●1●1C | medium inertia |
| 0.75 | 1.13 | 2.39 | 7.16 | 5000 | 3000 | LXM23CU07M3X | BCH0802O●1●1C | low inertia |
| 0.9 | 11.18 | 8.59 | 25.78 | 2000 | 1000 | LXM23CU10M3X | BCH1303M●1●1C | medium inertia |
| 1 | 2.65 | 3.18 | 9.54 | 5000 | 3000 | LXM23CU10M3X | BCH1001O●1●1C | low inertia |
| 1 | 8.41 | 4.77 | 14.32 | 3000 | 2000 | LXM23CU10M3X | BCH1302N●1●1C | medium inertia |
| 1.5 | 11.18 | 7.16 | 21.48 | 3000 | 2000 | LXM23CU15M3X | BCH1303N●1●1C | medium inertia |
| Three phase : 1700255 V ~ 50/60 Hz | | | | | | | | |
| 2 | 4.45 | 6.37 | 19.11 | 5000 | 3000 | LXM23CU20M3X | BCH1002O●1●1C | low inertia |
| 2 | 14.59 | 9.55 | 26.65 | 3000 | 2000 | LXM23CU20M3X | BCH1304N●1●1C | medium inertia |
| 2 | 34.68 | 9.55 | 26.65 | 3000 | 2000 | LXM23CU20M3X | BCH1801N●1●1C | high inertia |
| 3 | 54.95 | 19.10 | 57.29 | 3000 | 1500 | LXM23CU30M3X | BCH1802M●1●1C | high inertia |
| 3 | 54.95 | 19.10 | 57.29 | 3000 | 1500 | LXM23MU45M3X | BCH1802M●2●1C | high inertia |
| 3.5 | 54.8 | 16.71 | 50.31 | 3000 | 2000 | LXM23MU45M3X | BCH1802N●2●1C | high inertia |
| 4.5 | 77.75 | 28.65 | 71.62 | 3000 | 1500 | LXM23MU45M3X | BCH1803M●2●1C | high inertia |
| 5.5 | 99.78 | 35.01 | 87.53 | 3000 | 1500 | LXM23MU55M3X | BCH1804M●2●1C | high inertia |
| 7.5 | 142.7 | 47.74 | 119.36 | 3000 | 1500 | LXM23MU75M3X | BCH1805M●2●1C | high inertia |

Also, please ensure that both the servo drive and motor are correctly matched for size (power rating). For the detail specifications of servo drives and motors, please refer to Chapter 11 "Specifications".

The drives shown in the above table are designed according to the three multiple of rated current of motors shown in the above table. If the drives which are designed according to the six multiple of rated current of motors are needed, please contact our distributors or your local Schneider electric sales representative.

1.4 Servo Drive Features

Lexium 23C Series Servo Drive

Heatsink
Used to secure servo drive and for heat dissipation

Charge LED
A lit LED indicates that either power is connected to the servo drive OR a residual charge is present in the drive's internal power components. **DO NOT TOUCH ANY ELECTRICAL CONNECTIONS WHILE THIS LED IS LIT.** (Please refer to the Safety Precautions on page i).

Control Circuit Terminal (L1, L2)
Used to connect 200-230Vac, 50/60Hz 1-phase/3-phase VAC supply.

Main Circuit Terminal (R, S, T)
Used to connect 200-230V, 50/60Hz commercial power supply

Servo Motor Output (U, V, W)
Used to connect servo motor, Never connect the output terminal to main circuit power. The AC servo drive may be destroyed beyond repair if incorrect cables are connected to the output terminals.

Internal/External Regenerative Resistor Terminal

- 1) When using an external regenerative resistor, connect PA/+ and PBe to the regenerative resistor and ensure that the circuit between PA/+ and PBi is open.
- 2) When using the internal regenerative resistor, ensure that the circuit between PA/+ and PBi is closed and the circuit between PA/+ and PBe is open.

LED Display
The 5 digit, 7 segment LED displays the servo status or fault codes

Operation Panel
Used function keys to perform status display, monitor and diagnostic, function and parameter setting.
Function Keys:

M : Press this key to select/change mode

S : Shift Key has several functions:
moving the cursor and indexing through the parameter groups
Press this key to shift cursor to the left

▲ : Press this key to increase values on the display

▼ : Press this key to decrease values on the display


ENT : Press this key to store data

I/O Interface
Used to connect Host Controller (PLC) or control I/O signal

Encoder Interface
Used to connect Encoder of Servo Motor

Serial Communication Interface
For RS-485/232/422 serial communication
Used to connect personal computer or other controllers

Ground Terminal



Lexium 23M Series Servo Drive

Heatsink
Used to secure servo drive and for heat dissipation

Charge LED
A lit LED indicates that either power is connected to the servo drive OR a residual charge is present in the drive's internal power components. **DO NOT TOUCH ANY ELECTRICAL CONNECTIONS WHILE THIS LED IS LIT.** (Please refer to the Safety Precautions on page i).

Control Circuit Terminal (L1, L2)
Used to connect 230Vac, 50/60Hz 3-phase VAC supply.

Main Circuit Terminal (R, S, T)
Used to connect 230V, 50/60Hz commercial power supply

Servo Motor Output (U, V, W)
Used to connect servo motor, Never connect the output terminal to main circuit power. The AC servo drive may be destroyed beyond repair if incorrect cables are connected to the output terminals.

Internal/External Regenerative Resistor Terminal
1) When using an external regenerative resistor, connect PA/+ and PBe to the regenerative resistor and ensure that the circuit between PA/+ and PBi is open.
2) When using the internal regenerative resistor, ensure that the circuit between PA/+ and PBi is closed and the circuit between PA/+ and PBe is open.

LED Display
The 5 digit, 7 segment LED displays the servo status or fault codes

Operation Panel
Used function keys to perform status display, monitor and diagnostic, function and parameter setting.
Function Keys:


- (M)** : Press this key to select/change mode
- (S)** : Shift Key has several functions:
moving the cursor and indexing through the parameter groups
Press this key to shift cursor to the left
- (▲)** : Press this key to increase values on the display
- (▼)** : Press this key to decrease values on the display
- (ENT)** : Press this key to store data

I/O Interface
Used to connect Host Controller (PLC) or control I/O signal

Encoder Interface
Used to connect Encoder of Servo Motor

Serial Communication Interface
For RS-485/232/422 serial communication
Used to connect personal computer or other controllers

Ground Terminal



1.5 Control Modes of Servo Drive

The Schneider electric Servo can be programmed to provide six single and five dual modes of operation.

Their operation and description is listed in the following table.

| Mode | | Code | Description |
|-------------|---------------------------|------|--|
| Single Mode | External Position Control | Pt | Position control for the servo motor is achieved via an external pulse command. |
| | Motion Sequence Control | Pr | Position control for the servo motor is achieved via by 8 commands stored within the servo controller. Execution of the 8 positions is via Digital Input (DI) signals. |
| | Speed Control | S | Speed control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command. Control of the internal speed parameters is via the Digital Inputs (DI). (A maximum of three speeds can be stored internally). |
| | Internal Speed Control | Sz | Speed control for the servo motor is only achieved via parameters set within the controller. Control of the internal speed parameters is via the Digital Inputs (DI). (A maximum of three speeds can be stored internally). |
| | Torque Control | T | Torque control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command. Control of the internal torque parameters is via the Digital Inputs (DI). (A maximum of three torque levels can be stored internally). |
| | Internal Torque Control | Tz | Torque control for the servo motor is only achieved via parameters set within the controller. Control of the internal torque parameters is via the Digital Inputs (DI). (A maximum of three torque levels can be stored internally). |
| Dual Mode | | Pt-S | Either Pt or S control mode can be selected via the Digital Inputs (DI) |
| | | Pt-T | Either Pt or T control mode can be selected via the Digital Inputs (DI) |
| | | Pr-S | Either Pr or S control mode can be selected via the Digital Inputs (DI) |
| | | Pr-T | Either Pr or T control mode can be selected via the Digital Inputs (DI) |
| | | S-T | Either S or T control mode can be selected via the Digital Inputs (DI) |


The above control modes can be accessed and changed via by parameter P1-01. If the control mode is changed, switch the drive off and on after the new control mode has been entered. The new control mode will only be valid after drive off/on action. Please see safety precautions on page iii (switching drive off/on multiple times).

1.6 Molded-case Circuit Breaker and Fuse Current

Lexium 23 Series Servo Drive

| Servo drive Reference | Nominal power | Circuit Breaker | Fuse to be placed upstream |
|-----------------------|---------------|-----------------|----------------------------|
| | kW | A | A |
| LXM23CU01M3X | 0.1 | 6.3 | 5 |
| LXM23CU02M3X | 0.2 | 6.3 | 5 |
| LXM23CU04M3X | 0.4 | 10 | 20 |
| LXM23CU07M3X | 0.75 | 10 | 20 |
| LXM23CU10M3X | 1 | 14 | 25 |
| LXM23CU15M3X | 1.5 | 25 | 40 |
| LXM23CU20M3X | 2 | 30 | 60 |
| LXM23CU30M3X | 3 | 30 | 80 |
| LXM23MU45M3X | 4.5 | 50 | 120 |
| LXM23MU55M3X | 5.5 | 100 | 120 |
| LXM23MU75M3X | 7.5 | 100 | 120 |

Installation and Storage



At a Glance

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|---|------|
| Installation Notes | 24 |
| Storage Conditions | 25 |
| Installation Conditions | 26 |
| Installation Procedure and Minimum Clearances | 27 |

2.1 Installation Notes

Pay close attention on the following installation notes:

- Do not bend or strain the connection cables between servo drive and motor.
 - When mounting servo drive, make sure to tighten screws to secure the drive in place.
 - If the servo motor shaft is coupled directly to a rotating device ensure that the alignment specifications of the servo motor, coupling, and device are followed. Failure to do so may cause unnecessary loads or premature failure to the servo motor.
 - If the length of cable connected between servo drive and motor is more than 20m, please increase the wire gauge of the encoder cable and motor connection cable (connected to U, V, W terminals).
 - Make sure to tighten the screws for securing motor.
-

2.2 Storage Conditions

The product should be kept in the shipping carton before installation. In order to retain the warranty coverage, the AC servo drive should be stored properly when it is not to be used for an extended period of time. Some storage suggestions are:

- Store in a clean and dry location free from direct sunlight.
 - Store within an ambient temperature range of -20°C to +65°C (-4°F to 149°F).
 - Store within a relative humidity range of 0% to 90% and non-condensing.
 - Do not store in a place subjected to corrosive gases and liquids.
 - Correctly packaged and placed on a solid surface.
-

2.3 Installation Conditions

Operating Temperature

Lexium 23 Series Servo Drive : 0°C to 55°C (32°F to 131°F)

BCH Series Servo Motor : 0°C to 40°C (32°F to 104°F)

The ambient temperature of servo drive for long-term reliability should be under 45°C (113°F).

If the ambient temperature of servo drive is greater than 45°C (113°F), please install the drive in a wellventilated location and do not obstruct the airflow for the cooling fan.

Caution

The servo drive and motor will generate heat. If they are installed in a control panel, please ensure sufficient space around the units for heat dissipation.

Pay particular attention to vibration of the units and check if the vibration has impacted the electric devices in the control panel. Please observe the following precautions when selecting a mounting location. **Failure to** observe the following precautions may void the warranty!


- Do not mount the servo drive or motor adjacent to heat-radiating elements or in direct sunlight.
 - Do not mount the servo drive or motor in a location subjected to corrosive gases, liquids, or airborne dust or metallic particles.
 - Do not mount the servo drive or motor in a location where temperatures and humidity will exceed specification.
 - Do not mount the servo drive or motor in a location where vibration and shock will exceed specification.
 - Do not mount the servo drive or motor in a location where it will be subjected to high levels of electromagnetic radiation.
-

2.4 Installation Procedure and Minimum Clearances

Installation Procedure

Incorrect installation may result in a drive malfunction or premature failure of the drive and or motor. Please follow the guidelines in this manual when installing the servo drive and motor.

The Lexium 23 servo drive should be mounted perpendicular to the wall or in the control panel. In order to ensure the drive is well ventilated, ensure that the all ventilation holes are not obstructed and sufficient free space is given to the servo drive. Do not install the drive in a horizontal position or malfunction and damage will occur.



Drive Mounting

The Lexium 23 Servo drives must be back mounted vertically on a dry and solid surface such as a NEMA enclosure. A minimum spacing of two inches must be maintained above and below the drive for ventilation and heat dissipation. Additional space may be necessary for wiring and cable connections. Also, as the drive conducts heat away via the mounting, the mounting plane or surface should be conductor away and not conduct heat into the drive from external sources

Motor Mounting


The BCH Servo motors should be mounted firmly to a dry and solid mounting surface to ensure maximum heat transfer for maximum power output and to provide a good ground.

For the dimensions and weights specifications of servo drive or motor, please refer to Chapter 11 "Specifications".


Minimum Clearances

Install a fan to increase ventilation to avoid ambient temperatures that exceed the specification. When installing two or more drive adjacent to each other please follow the clearances as shown in the following diagram.

● **Minimum Clearances**



● **Side by Side Installation**



Connections and Wiring



At a Glance

Presentation

This chapter provides information on wiring Lexium 23 series products, the descriptions of I/O signals and gives typical examples of wiring diagrams.

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|---|------|
| Connections | 30 |
| Basic Wiring | 40 |
| Input / Output Interface Connector -CN1 | 43 |
| Encoder Connector CN2 | 62 |
| Serial Communication Connector CN3 | 64 |
| Standard Connection Example | 66 |

3.1 Connections

3.1.1 Connecting to Peripheral Devices

In Figure 3.1 and 3.2, it briefly explains how to connect each peripheral device.
Figure 3.1 (Lexium 23C Series)





Figure 3.2 (Lexium 23M Series)



3.1.2 Servo Drive Connectors and Terminals

| Terminal Identification | Terminal Description | Notes | |
|--|--|---|--|
| L1, L2 | Control circuit terminal | The servo Control Circuit requires an independent 220V single-phase VAC supply. | |
| R, S, T | Main circuit terminal | The Main Circuit Terminal is used to supply the servo with line power. If a single-phase supply, is used connect the R and S terminals to power. If 3-phase, connect all three R, S, & T terminals. To provide Control Circuit power two jumpers can be added from R and S to L1 and L2. | |
| U, V, W, FG | Servo motor output | Used to connect servo motor | |
| | | Terminal Symbol | Wire Color |
| | | U | Red |
| | | V | White |
| | | W | Black |
| FG | Green | | |
| PA/+, PBi, PBe | Regenerative resistor terminal | Internal resistor | Ensure the circuit is closed between PA/+ and PBi, and the circuit is open between PA/+ and PBe. |
| | | External resistor | Connect regenerative resistor to PA/+ and PBe, and ensure an open circuit between PA/+ and PBi. |
| P, N | P: Main circuit (+) terminal N: Main circuit (-) terminal | Braking unit is suitable for 2kW and above models. When using braking unit, ensure to connect (+) terminal of the braking unit to P, main circuit (+) terminal of the servo drive, and connect (-) terminal of the braking unit to N, main circuit (-) terminal of the servo drive. The braking unit is an optional part. Usually, the braking unit is not necessary. It is used to absorb the large regenerative power that is generated when the external load is much greater than the motor torque. | |
|  two places | Ground terminal | Used to connect grounding wire of power supply and servo motor. | |
| CN1 | I/O connector | Used to connect external controllers. Please refer to section 3.3 for details. | |
| CN2 | Encoder connector | Used to connect encoder of servo motor. Please refer to section 3.4 for details. | |
| | | Lexium 23C Series | |
| | | Terminal Symbol | Wire Color |
| | | A | Black |
| | | /A | Black/Red |
| | | B | White |
| | | /B | White/Red |
| | | Z | Orange |
| | | /Z | Orange/Red |
| | | +5V | Brown & Brown/White |
| | | GND | Blue & Blue/White |
| | | Lexium 23M Series | |
| | | Terminal Symbol | Wire Color |
| | | Line driver SD | Blue |
| | | Line driver /SD | Blue/Black |
| Vcc | Red | | |
| GND | Black | | |
| CN3 | Communication connector | Used to connect PC or keypad. Please refer to section 3.5 for details. | |

Note: U, V, W, CN1, CN2, CN3 terminals provide short circuit protection.

Wiring Notes

Please observe the following wiring notes while performing wiring and touching any electrical connections on the servo drive or servo motor.

1. Ensure to check if the power supply and wiring of the "power" terminals (R, S, T, U, V, & W) is correct.
 2. Please use shielded twisted-pair cables for wiring to prevent voltage coupling and eliminate electrical noise and interference.
 3. As a residual hazardous voltage may remain inside the drive, please do not immediately touch any of the "power" terminals (R, S, T, U, V, & W) and/or the cables connected to them after the power has been turned off and the charge LED is lit. (Please refer to the Safety Precautions on page ii).
 4. The cables connected to R, S, T and U, V, W terminals should be placed in separate conduits from the encoder or other signal cables. Separate them by at least 30cm (11.8 inches).
 5. If the encoder cable is too short, please use a twisted-shield signal wire with grounding conductor. The wire length should be 20m (65.62ft.) or less. For lengths greater than 20m (65.62ft.), the wire gauge should be doubled in order to lessen any signal attenuation.
 6. As for motor cable selection, please use the 600V PTFE wire and the wire length should be less than 98.4ft. (30m). If the wiring distance is longer than 30m (98.4ft.), please choose the adequate wire size according to the voltage.
 7. The shield of shielded twisted-pair cables should be connected to the SHIELD end (terminal marked ) of the servo drive.
 8. For the connectors and cables specifications, please refer to section 3.1.6 for details.
-

3.1.3 Wiring Methods

For servo drives from 100W to 1.5kW the input power can be either single or three-phase. For servo drives 2kW and above only three-phase connections are available. In the wiring diagram figures 3.3 & 3.4:

Power ON : contact "a" (normally open)

Power OFF or Alarm Processing : contact "b" (normally closed)

1MC/a : self-holding power

1MC : contact of main circuit power

Figure 3.3 Single-Phase Power Supply Connection (for 1.5kW and below models)











Figure 3.4 Three-Phase Power Supply Connection (for 2kW and above models)





3.1.4 Motor Power Cable Connector Specifications

| Motor Model Name | U, V, W / Electromagnetic Brake Connector | Terminal Identification |
|---|---|-------------------------|
| BCH0401O (100W) BCH0601O (200W) BCH0602O (400W) BCH0801O (400W) BCH0802O (750W) |   HOUSING:JOWLE (C4201H00-2*2PA) | A |
| BCH0601O (200W) BCH0602O (400W) BCH0801O (400W) BCH0801O (750W) |   HOUSING:JOWLE (C4201H00-2*3PA) | B |

| Motor Model Name | U, V, W / Electromagnetic Brake Connector | Terminal Identification |
|---|---|-------------------------|
| BCH1301M (300 W) BCH1301N (500W) BCH1302M (600 W) BCH1303M (900 W) BCH1001O (1000W) BCH1302N (1000W) BCH1303N (1500W) BCH1002O (2000W) BCH1304N (2000W) |  <p>3106A-20-18S</p> | C |
| BCH1801N (2000W) BCH1802N (3500W) BCH1802M (3000W) BCH1803M (4500W) BCH1804M (5500W) BCH1805M (7500W) |  <p>3106A-24-11S</p> | D |

| Terminal Identification | U (Red) | V (White) | W (Black) | CASE GROUND (Green) | BRAKE1 (Blue) | BRAKE2 (Brown) |
|-------------------------|---------|-----------|-----------|---------------------|---------------|----------------|
| A | 1 | 2 | 3 | 4 | - | - |
| B | 1 | 2 | 3 | 4 | 5 | 6 |
| C | F | I | B | E | G | H |
| D | D | E | F | G | A | B |

3.1.5 Encoder Connector Specifications

| Motor Model Name | Encoder Connector | Terminal Identification |
|---|---|-------------------------|
| BCH0401O (100W) BCH0601O (200W) BCH0602O (400W) BCH0801O (400W) BCH0802O (750W) |  <p>HOUSING: AMP (1-172161-9)</p> | A |
| BCH1301M (300 W) BCH1301N (500W) BCH1302M (600 W) BCH1303M (900 W) BCH1001O (1000W) BCH1302N (1000W) BCH1303N (1500W) BCH1002O (2000W) BCH1304N (2000W) |  <p>3106A-20-29S</p> | B |

| Terminal Identification AMP (1-172161-9) | A (Black) | /A (Black/ Red) | B (White) | /B (White/ Red) | Z (Orange) | /Z (Orange/ Red) | +5V (Brown & Brown/ White) | GND (Blue & Blue/ White) | BRAIDS HELD |
|--|--------------|------------------------|--------------|-------------------------|---------------|--------------------------|-------------------------------------|-------------------------------------|----------------|
| A | 1 | 4 | 2 | 5 | 3 | 6 | 7 | 8 | 9 |
| Terminal Identification 3106A-20- 29S | A (Blue) | /A (Blue/ Black) | B (Green) | /B (Green/ Black) | Z (Yellow) | /Z (Yellow/ Black) | +5V (Red & Red/ White) | GND (Black & Black/ White) | BRAIDS HELD |
| B | A | B | C | D | F | G | S | R | L |

3.1.6 Cable Specifications for Servo Drive

The boxes (●) in the model names are for optional configurations. (Please refer to section 1.2 for model explanation.)

Power Cable

| Servo Drive and Servo Motor | | Power Cable - Wire Gauge mm ² (AWG) | | | |
|-----------------------------|----------------|--|-------------|--------------|-------------|
| | | L1, L2 | R, S, T | U, V, W | PA/+, PBe |
| LXM23CU01M3X | BCH0401O●●●A1C | 1.3 (AWG16) | 2.1 (AWG14) | 0.82 (AWG18) | 2.1 (AWG14) |
| LXM23CU02M3X | BCH0601O●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 0.82 (AWG18) | 2.1 (AWG14) |
| LXM23CU04M3X | BCH0602O●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 0.82 (AWG18) | 2.1 (AWG14) |
| | BCH0801O●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 0.82 (AWG18) | 2.1 (AWG14) |
| | BCH1301N●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 0.82 (AWG18) | 2.1 (AWG14) |
| | BCH1301M●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 0.82 (AWG18) | 2.1 (AWG14) |
| LXM23CU07M3X | BCH0802O●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 0.82 (AWG18) | 2.1 (AWG14) |
| | BCH1302M●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 0.82 (AWG18) | 2.1 (AWG14) |
| LXM23CU10M3X | BCH1001O●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 1.3 (AWG16) | 2.1 (AWG14) |
| | BCH1302N●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 1.3 (AWG16) | 2.1 (AWG14) |
| | BCH1303M●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 1.3 (AWG16) | 2.1 (AWG14) |
| LXM23CU15M3X | BCH1303N●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 1.3 (AWG16) | 2.1 (AWG14) |
| LXM23CU20M3X | BCH1001O●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 2.1 (AWG14) | 2.1 (AWG14) |
| | BCH1304N●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 2.1 (AWG14) | 2.1 (AWG14) |
| | BCH1801N●●●1C | 1.3 (AWG16) | 2.1 (AWG14) | 3.3 (AWG12) | 2.1 (AWG14) |
| LXM23MU45M3X | BCH1802N●●●1C | 1.3 (AWG16) | 3.3 (AWG12) | 3.3 (AWG12) | 3.3 (AWG12) |
| | BCH1802M●●●1C | 1.3 (AWG16) | 3.3 (AWG12) | 3.3 (AWG12) | 3.3 (AWG12) |
| | BCH1803M●●●1C | 1.3 (AWG16) | 3.3 (AWG12) | 8.4 (AWG12) | 3.3 (AWG12) |
| LXM23MU55M3X | BCH1804M●●●1C | 1.3 (AWG16) | 3.3 (AWG12) | 8.4 (AWG12) | 3.3 (AWG12) |
| LXM23MU75M3X | BCH1805M●●●1C | 1.3 (AWG16) | 3.3 (AWG12) | 8.4 (AWG12) | 3.3 (AWG12) |

Encoder Cable

| Servo Drive | Encoder Cable - Wire Gauge mm ² (AWG) | | | |
|--------------|--|------------------|-----------|--------------|
| | Wire Size | Core Number | UL Rating | Wire Length |
| LXM23CU01M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23CU02M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23CU04M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23CU07M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23CU10M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23CU15M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23CU20M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23MU45M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23MU55M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |
| LXM23MU75M3X | 0.13 (AWG26) | 10 core (4 pair) | UL2464 | 3m (9.84ft.) |

Note:

- 1) Please use shielded twisted-pair cables for wiring to prevent voltage coupling and eliminate electrical noise and interference.
- 2) The shield of shielded twisted-pair cables should be connected to the SHIELD end (terminal marked ) of the servo drive.
- 3) In order to prevent fire hazard and accidents, please form the wiring by following the cable specifications outlined above.

Figure 3.6 Basic Wiring Schematic of 2kW - 3kW models





Figure 3.7 Basic Wiring Schematic of 4.5kW and above models




3.3 Input / Output Interface Connector -CN1

The CN1 Interface Connector provides access to three signal groups:

- i General interface for the analog speed and torque control, encoder reference signal from the motor, pulse / direction inputs, and reference voltages.
 - ii 8 programmable Digital Inputs (DI), can be set via parameters P2-10 ~ P2-17
 - iii 5 programmable Digital Outputs (DO), can be set via parameters P2-18 ~ P2-22
- A detailed explanation of each group is available in Section 3.3.2, Tables 3.A, 3.B & 3.C.

3.3.1 CN1 Terminal Identification

Figure 3.8 The Layout of CN1 Drive Connector



| | | | | | |
|----|---------|--------------------------------------|----|--------|--|
| 1 | DO4+ | Digital output | 2 | DO3- | Digital output |
| 3 | DO3+ | Digital output | 4 | DO2- | Digital output |
| 5 | DO3+ | Digital output | 6 | DO1- | Digital output |
| 7 | DO1+ | Digital output | 8 | DI4- | Digital input |
| 9 | DI1- | Digital input | 10 | DI2- | Digital input |
| 11 | COM+ | Power input (12-24V) | 12 | GND | Analog input signal ground |
| 13 | GND | Analog input signal ground | 14 | NC | No Connection |
| 15 | MON2 | Analog monitor output 2 | 16 | MON1 | Analog monitor output 1 |
| 17 | VDD | +24V power output (for external I/O) | 18 | T_REF | Analog torque Input |
| 19 | GND | Analog input signal ground | 20 | VCC | +12V power output (for analog command) |
| 21 | OA | Encoder A pulse output | 22 | /OA | Encoder /A pulse output |
| 23 | /OB | Encoder /B pulse output | 24 | /OZ | Encoder /Z pulse output |
| 25 | OB | Encoder B pulse output | 26 | DO4- | Digital output |
| 27 | DO5- | Digital output | 28 | DO5+ | Digital output |
| 29 | /HPULSE | High-speed Pulse input (-) | 30 | DI8- | Digital input |
| 31 | DI7- | Digital input | 32 | DI6- | Digital input |
| 33 | DI5- | Digital input | 34 | DI3- | Digital input |
| 35 | PULL HI | Pulse applied power | 36 | SIGN | Position sign (+) |
| 37 | /SIGN | Position sign (-) | 38 | HPULSE | High-speed Pulse input (+) |
| 39 | NC | No Connection | 40 | /HSIGN | High-speed position sign (-) |
| 41 | /PULSE | Pulse input (-) | 42 | V_REF | Analog speed input (+) |
| 43 | PULSE | Pulse input (+) | 44 | GND | Analog input signal ground |
| 45 | COM- | VDD(24V) power ground | 46 | HSIGN | High-speed position sign (+) |
| 47 | COM- | VDD(24V) power ground | 48 | OCZ | Encoder Z pulse Open-collector output |
| 49 | COM- | VDD(24V) power ground | 50 | OZ | Encoder Z pulse Line-driver output |

Note:

- 1) CN1 terminal signal, HSIGN (pin 46), /HSIGN (pin 40), HPULSE (pin 38), and /HPULSE (pin 29) are provided in Lexium 23M series only. In Lexium 23C series, the function of these terminals is "NC", which means "No Connection".
- 2) The terminals marked "NC" must be left unconnected (No Connection). The NC terminals are used within the servo drive. Any outside connection to the NC terminals will result in damage to the drive and void the warranty!

3.3.2 Signals Explanation of Connector CN1

The Tables 3.A, 3.B, & 3.C detail the three groups of signals of the CN1 interface. Table 3.A details the general signals. Table 3.B details the Digital Output (DO) signals and Table 3.C details the Digital Input (DI) signals. The General Signals are set by the factory and can not be changed, eprogrammed or adjusted. Both the Digital Input and Digital Output signals can be programmed by the users.

Table 3.A General Signals

| Signal | | Pin No. | Details | Wiring Diagram (Refer to 3.3.4) |
|---|--------------------------------------|----------------------|---|------------------------------------|
| Analog Signal Input | V_REF | 42 | Motor speed command: -10V to +10V, corresponds to the maximum speed programmed P1-55 Maximum Speed Limit (Factory default 3000 r/min). | C1 |
| | T_REF | 18 | Motor torque command: -10V to +10V, corresponds to -100% to +100% rated torque command. | C1 |
| Analog Monitor Output | MON1 MON2 | 16 15 | The MON1 and MON2 can be assigned drive and motor parameters that can be monitored via an analogue voltage. Please reference parameter P0-03 for monitoring commands and P1-04 / P1-05 for scaling factors. Output voltage is reference to the power ground. | C2 |
| Position Pulse Input | PULSE /PULSE SIGN /SIGN | 43 41 36 37 | The drive can accept two different types of pulse inputs: Open Collector and Line Driver. Three different pulse commands can be selected via parameter P1-00. Quadrature, CW + CCW pulse & Pulse / Direction. | C3/C4-1 |
| | PULL HI | 35 | Should an Open Collector type of pulse be used this terminal must be lull high to pin 17. | C3 |
| Highspeed Position Pulse Input | HSIGN /HSIGN HPULSE /HPULSE | 46 40 38 29 | The drive can accept two different types of pulse inputs: Open Collector and Line Driver. Three different pulse commands can be selected via parameter P1-00. Quadrature, CW + CCW pulse & Pulse / Direction. These signals are used for Lexium 23M series only. In Lexium 23C series, these terminals are marked "NC", which means "No Connection" and must be left unconnected. | C4-2 |

| Signal | | Pin No. | Details | Wiring Diagram (Refer to 3.3.4) |
|-----------------------------|--------------|----------------------|--|------------------------------------|
| Position Pulse Output | OA /OA | 21 22 | The motor encoder signals are available through these terminals. The encoder output pulse count can be set via parameter P1-46. | C11/C12 |
| | OB /OB | 25 23 | | |
| | OZ /OZ | 50 24 | | |
| Power | VDD | 17 | VDD is the +24V source voltage provided by the drive. Maximum permissible current 500mA. | - |
| | COM+ COM- | 11 45 47 49 | COM+ is the common voltage rail of the Digital Input and Digital Output signals. Connect VDD to COM+ for source mode. For external applied power sink mode (+12V to +24V), the positive terminal should be connected to COM+ and the negative to COM-. | |
| | VCC | 20 | VCC is a +12V power rail provided by the drive. It can be used for the input on an analog speed or torque command. Maximum permissible current 100mA. | |
| Power | GND | 12,13,19,44 | The polarity of VCC is with respect to Ground (GND). | - |
| Other | NC | 14,29,38,39,40,46,48 | See previous note for NC terminals CN1 connector on page 3-15. | - |

The Digital Input (DI) and Digital Output (DO) have factory default settings which correspond to the various servo drive control modes. (See section 1.5). However, both the DI's and DO's can be programmed independently to meet the requirements of the users.

Detailed in Tables 3.B and 3.C are the DO and DI functions with their corresponding signal name and wiring schematic. The factory default settings of the DI and DO signals are detailed in Table 3.G and 3.H.

All of the DI's and DO's and their corresponding pin numbers are factory set and non-changeable, however, all of the assigned signals and control modes are user changeable. For Example, the factory default setting of DO5 (pins 28/27) can be assigned to DO1 (pins 7/6) and vice versa.

The following Tables 3.B and 3.C detail the functions, applicable operational modes, signal name and relevant wiring schematic of the default DI and DO signals

Table 3.B DO Signals

| DO Signal | DO Code | Assigned Control Mode | Pin No. (Default) | | Details ^(*) | Wiring Diagram (Refer to 3.3.4) |
|-----------|---------|--------------------------------|-------------------|----|--|---------------------------------|
| | | | + | - | | |
| SRDY | 01 | ALL | 7 | 6 | SRDY is activated when the servo drive is ready to run. All fault and alarm conditions, if present, have been cleared. | C5/C6/C7/C8 |
| SON | 02 | Not assigned | - | - | SON is activated when control power is applied the servo drive. The drive may or may not be ready to run as a fault / alarm condition may exist. Servo ON (SON) is "ON" with control power applied to the servo drive, there may be a fault condition or not. The servo is not ready to run. Servo ready (SRDY) is "ON" where the servo is ready to run, NO fault / alarm exists. (P2-51 should turn servo ready SRDY off / on) | |
| ZSPD | 03 | ALL | 5 | 4 | ZSPD is activated when the drive senses the motor is equal to or below the Zero Speed Range setting as defined in parameter P1- 38. For Example, at factory default ZSPD will be activated when the drive detects the motor rotating at speed at or below 10 r/min. ZSPD will remain activated until the motor speed increases above 10 r/min. | |
| TSPD | 04 | ALL | 3 | 2 | TSPD is activated once the drive has detected the motor has reached the Target Rotation Speed setting as defined in parameter P1-39. TSPD will remain activated until the motor speed drops below the Target Rotation Speed. | |
| TPOS | 05 | Pt, Pr, Pt-S, Pt-T, Pr-S, Pr-T | 1 | 26 | <ol style="list-style-type: none"> 1. When the drive is in Pt mode, TPOS will be activated when the position error is equal and below the setting value of P1- 54. 2. When the drive is in Pr mode, TPOS will be activated when the drive detects that the position of the motor is in a -P1-54 to +P1-54 band of the target position. For Example, at factory default TPOS will activate once the motor is in -99 pulses range of the target position, then deactivate after it reaches +99 pulses range of the desired position. | |

| DO Signal | DO Code | Assigned Control Mode | Pin No. (Default) | | Details(*1) | Wiring Diagram (Refer to 3.3.4) |
|-----------|---------|-----------------------|-------------------|----|--|---------------------------------|
| | | | + | - | | |
| TQL | 06 | Not assigned | - | - | TQL is activated when the drive has detected that the motor has reached the torques limits set by either the parameters P1-12 - P1-14 of via an external analog voltage. | C5/C6/C7/C8 |
| ALRM | 07 | ALL | 28 | 27 | ALRM is activated when the drive has detected a fault condition. (However, when Reverse limit error, Forward limit error, Emergency stop, Serial communication error, and Undervoltage these fault occur, WARN is activated first.) | |
| BRKR | 08 | ALL | 1 | 26 | BRKR is activated actuation of motor brake. | |
| HOME | 09 | ALL | 3 | 2 | HOME is activated when the servo drive has detected that the "HOME" sensor (Digital Input 24) has been detected and the home conditions set in parameters P1-47, P1-50, and P1-51 have been satisfied. | |
| OLW | 10 | ALL | - | - | OLW is activated when the servo drive has detected that the motor has reached the output overload level set by the parameter P1-56. | |
| WARN | 11 | ALL | - | - | Servo warning activated. WARN is activated when the drive has detected Reverse limit error, Forward limit error, Emergency stop, Serial communication error, and Undervoltage these fault conditions. | |
| CMDOK | 12 | Pr | - | - | Internal position command completed output. CMDOK is activated when the servo drive has detected that the internal position command has been completed or stopped after the delay time which is set by the parameter P1-62 has elapsed. | |

Footnote *1: The "state" of the output function may be turned ON or OFF as it will be dependant on the settings of P2-18-P2-22.

Note:

- 1) PINS 3 & 2 can either be TSPD or HOME dependent upon control mode selected.
- 2) PINS 1 & 26 are different depending on control mode either BRKR or TPOS.

Table 3.C DI Signals

| DI Signal | DI Code | Assigned Control Mode | Pin No. (Default) | Details ^(*)2) | Wiring Diagram (Refer to 3.3.4) |
|-----------|---------|----------------------------|-------------------|--|---------------------------------|
| SON | 01 | ALL | 9 | Servo On. Switch servo to "Servo Ready". Check parameter P2-5 1. | C9/C10 |
| ARST | 02 | ALL | 33 | A number of Faults (Alarms) can be cleared by activating ARST. Please see table 10-3 for applicable faults that can be cleared with the ARST command. However, please investigate Fault or Alarm if it does not clear or the fault description warrants closer inspection of the drive system. | |
| GAINUP | 03 | ALL | - | Gain switching in speed and position mode | |
| CCLR | 04 | Pt, Pr | 10 | When CCLR is activated the setting is parameter P2-50 Pulse Clear Mode is executed. | |
| ZCLAMP | 05 | ALL | - | When this signal is On and the motor speed value is lower than the setting value of P1-38, it is used to lock the motor in the instant position while ZCLAMP is On. | |
| CMDINV | 06 | Pr, T, S | - | When this signal is On, the motor is in reverse rotation. | |
| HOLD | 07 | Not assigned | | Internal position control command pause | |
| CTRG | 08 | Pr, Pr-S, Pr-T | 10 | When the drive is in Pr mode and CTRG is activated, the drive will command the motor to move the stored position which correspond the POS 0, POS 1, POS 2 settings. Activation is triggered on the rising edge of the pulse. | |
| TRQLM | 09 | S, Sz | 10 | ON indicates the torque limit command is valid. | |
| SPDLM | 10 | T, Tz | 10 | ON indicates the speed limit command is valid. | |
| POS0 | 11 | Pr, Pr-S, Pr-T | 34 | When the Pr Control Mode is selected the 8 stored positions are programmed via a combination of the POS 0, POS 1, and POS 2 commands. See table 3.D. | |
| POS1 | 12 | | 8 | | |
| POS2 | 13 | | - | | |
| SPD0 | 14 | S, Sz, Pt-S, S | 34 | Select the source of speed command: See table 3.E. | |
| SPD1 | 15 | Pr-S, S-T | 8 | | |
| TCM0 | 16 | Pt, T, Tz, Pt-T, Pr-T, S-T | 34 | Select the source of torque command: See table 3.F. | |
| TCM1 | 17 | T, S-T | 8 | | |
| S-P | 18 | Pt-S, Pr-S | 31 | Speed / Position mode switching OFF: Speed, ON: Position | |

| DI Signal | DI Code | Assigned Control Mode | Pin No. (Default) | Details ^(*2) | Wiring Diagram (Refer to 3.3.4) |
|-----------|---------|------------------------|-------------------|---|---------------------------------|
| S-T | 19 | S-T | 31 | Speed / Torque mode switching OFF: Speed, ON: Torque | C9/C10 |
| T-P | 20 | Pt-T, Pr-T | 31 | Torque / Position mode switching OFF: Torque, ON: Position | |
| EMGS | 21 | ALL | 30 | It should be contact "b" and normally ON or a fault (ALE13) will display. | |
| CWL | 22 | Pt, Pr, S, T Sz, Tz | 32 | Reverse inhibit limit. It should be contact "b" and normally ON or a fault (ALE14) will display. | |
| CCWL | 23 | Pt, Pr, S, T Sz, Tz | 31 | Forward inhibit limit. It should be contact "b" and normally ON or a fault (ALE15) will display. | |
| ORGP | 24 | Pr | - | When ORGP is activated, the drive will command the motor to start to search the reference "Home" sensor. | |
| TLLM | 25 | Not assigned | - | Torque limit - Reverse operation (Torque limit function is valid only when P1-02 is enabled) | |
| TRLM | 26 | Not assigned | - | Torque limit - Forward operation (Torque limit function is valid only when P1-02 is enabled) | |
| SHOM | 27 | Pr | - | When SHOM is activated, the drive will command the motor to move to "Home". | |
| INDEX0 | 28 | Pr | - | Feed step selection input 0 - 4 (bit 0 - 4). When the drive is in Pr mode, if users set P1-33 to 2, 3 and 4 (Feed step control mode), feed step control function are provided (1 - 32 steps). [see section 12.6 Feed Step Control] | |
| INDEX1 | 29 | Pr | - | | |
| INDEX2 | 30 | Pr | - | | |
| INDEX3 | 31 | Pr | - | | |
| INDEX4 | 32 | Pr | - | | |
| MDO | 33 | Pr | - | Feed step mode input 0 (bit 0) | |
| MD1 | 34 | Pr | - | Feed step mode input 1 (bit 1) | |
| MDPO | 35 | Pr | - | Manually continuous operation | |
| MDP1 | 36 | Pr | - | Manually single step operation | |
| JOGU | 37 | ALL | - | Forward JOG input. When JOGU is activated, the motor will JOG in forward direction. [see P4-05] | |

| DI Signal | DI Code | Assigned Control Mode | Pin No. (Default) | Details (*2) | Wiring Diagram (Refer to 3.3.4) |
|-----------|---------|------------------------|-------------------|---|---------------------------------|
| JOGD | 38 | ALL | - | Reverse JOG input. When JOGD is activated, the motor will JOG in reverse direction. [see P4-05] | C9/C10 |
| STEPU | 39 | Pr | - | Step up input. When STEPUP is activated, the motor will run to next position. | |
| STEPD | 40 | Pr | - | Step down input. When STEPDOWN is activated, the motor will run to previous position. | |
| STEPB | 41 | Pr | - | Step back input. When STEPBACK is activated, the motor will return to first position. | |
| AUTOR | 42 | Pr | - | Auto run input. When AUTOR is activated, the motor will run automatically according to internal position command. For time interval setting, please see P2-52 to P2-59. | |
| GNUM0 | 43 | Pt, Pr, Pt-S, Pr-S | - | Electronic gear ratio (Numerator) selection 0 [See P2-60-P2-62] | |
| GNUM1 | 44 | Pt, Pr, Pt-S, Pr-S | - | Electronic gear ratio (Numerator) selection 1 [See P2-60-P2-62] | |
| INHP | 45 | Pt, Pt-S | - | Pulse inhibit input. When the drive is in position mode, if INHP is activated, the external pulse input command is not valid. | |
| STF | 46 | S, Sz, Pt-S, Pr-S, S-T | - | Enable motor forward operation. In speed mode, it is used to enable the motor forward operation. | |
| STB | 47 | S, Sz, Pt-S, Pr-S, S-T | - | Enable motor reverse operation. In speed mode, it is used to enable the motor reverse operation. | |

Footnote *2: The "state" of the input function may be turned ON or OFF as it will be dependant on the settings of P2-10~P2-17.

Table 3.D Source of Position Command

| POS2 | POS1 | POS0 | Parameter |
|------|------|------|--------------|
| OFF | OFF | OFF | P1-15, P1-16 |
| OFF | OFF | ON | P1-17, P1-18 |
| OFF | ON | OFF | P1-19, P1-20 |
| OFF | ON | ON | P1-21, P1-22 |
| ON | OFF | OFF | P1-23, P1-24 |
| ON | OFF | ON | P1-25, P1-26 |
| ON | ON | OFF | P1-27, P1-28 |
| ON | ON | ON | P1-29, P1-30 |

Table 3.E Source of Speed Command

| SPD1 | SPD0 | Parameter |
|------|------|------------------------------------|
| OFF | OFF | S mode: analog input Sz mode: 0 |
| OFF | ON | P1-09 |
| ON | OFF | P1-10 |
| ON | ON | P1-11 |

Table 3.F Source of Torque Command

| TCM1 | TCM0 | Parameter |
|------|------|------------------------------------|
| OFF | OFF | T mode: analog input Tz mode: 0 |
| OFF | ON | P1-12 |
| ON | OFF | P1-13 |
| ON | ON | P1-14 |

The default DI and DO signals in different control mode are listed in the following table 3.G and table 3.H. Although the content of the table 3.G and table 3.H do not provide more information than the table 3.B and table 3.C above, as each control mode is separated and listed in different row, it is easy for user to view and can avoid confusion. However, the Pin number of each signal can not be displayed in the table 3.G and table 3.H.

Table 3.G Default DI signals and Control modes

| Signal | DI Code | Function | Pt | Pr | S | T | Sz | Tz | Pt S | Pt T | Pr S | Pr T | S T |
|--------|---------|--|-----|-----|-----|-----|-----|-----|------|------|------|------|-----|
| SON | 01 | Servo On | DI1 | DI1 | DI1 | DI1 | DI1 |
| ARST | 02 | Alarm Reset | DI5 | DI5 | DI5 | DI5 | DI5 | DI5 | | | | | |
| GAINUP | 03 | Gain switching in speed and position mode | | | | | | | | | | | |
| CCLR | 04 | Pulse clear (see P2-50) | DI2 | | | | | | DI2 | DI2 | | | |
| ZCLAMP | 05 | Zero speed CLAMP | | | | | | | | | | | |
| CMDINV | 06 | Command input reverse | | | | | | | | | | | |
| HOLD | 07 | control Position command pause (Internal position control only) | | | | | | | | | | | |
| CTRG | 08 | Command triggered (available in Pr mode only) | | DI2 | | | | | | | DI2 | DI2 | |
| TRQLM | 09 | Torque limit enabled | | | DI2 | | DI2 | | | | | | |
| SPDLM | 10 | Speed limit enabled | | | | DI2 | | DI2 | | | | | |
| POS0 | 11 | Position command selection 0 | | DI3 | | | | | | | DI3 | DI3 | |
| POS1 | 12 | Position command selection 1 | | DI4 | | | | | | | DI4 | DI4 | |
| POS2 | 13 | Position command selection 2 | | | | | | | | | | | |
| SPD0 | 14 | Speed command selection 0 | | | DI3 | | DI3 | | DI3 | | DI5 | | DI3 |
| SPD1 | 15 | Speed command selection 1 | | | DI4 | | DI4 | | DI4 | | DI6 | | DI4 |
| TCM0 | 16 | Torque command selection 0 | DI3 | | | DI3 | | DI3 | | DI3 | | DI5 | DI5 |
| TCM1 | 17 | Torque command selection 1 | DI4 | | | DI4 | | DI4 | | DI4 | | DI6 | DI6 |
| S-P | 18 | Position / Speed mode switching (OFF: Speed, ON: Position) | | | | | | | DI7 | | DI7 | | |
| S-T | 19 | Speed / Torque mode switching (OFF: Speed, ON: Torque) | | | | | | | | | | | DI7 |
| T-P | 20 | Torque / Position mode switching (OFF: Torque, ON: Position) | | | | | | | | DI7 | | DI7 | |

| Signal | DI Code | Function | Pt | Pr | S | T | Sz | Tz | Pt S | Pt T | Pr S | Pr T | S T |
|--------|---------|--|-----|-----|-----|-----|-----|-----|------|------|------|------|-----|
| EMGS | 21 | Emergency stop (contact b, normally closed) | DI8 | DI8 | DI8 | DI8 | DI8 |
| CWL | 22 | Reverse inhibit limit (contact b, normally closed) | DI6 | DI6 | DI6 | DI6 | DI6 | DI6 | | | | | |
| CCWL | 23 | Forward inhibit limit (contact b, normally closed) | DI7 | DI7 | DI7 | DI7 | DI7 | DI7 | | | | | |
| ORGP | 24 | Reference "Home" sensor | | | | | | | | | | | |
| TLLM | 25 | Torque limit - Reverse operation (torque limit function is valid only when P1-02 is enabled) | | | | | | | | | | | |
| TRLM | 26 | Torque limit - Forward operation (torque limit function is valid only when P1-02 is enabled) | | | | | | | | | | | |
| SHOM | 27 | Move to "Home" | | | | | | | | | | | |
| INDEX0 | 28 | Feed step selection input 0 (bit 0) | | | | | | | | | | | |
| INDEX1 | 29 | Feed step selection input 1 (bit 1) | | | | | | | | | | | |
| INDEX2 | 30 | Feed step selection input 2 (bit 2) | | | | | | | | | | | |
| INDEX3 | 31 | Feed step selection input 3 (bit 3) | | | | | | | | | | | |
| INDEX4 | 32 | Feed step selection input 4 (bit 4) | | | | | | | | | | | |
| MD0 | 33 | Feed step mode input 0 | | | | | | | | | | | |
| MD1 | 34 | Feed step mode input 1 | | | | | | | | | | | |
| MDP0 | 35 | Manually continuous operation | | | | | | | | | | | |
| MDP1 | 36 | Manually single step operation | | | | | | | | | | | |
| JOGU | 37 | Forward JOG input | | | | | | | | | | | |
| JOGD | 38 | Reverse JOG input | | | | | | | | | | | |
| STEPU | 39 | Step up input (available in Pr mode only) | | | | | | | | | | | |

| Signal | DI Code | Function | Pt | Pr | S | T | Sz | Tz | Pt S | Pt T | Pr S | Pr T | S T |
|--------|---------|---|----|----|---|---|----|----|------|------|------|------|-----|
| STEPD | 40 | Step down input (available in Pr mode only) | | | | | | | | | | | |
| STEPB | 41 | Step back input. (available in internal auto running mode only) | | | | | | | | | | | |
| AUTOR | 42 | Auto run input | | | | | | | | | | | |
| GNUM0 | 43 | Electronic gear ratio (Numerator) selection 0 [see P2-60-P2-62] | | | | | | | | | | | |
| GNUM1 | 44 | Electronic gear ratio (Numerator) selection 1 [see P2-60-P2-62] | | | | | | | | | | | |
| INHP | 45 | Pulse inhibit input | | | | | | | | | | | |
| STF | 46 | Enable motor forward operation. | | | | | | | | | | | |
| STB | 47 | Enable motor reverse operation. | | | | | | | | | | | |

Note: For Pin numbers of DI1 ~DI8 signals, please refer to section 3.3.1.

Table 3.H Default DO signals and Control modes

| Signal | DO Code | Function | Pt | Pr | S | T | Sz | Tz | Pt S | Pt T | Pr S | Pr T | S T |
|--------|---------|-------------------------------------|-----|-----|-----|-----|-----|-----|------|------|------|------|-----|
| SRDY | 01 | Servo ready | DO1 | DO1 | DO1 | DO1 | DO1 |
| SON | 02 | Servo On | | | | | | | | | | | |
| ZSPD | 03 | At Zero speed | DO2 | DO2 | DO2 | DO2 | DO2 |
| TSPD | 04 | At Speed reached | | | DO3 | DO3 | DO3 | DO3 | DO3 | DO3 | DO3 | DO3 | DO3 |
| TPOS | 05 | At Positioning completed | DO4 | DO4 | | | | | DO4 | DO4 | DO4 | DO4 | DO4 |
| TQL | 06 | At Torques limit | | | | | | | | | | | |
| ALRM | 07 | Servo alarm (Servo fault) activated | DO5 | DO5 | DO5 | DO5 | DO5 |
| BRKR | 08 | Electromagnetic brake control | | | DO4 | DO4 | DO4 | DO4 | | | | | |
| HOME | 09 | Homing completed | DO3 | DO3 | | | | | | | | | |
| OLW | 10 | Output overload warning | | | | | | | | | | | |
| WARN | 11 | Servo warning activated | | | | | | | | | | | |
| CMDOK | 12 | Internal position command completed | | | | | | | | | | | |

Note: For Pin numbers of DO1 ~DO5 signals, please refer to section 3.3.1.

3.3.3 User-defined DI and DO signals

If the default DI and DO signals could not be able to fulfill users' requirements, there are still user-defined DI and DO signals. The setting method is easy and they are all defined via parameters. The user-defined DI and DO signals are defined via parameters P2-10 to P2-17 and P2-18 to P2-22. Please refer to the following Table 3.1 for the settings..

Table 3.1 User-defined DI and DO signals

| Signal Name | Pin No. | Parameter | |
|-------------|---------|-----------|-------|
| DI | DI1- | 9 | P2-10 |
| | DI2- | 10 | P2-11 |
| | DI3- | 34 | P2-12 |
| | DI4- | 8 | P2-13 |
| | DI5- | 33 | P2-14 |
| | DI6- | 32 | P2-15 |
| | DI7- | 31 | P2-16 |
| | DI8- | 30 | P2-17 |

| Signal Name | Pin No. | Parameter | |
|-------------|---------|-----------|-------|
| DO | DO1+ | 7 | P2-18 |
| | DO1- | 6 | |
| | DO2+ | 5 | P2-19 |
| | DO2- | 4 | |
| | DO3+ | 3 | P2-20 |
| | DO3- | 2 | |
| | DO4+ | 1 | P2-21 |
| | DO4- | 26 | |
| | DO5+ | 28 | P2-22 |
| | DO5- | 27 | |

DI signal:


For example: If the users want to set DI1 to be servo on, it only needs to set the value of parameter P2- 10 to 101 (refer to chapter 7).

DO signal:


For example: If the users want to set DO1 to be servo ready, it only needs to set the value of parameter P2-18 to 101 (refer to chapter 7).

3.3.4 Wiring Diagrams of I/O Signals (CN1)



The valid voltage range of analog input command in speed and torque mode is -10V ~+10V. The command value can be set via relevant parameters.



There are two kinds of pulse inputs, Line driver input and Open-collector input. Max. input pulse frequency of Line driver input is 500kpps and max. input pulse frequency of Open-collector input is 200kpps.





Caution: Do not use dual power supply. Failure to observe this caution may result in damage to the servo drive and servo motor.




Caution: Ensure that the ground terminal of the controller and the servo drive should be connected to each other.


Be sure to connect a diode when the drive is applied to inductive load. (Continuous maximum current: 40mA, Instantaneous peak current: max. 100mA)




Use a relay or open-collector transistor to input signal.
 NPN transistor with multiple emitter fingers (SINK Mode)



PNP transistor with multiple emitter fingers (SOURCE Mode)



Caution: Do not use dual power supply. Failure to observe this caution may result in damage to the servo drive and servo motor.



3.4 Encoder Connector CN2

Integrated within the servo motor is an incremental encoder with 2,500PPR and commutation signal.




When power is first applied to the servo drive, control algorithms detect the motor's rotor position through imbedded sensors in the motor within 500msec approximately.

Feedback to the amplifier of the UVW signals for commutation is via the ABZ encoder signal wires.

Following rotor position sensing the amplifier automatically switches to encoding for commutation control.

The 2500PPR encoder is automatically multiplied to 10000PPR by X4 logic for increased control accuracy.

Figure 3.9 The layout of CN2 Drive Connector



CN2 Terminal Signal Identification**Lexium 23C Series**

| Pin No | Signal Name | Terminal Identification | Military Connector | Quick Connector | Description |
|--------|----------------|-------------------------|--------------------|-----------------|-------------------------|
| 2 | /Z phase input | /Z | G | 6 | Encoder /Z phase output |
| 4 | /A phase input | /A | B | 2 | Encoder /A phase output |
| 5 | A phase input | A | A | 1 | Encoder A phase output |
| 7 | B phase input | B | C | 3 | Encoder B phase output |
| 9 | /B phase input | /B | D | 4 | Encoder /B phase output |
| 10 | Z phase input | Z | F | 5 | Encoder Z phase output |
| 14,16 | Encoder power | +5V | S | 7 | Encoder 5V power |
| 13,15 | Encoder power | GND | R | 8 | Grounding |
| | Shielding | Shielding | L | 9 | Shielding |

Lexium 23M Series

| Pin No | Signal Name | Terminal Identification | Military Connector | Quick Connector | Description |
|--------|-----------------|-------------------------|--------------------|-----------------|---------------------------------------|
| 4 | Line driver /SD | /SD | B | 2 | Encoder line driver /SD signal output |
| 5 | Line driver SD | SD | A | 1 | Encoder line driver SD signal output |
| 14,16 | Encoder power | +5V | S | 7 | Encoder 5V power |
| 13,15 | Encoder power | GND | R | 8 | Grounding |
| | Shielding | Shielding | L | 9 | Shielding |


3.5 Serial Communication Connector CN3

3.5.1 CN3 Terminal Layout and Identification

The servo drive can be connected to a PC or controller via a serial communication connector. Users can operate the servo drive through PC software supplied by Schneider electric (contact to the dealer). The communication connector/port of Lexium 23 servo drive can provide three common serial communication interfaces: RS-232, RS-485, and RS-422 connection. RS-232 is mostly be used but is somewhat limited.

The maximum cable length for an RS-232 connection is 15 meters (50 feet). Using RS-485 or RS-422 interface can allow longer distance for transmission and support multiple drives to be connected simultaneously.

Figure 3.10 The layout of CN3 Drive Connector




CN3 Terminal Signal Identification

| Pin No. | Signal Name | Terminal Identification | Description |
|---------|--------------------------|-------------------------|--|
| 1 | Grounding | GND | - |
| 2 | RS-232 data transmission | RS-232-TX | For data transmission of the servo drive. Connected to the RS-232 interface of PC. |
| 3 | RS-422 data receiving | RS-422-RX+ | For data receiving of the servo drive (differential line driver + end) |
| 4 | RS-232 data receiving | RS-232_RX | For data receiving of the servo drive. Connected to the RS-232 interface of PC. |
| | RS-422 data receiving | RS-422_RX- | For data receiving of the servo drive (differential line driver - end) |
| 5 | RS-422 data transmission | RS-422-TX+ | For data transmission of the servo drive (differential line driver + end) |
| 6 | RS-422 data transmission | RS-422-TX- | For data transmission of the servo drive (differential line driver - end) |

NOTE:


- 1) For the connection of RS-485, please refer to pages 8.2 and 8.3.
- 2) There are two kinds of IEEE1394 communication cables available on the market. If the user uses one kind of cable, which its GND terminal (Pin 1) and its shielding is short-circuited, the communication may be damaged. Never connect the case of the terminal to the ground of this kind of communication cable.

3.5.2 Connection between PC and Connector CN3



3.6 Standard Connection Example


3.6.1 Position (Pt) Control Mode



Note:

- *1: Please refer to C4 wiring diagram on page 3-28. If it is open-collector input, please refer to C3 wiring diagram on page 3-27.
- *2: These terminals are for Lexium 23M series only. In Lexium 23C series, they are marked NC (No Connection) and must be left unconnected.
- *3: CN2 encoder terminals for Lexium 23M series only.
- *4: Please refer to parameter P1-46 in Chapter 7.

3.6.2 Position (Pr) Control Mode




Note:

*1: CN2 encoder terminals for Lexium 23M series only.

*2: Please refer to parameter P1-46 in Chapter 7.

3.6.3 Speed Control Mode




Note:

*1: CN2 encoder terminals for Lexium 23M series only.

*2: Please refer to parameter P1-46 in Chapter 7.

3.6.4 Torque Control Mode



Note:

*1: CN2 encoder terminals for Lexium 23M series only.

*2: Please refer to parameter P1-46 in Chapter 7.

Display and Operation



At a Glance

Presentation

This chapter describes the basic operation of the digital keypad and the features it offers.

What's in this Chapter?


This chapter contains the following topics:

| Topic | Page |
|-----------------------------------|------|
| Description of the Digital Keypad | 72 |
| Display Flowchart | 73 |
| Status Display | 74 |
| General Function Operation | 76 |

4.1 Description of the Digital Keypad

The digital keypad includes the display panel and function keys. The Figure 4.1 shows all of the features of the digital keypad and an overview of their functions.


Figure 4.1



| Name | Function |
|---|--|
| LCD Display | The LCD Display (5-digit, 7-step display panel) shows the monitor codes, parameter settings and operation values of the AC servo drive. |
| Charge LED | The Charge LED lights to indicate the power is applied to the circuit. |
|  | Pressing  key can enter or exit different parameter groups, and switch between Monitor mode and Parameter mode. |
|  | Pressing  key can scrolls through parameter groups. After a parameter is selected and its value displayed, pressing  key can move the cursor to the left and then change parameter settings (blinking digits) by using arrow keys. |
|  | Pressing the  and  key can scroll through and change monitor codes, parameter groups and various parameter settings. |
|  | Pressing the  key can display and save the parameter groups, the various parameter settings. During diagnosis operation, pressing  key can execute the function in the last step. (The parameter settings changes are not effective until the  key is pressed.) |

4.2 Display Flowchart

Figure 4.2 Keypad Operation



1. When the power is applied to the AC servo drive, the LCD display will show the monitor function codes for approximately one second, then enter into the monitor mode.
2. In monitor mode, pressing \uparrow or \downarrow key can switch monitor parameter code. At this time, monitor display symbol will display for approximately one second.
3. In monitor mode, pressing $\textcircled{\text{M}}$ key can enter into parameter mode, pressing the $\textcircled{\text{S}}$ key can switch parameter group and pressing \uparrow or \downarrow key can change parameter group code.
4. In parameter mode, the system will enter into the setting mode immediately after the $\textcircled{\text{ENT}}$ key is pressed. The LCD display will display the corresponding setting value of this parameter simultaneously. Then, users can use \uparrow or \downarrow key to change parameter value or press $\textcircled{\text{M}}$ to exit and return back to the parameter mode.
5. In parameter setting mode, the users can move the cursor to left by pressing the $\textcircled{\text{S}}$ key and change the parameter settings (blinking digits) by pressing the \uparrow or \downarrow key.
6. After the setting value change is completed, press $\textcircled{\text{ENT}}$ key to save parameter settings or execute command.
7. When the parameter setting is completed, LCD display will show the end code "-END-" and automatically return back to parameter mode.

4.3 Status Display

4.3.1 Save Setting Display

After the **ENT** key is pressed, LCD display will show the following display messages for approx. one second according to different status.

| Display Message | Description |
|------------------|--|
| - E n d - | The setting value is saved correctly. |
| E r r - r | This parameter is read only. Write-protected. (cannot be changed) |
| E r r - P | Invalid password or no password was input. |
| E r r - C | The setting value is error or invalid. |
| S r u O n | The servo system is running and it is unable to accept this setting value to be changed. |
| Π o - E E | This parameter will not be stored in EEPROM. |
| P a - O n | This parameter is valid after restarting the drive. |

4.3.2 Abort Setting Display

| Display Message | Description |
|------------------|--|
| A b o r t | In parameter mode, pressing M key can abort parameter setting change and return to monitor mode. In parameter setting mode, pressing M key can return back to parameter mode. After returning back to parameter mode, pressing M key again can abort parameter setting change. |

4.3.3 Fault Message Display

| Display Message | Description |
|------------------|--|
| A L E n n | When the AC servo drive has a fault, LCD display will display "ALEnn". "ALE" indicates the alarm and "nn" indicates the drive fault code. The display range of alarm code "nn" is 1 to 22. For the list of drive fault code, please refer to parameter P0-01 or refer to Chapter 10 (Troubleshooting). |

4.3.4 Polarity Setting Display

| Display Message | Description |
|------------------|---|
| 2 4 6 8 | Positive value display. When entering into parameter setting mode, pressing ▲ or ▼ key can increase or decrease the display value. S key is used to change the selected digit (The selected digit will blink). |
| 2.46.8.0 | Negative value display. When the parameter setting is greater than four digits (for the setting value within the range of less than five decimal places), after the display value is set, continuously press S key for many times and then the lit decimal points are used to indicate a negative value. |
| - 2 4 6 8 | Negative value display. When the parameter setting is less than five digits (for the setting value within the range of five decimal places), after the display value is set, continuously press S key for many times and then the negative sign will show up to indicate a negative value. |

4.3.5 Monitor Setting Display

When the AC servo drive is applied to power, the LCD display will show the monitor function codes for approximately one second and then enter into the monitor mode. In monitor mode, in order to change the monitor status, the users can press

▲ or ▼ N arrow key or change parameter PO-02 directly to specify the monitor status. When the power is applied, the monitor status depends on the setting value of PO-02. For example, if the setting value of PO-02 is 2 when the power is applied, the monitor function will be Pulse counts of pulse command, the C.P monitor codes will first display and then the pulse number will display after.

Lexium 23C Series

| PO-02 Setting | Display Message | Description | Unit |
|---------------|--------------------|--|---------|
| 0 | <i>F b . P</i> | Motor feedback pulse number (Absolute value) | [pulse] |
| 1 | <i>F b . r E u</i> | Motor feedback rotation number (Absolute value) | [rev] |
| 2 | <i>C . P</i> | Pulse counts of pulse command | [pulse] |
| 3 | <i>C . r E u</i> | Rotation number of pulse command | [rev] |
| 4 | <i>P E r r</i> | Position error counts | [pulse] |
| 5 | <i>C P . F r</i> | Input frequency of pulse command | [r/min] |
| 6 | <i>S P E E d</i> | Motor rotation speed | [r/min] |
| 7 | <i>C . S P d 1</i> | Speed input command | [V] |
| 8 | <i>C . S P d 2</i> | Speed input command | [r/min] |
| 9 | <i>C . t 9 1</i> | Torque input command | [V] |
| 10 | <i>C . t 9 2</i> | Torque input command | [%] |
| 11 | <i>A v G . L</i> | Average load | [%] |
| 12 | <i>P E . L</i> | Peak load | [%] |
| 13 | <i>U b u S</i> | Main circuit voltage | [V] |
| 14 | <i>J L</i> | Ratio of load inertia to Motor inertia | [times] |
| 15 | <i>P L S .</i> | Motor feedback pulse number (Relative value) / Position latch pulse number | [pulse] |
| 16 | <i>r E u .</i> | Motor feedback rotation number (Relative value) / Position latch rotation number | [rev] |

Lexium 23M Series

| PO-02 Setting | Display Message | Description | Unit |
|---------------|------------------|---|---------|
| 17 | - | Reserved | - |
| 18 | <i>H F b . P</i> | High resolution pulse number | [pulse] |
| 19 | <i>A F b . P</i> | Absolute pulse number (use Z pulse as home) | [pulse] |

The following table lists the display examples of monitor value:


| Display Message | Description |
|-------------------|---|
| <i>1234</i> | Positive value display. No positive sign is displayed to indicate it is a positive value. Display value: +1234. |
| <i>- 1234</i> | Negative value display (The decimal place is greater than four). The lit decimal points are used to indicate it is a negative value. Display value: -12345. |
| <i>1.2.3.4.5.</i> | Negative value display (The decimal place is less than five). The negative sign is displayed to indicate it is a negative value. Display value: -1234. |
| <i>12.34</i> | Decimal value display. Display value: 12.34. |

4.4 General Function Operation

4.4.1 Fault Code Display Operation

After entering the parameter mode P4-00 to P4-04 (Fault Record), press **ENT** key to display the corresponding fault code history for the parameter or press **▲** key to display the fault code of H1 to H5 in order. H1 indicates the most recent occurred fault code, H2 is the previous occurred fault code before H1 and so on. Please refer to the Figure 4.3. The recently occurred error code is 10.

Figure 4.3




4.4.2 JOG Operation

After entering parameter mode P4-05, the users can follow the following steps to perform JOG operation.(Please also refer to Figure 4.4).

- Step1. Press the **ENT** key to display the JOG r/min speed. (The default value is 20 r/min).
- Step2. Press the **▲** or **▼** keys to increase or decrease the desired JOG speed. (This also can be undertaken by using the SHIFT key to move the cursor to the desired unit column (the effected number will blink) then changed using the **▲** or **▼** keys. The example display in Figure 4.4 is adjusted as 100 r/min.)
- Step3. Press the **ENT** key when the desired JOG speed is set. The Servo Drive will display "JOG".
- Step4. Press the **▲** or **▼** keys to jog the motor either CCW or CW. The motor will only rotate while the arrow key is activated.
- Step5. To change JOG speed again, press the **M** key. The servo Drive will display "P4-05". Press the **ENT** key and the JOG r/min speed will displayed again. Refer back to #2 and #3 to change speed.

Figure 4.4



Note: JOG operation is effective only when Servo On (when the servo drive is enabled).


The learning position and internal memorized position are listed as below:

| Learning Position | Internal Memorized Position |
|-------------------|---|
| JOGo1 | P1-15 (1st Position Command for Rotation) P1-16 (1st Position Command for Pulse) |
| JOGo2 | P1-17 (2nd Position Command for Rotation) P1-18 (2nd Position Command for Pulse) |
| JOGo3 | P1-19 (3rd Position Command for Rotation) P1-20 (3rd Position Command for Pulse) |
| JOGo4 | P1-21 (4th Position Command for Rotation) P1-22 (4th Position Command for Pulse) |
| JOGo5 | P1-23 (5th Position Command for Rotation) P1-24 (5th Position Command for Pulse) |
| JOGo6 | P1-25 (6th Position Command for Rotation) P1-26 (6th Position Command for Pulse ber) |
| JOGo7 | P1-27 (7th Position Command for Rotation) P1-28 (7th Position Command for Pulse) |
| JOGo8 | P1-29 (8th Position Command for Rotation) P1-30 (8th Position Command for Pulse) |

4.4.4 Force Output Control Operation

For testing, the digital outputs can be forced to be activated (ON) or inactivated (OFF) by using parameter P4-06. Follow the setting method in Figure 4.6 to enter into Force Output Control operation (OP xx) mode ("xx" indicates the parameter range from 00 to 1F). Pressing ▲ or ▼ key can change "xx" value from 00 to 1F (hexadecimal format) and force digital outputs DO1 to DO5 to be activated (ON) or inactivated (OFF). The DO function and status is determined by P2-18 to P2-22. This function is enabled only when Servo Off (the servo drive is disabled).


Figure 4.6



4.4.5 DI Diagnosis Operation

Following the setting method in Figure 4.7 can perform DI diagnosis operation (parameter P4-07, Input Status or Force Input Control). According to the ON and OFF status of the digital inputs DI1 to DI8, the corresponding status will display on the servo drive LED display. When the segment lit and display on the screen, it means that the corresponding digital input signal is ON. (Please also refer to Figure 4.7)


Figure 4.7



4.4.6 DO Diagnosis Operation

Following the setting method in Figure 4.8 can perform DO diagnosis operation (parameter P4-09, Output Status Display). According to the ON and OFF status of the digital outputs DO1 to DO5, the corresponding status will display on the servo drive LED display. When the segment lit and display on the screen, it means that the corresponding digital input signal is ON. (Please also refer to Figure 4.8)

Figure 4.8



Trial Run and Tuning Procedure

5

At a Glance

Presentation

This chapter, which is divided into two parts, describes trial run for servo drive and motor. One part is to introduce the trial run without load, and the other part is to introduce trial run with load. Ensure to complete the trial run without load first before performing the trial run with load.

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|---------------------------------|------|
| Inspection without Load | 86 |
| Applying Power to the Drive | 88 |
| JOG Trial Run without Load | 92 |
| Speed Trial Run without Load | 94 |
| Position Trial Run without Load | 96 |
| Tuning Procedure | 99 |

5.1 Inspection without Load

In order to prevent accidents and avoid damaging the servo drive and mechanical system, the trial run should be performed under no load condition (no load connected, including disconnecting all couplings and belts). Do not run servo motor while it is connected to load or mechanical system because the unassembled parts on motor shaft may easily disassemble during running and it may damage mechanical system or even result in personnel injury. After removing the load or mechanical system from the servo motor, if the servo motor can run normally following up the normal operation procedure (when trial run without load is completed), then the users can connect to the load and mechanical system to run the servo motor.

Caution

UNINTENDED EQUIPMENT OPERATION

In order to prevent accidents, the initial trial run for servo motor should be conducted under no load conditions (separate the motor from its couplings and belts).

Please perform trial run without load first and then perform trial run with load connected. After the servo motor is running normally and regularly without load, then run servo motor with load connected. Ensure to perform trial run in this order to prevent unnecessary danger.

Failure to follow this instruction will result in death, serious injury, or equipment damage.

After power is connected to AC servo drive, the charge LED will light and it indicates that AC servo drive is ready. Please check the followings before trial run:

| Item | Content |
|---|---|
| Inspection before operation (Control power is not applied) | <ul style="list-style-type: none"> ● Inspect the servo drive and servo motor to insure they were not damaged. ● To avoid an electric shock, be sure to connect the ground terminal of servo drive to the ground terminal of control panel. ● Before making any connection, wait 10 minutes for capacitors to discharge after the power is disconnected, alternatively, use an appropriate discharge device to discharge. ● Ensure that all wiring terminals are correctly insulated. ● Ensure that all wiring is correct or damage and or malfunction may result. ● Visually check to ensure that there are not any unused screws, metal strips, or any conductive or inflammable materials inside the drive. ● Never put inflammable objects on servo drive or close to the external regenerative resistor. ● Make sure control switch is OFF. ● If the electromagnetic brake is being used, ensure that it is correctly wired. ● If required, use an appropriate electrical filter to eliminate noise to the servo drive. ● Ensure that the external applied voltage to the drive is correct and matched to the controller. |
| Inspection during operation (Control power is applied) | <ul style="list-style-type: none"> ● Ensure that the cables are not damaged, stressed excessively or loaded heavily. When the motor is running, pay close attention on the connection of the cables and notice that if they are damaged, frayed or over extended. ● Check for abnormal vibrations and sounds during operation. If the servo motor is vibrating or there are unusual noises while the motor is running, please contact the dealer or manufacturer for assistance. ● Ensure that all user-defined parameters are set correctly. Since the characteristics of various machinery equipment are different, in order to avoid accident or cause damage, do not adjust the parameter abnormally and ensure the parameter setting is not an excessive value. ● Ensure to reset some parameters when the servo drive is off (Please refer to Chapter 7). Otherwise, it may result in malfunction. ● If there is no contact sound or there be any unusual noises when the relay of the servo drive is operating, please contact your distributor for assistance or contact with Schneider electric. ● Check for abnormal conditions of the power indicators and LED display. If there is any abnormal condition of the power indicators and LED display, please contact your distributor for assistance or contact with Schneider electric. |

5.2 Applying Power to the Drive

The users please observe the following steps when applying power supply to the servo drive.

1. Please check and confirm the wiring connection between the drive and motor is correct.
 - 1) Terminal U, V, W and FG (frame ground) must connect to Red, White, Black and Green cables separately (U: Red, V: White, W: Black, FG: Green). If not connect to the specified cable and terminal, then the drive cannot control motor. The motor grounding lead, FG must connect to grounding terminal. For more information of cables, please refer to section 3.1.
 - 2) Ensure to connect encoder cable to CN2 connector correctly. If the users only desire to execute JOG operation, it is not necessary to make any connection to CN1 and CN3 connector. For more information of the connection of CN2 connector, please refer to Section 3.1 and 3.4.

Caution

RISK OF EQUIPMENT DAMAGE

Do not connect the input power (R, S, T) to the (U, V, W) output terminals. This will damage the AC servo drive.

Failure to follow this instruction can result in injury or equipment damage.

2. Main circuit wiring

Connect power to the AC servo. For three-phase input power connection and single-phase input power connection, please refer to Section 3.1.3.


3. Turn the Power On

The Power includes control circuit power (L1, L2) and main circuit power (R, S, T). When the power is on, the normal display should be shown as the following figure:



As the default settings of digital input signal, DI6, DI7 and DI8 are Reverse Inhibit Limit (CWL), Forward Inhibit Limit (CCWL) and Emergency Stop (EMGS) respectively, if the users do not want to use the default settings of DI6-DI8, the users can change their settings by using parameters P2-15 to P2-17 freely. When the setting value of parameters P2-15 to P2-17 is 0, it indicates the function of this DI signal is disabled. For more information of parameters P2-15 to P2-17, please refer to Chapter 7 "Parameters".

If the parameter P0-02 is set as motor speed (06), the normal display should be shown as the following figure:



If there is no text or character displayed on the LED display, please check if the voltage of the control circuit terminal (L1 and L2) is over low.

1) When display shows:

Over voltage:

The main circuit voltage has exceeded its maximum allowable value or input power is error (Incorrect power input).

Corrective Actions:

- Use voltmeter to check whether the input voltage falls within the rated input voltage.
- Use voltmeter to check whether the input voltage is within the specified limit.

2) When display shows:

Encoder error:

Check if the wiring is correct. Check if the encoder wiring (CN2) of servo motor is loose or incorrect.

Corrective Actions:

- Check if the users perform wiring recommended in the user manual.
- Examine the encoder connector and cable.
- Inspect whether wire is loose or not.
- Check if the encoder is damaged.

3) When display shows:


Emergency stop activated:

Please check if any of digital inputs DI1 ~DI8 signal is set to "Emergency Stop" (EMGS).

Corrective Actions:

- If it does not need to use "Emergency Stop (EMGS)" as input signal, the users only need to confirm that if all of the digital inputs DI1 -DI8 are not set to "Emergency Stop (EMGS)". (The setting value of parameter P2-10 to P2-17 is not set to 21.)
- If it is necessary to use "Emergency Stop (EMGS)" as input signal, the users only need to confirm that which of digital inputs DI1 ~DI8 is set to "Emergency Stop (EMGS)" and check if the digital input signal is ON (It should be activated).

4) When display shows:




Reverse limit switch error:

Please check if any of digital inputs DI1 -DI8 signal is set to "Reverse inhibit limit (CWL)" and check if the signal is ON or not.

Corrective Actions:

- If it does not need to use "Reverse inhibit limit (CWL)" as input signal, the users only need to confirm that if all of the digital inputs DI1 -DI8 are not set to "Reverse inhibit limit (CWL)". (The setting value of parameter P2-10 to P2-17 is not set to 22.)
- If it is necessary to use "Reverse inhibit limit (CWL)" as input signal, the users only need to confirm that which of digital inputs DI1 -DI8 is set to "Reverse inhibit limit (CWL)" and check if the digital input signal is ON (It should be activated).

5) When display shows:



Forward limit switch error:

Please check if any of digital inputs DI1 -DI8 signal is set to "Forward inhibit limit (CCWL)" and check if the signal is ON or not.

Corrective Actions:

- If it is no need to use "Forward inhibit limit (CCWL)" as input signal, the users only need to confirm that if all of the digital inputs DI1 -DI8 are not set to "Forward inhibit limit (CCWL)". (The setting value of parameter P2-10 to P2-17 is not set to 23.)
- If it is necessary to use "Forward inhibit limit (CCWL)" as input signal, the users only need to confirm that which of digital inputs DI1 -DI8 is set to "Forward inhibit limit (CCWL)" and check if the digital input signal is ON (It should be activated).

When "Digital Input 1 (DI1)" is set to Servo On (SON), if DI1 is set to ON (it indicates that Servo On (SON) function is enabled) and the following fault message shows on the display:

6) When display shows:

A digital LED display showing the fault code "AL E01".

Overcurrent:

Corrective Actions:

- Check the wiring connections between the servo drive and motor.
- Check if the circuit of the wiring is closed.
- Remove the short-circuited condition and avoid metal conductor being exposed.

7) When display shows:

A digital LED display showing the fault code "AL E03".

Undervoltage:

Corrective Actions:

- Check whether the wiring of main circuit input voltage is normal.
- Use voltmeter to check whether input voltage of main circuit is normal.
- Use voltmeter to check whether the input voltage is within the specified specification.

Note: If there are any unknown fault codes and abnormal display when applying power to the drive or servo on is activated (without giving any command), please inform your distributor or contact with Schneider electric for assistance.

5.3 JOG Trial Run without Load

It is very convenient to use JOG trial run without load to test the servo drive and motor as it can save the wiring. The external wiring is not necessary and the users only need to connect the digital keypad to the servo drive. For safety, it is recommended to set JOG speed at low speed. Please refer to the following steps to perform JOG trial run without load.

STEP 1: Turn the drive ON through software. Ensure that the setting value of parameter P2-30 should be set to 1 (Servo On).

STEP 2: Set parameter P4-05 as JOG speed (unit: r/min). After the desired JOG speed is set, and then press  key, the drive will enter into JOG operation mode automatically.

STEP 3: The users can press  and  key to change JOG speed and press  key to adjust the digit number of the displayed value.

STEP 4: Pressing  key can determine the speed of JOG operation.

STEP 5: Pressing  key and the servo motor will run in CCW direction. After releasing  key, the motor will stop running.

STEP 6: Pressing  key and the servo motor will run in CW direction. After releasing  key, the motor will stop running.


CW and CCW Definition:

CCW (Counterclockwise): when facing the servo motor shaft, CCW is reverse running.

CW (Clockwise): when facing the servo motor shaft, CW is forward running.

STEP 7: When pressing  key, it can exit JOG operation mode.

In the example below, the JOG speed is adjusted from 20r/min (Default setting) to 100r/min.



If the servo motor does not rotate, please check if the wiring of U, V, W terminals and encoder is correct or not.

If the servo motor does not rotate properly, please check if the phase of U, V, W cables is connected correctly.

5.4 Speed Trial Run without Load

Warning

RISK OF UNEXPECTED MOVEMENTS

Before speed trial run, fix and secure the motor as possible to avoid the danger from the reacting force when motor speed changes.

Failure to follow these instructions can result in injuries or equipment damage

STEP 1:

Set the value of parameter P1-01 to 02 and it is speed (S) control mode. After selecting the operation mode as speed (S) control mode, please restart the drive as P1-01 is effective only after the servo drive is restarted (after switching power off and on).

STEP 2:

In speed control mode, the necessary Digital Inputs are listed as follows:

| Digital Input | Parameter Setting Value | Sign | Function Description | CN1 Pin No. |
|---------------|-------------------------|----------|------------------------------|-------------|
| DI1 | P2-10=101 | SON | Servo On | DI1--9 |
| DI2 | P2-11=109 | TRQLM | Torque limit enabled | DI2--10 |
| DI3 | P2-12=114 | SPD0 | Speed command selection | DI3--34 |
| DI4 | P2-13=115 | SPD1 | Speed command selection | DI4--8 |
| DI5 | P2-14=102 | ARST | Reset | DI5--33 |
| DI6 | P2-15=0 | Disabled | This DI function is disabled | - |
| DI7 | P2-16=0 | Disabled | This DI function is disabled | - |
| DI8 | P2-17=0 | Disabled | This DI function is disabled | - |

By default, DI6 is the function of reverse inhibit limit, DI7 is the function of forward inhibit limit and DI8 is the function of emergency stop (DI8), if the users do not set the setting value of parameters P2-15 to P2-17 to 0 (Disabled), the faults (ALE13, 14 and 15) will occur (For the information of fault messages, please refer to Chapter 10). Therefore, if the users do not need to use these three digital inputs, please set the setting value of parameters P2-15 to P2-17 to 0 (Disabled) in advance.

All the digital inputs of Lexium 23 series are user-defined, and the users can set the DI signals freely.

Ensure to refer to the definitions of DI signals before defining them (For the description of DI signals, please refer to Table 7.A in Chapter 7). If any alarm code displays after the setting is completed, the users can restart the drive or set DI5 to be activated to clear the fault. Please refer to section 5.2.

The speed command is selected by SPD0, SPD1. Please refer to the following table:

| Speed Command No. | DI signal of CN1 | | Command Source | Content | Range |
|----------------------|------------------|------|----------------------------|----------------------------------|-------------|
| | SPD1 | SPD0 | | | |
| S1 | 0 | 0 | External analog command | Voltage between V-REF and GND | +/-10V |
| S2 | 0 | 1 | Internal parameter | P1-09 | 0-5000r/min |
| S3 | 1 | 0 | | P1-10 | 0-5000r/min |
| S4 | 1 | 1 | | P1-11 | 0-5000r/min |

0: indicates OFF (Normally Open);

1: indicates ON (Normally Closed)

The settings of speed command:

P1-09 is set to 3000

P1-10 is set to 100

P1-11 is set to -3000

| Input value command | Rotation direction |
|---------------------|--------------------|
| + | CCW |
| - | CW |

STEP 3:

1. The users can use DI1 to enable the servo drive (Servo ON).
2. If DI3 (SPD0) and DI4 (SPD1) are OFF both, it indicates S1 command is selected. At this time, the motor is operating according to external analog command.
3. If only DI3 is ON (SPD0), it indicates S2 command (P1-09 is set to 3000) is selected, and the motor speed is 3000r/min at this time.
4. If only DI4 is ON (SPD1), it indicates S3 command (P1-10 is set to 100) is selected, and the motor speed is 100r/min at this time.
5. If DI3 (SPD0) and DI4 (SPD1) are ON both, it indicates S4 command (P1-11 is set to -3000) is selected, and the motor speed is -3000r/min at this time.
6. Repeat the action of (3), (4), (5) freely.
7. When the users want to stop the speed trial run, use DI1 to disable the servo drive (Servo OFF).

5.5 Position Trial Run without Load

Warning

RISK OF UNEXPECTED MOVEMENTS

Before position trial run, fix and secure the motor as possible to avoid the danger from the reacting force when the motor speed changes.

Failure to follow these instructions can result in Injuries or equipment damage

STEP 1:

Set the value of parameter P1-01 to 01 and it is position (Pr) control mode. After selecting the operation mode as position (Pr) control mode, please restart the drive and the setting would be valid.

STEP 2:

In position control mode, the necessary DI setting is listed as follows:

| Digital Input | Parameter Setting Value | Sign | Function Description | CN1 Pin No. |
|---------------|-------------------------|----------|------------------------------|-------------|
| DI1 | P2-10=101 | SON | Servo On | DI1-=9 |
| DI2 | P2-11=108 | CTRG | Command triggered | DI2-=10 |
| DI3 | P2-12=111 | POS0 | Position command selection | DI3-=34 |
| DI4 | P2-13=112 | POS1 | Position command selection | DI4-=8 |
| DI5 | P2-14=102 | ARST | Reset | DI5-=33 |
| DI6 | P2-15=0 | Disabled | This DI function is disabled | - |
| DI7 | P2-16=0 | Disabled | This DI function is disabled | - |
| DI8 | P2-17=0 | Disabled | This DI function is disabled | - |

By default, DI6 is the function of reverse inhibit limit, DI7 is the function of forward inhibit limit and DI8 is the function of emergency stop (DI8), if the users do not set the setting value of parameters P2-15 to P2-17 to 0 (Disabled), the faults (ALE13, 14 and 15) will occur (For the information of fault messages, please refer to Chapter 10). Therefore, if the users do not need to use these three digital inputs, please set the setting value of parameters P2-15 to P2-17 to 0 (Disabled) in advance.

All the digital inputs of Lexium 23 series are user-defined, and the users can set the DI signals freely.

Ensure to refer to the definitions of DI signals before defining them (For the description of DI signals, please refer to Table 7.A in Chapter 7). If any alarm code displays after the setting is completed, the users can restart the drive or set DI5 to be activated to clear the fault. Please refer to section 5.2.

For the information of wiring diagram, please refer to Section 3.6.2 (Wiring of position (Pr) control mode).

Because POS2 is not the default DI, the users need to change the value of parameter P2-14 to 113.

The position command is selected by POS0 ~ POS2. Please refer to the following table:

| Position Command | POS2 | POS1 | POS0 | CTRG | Parameters | Moving Speed Register | Description |
|---------------------|------|------|------|------|------------|-----------------------|--------------------------|
| Internal Position 1 | 0 | 0 | 0 | ↑ | P1-15 | P2-36(V1) | Rotation No. (+/- 30000) |
| | | | | | P1-16 | | Pulse No. (+/- max cnt) |
| Internal Position 2 | 0 | 0 | 1 | ↑ | P1-17 | P2-37(V2) | Rotation No. (+/- 30000) |
| | | | | | P1-18 | | Pulse No.(+/- max cnt) |
| Internal Position 3 | 0 | 1 | 0 | ↑ | P1-19 | P2-38(V3) | Rotation No.(+/- 30000) |
| | | | | | P1-20 | | Pulse No.(+/- max cnt) |
| Internal Position 4 | 0 | 1 | 1 | ↑ | P1-21 | P2-39(V4) | Rotation No.(+/- 30000) |
| | | | | | P1-22 | | Pulse No.(+/- max cnt) |
| Internal Position 5 | 1 | 0 | 0 | ↑ | P1-23 | P2-40(V5) | Rotation No.(+/- 30000) |
| | | | | | P1-24 | | Pulse No.(+/- max cnt) |
| Internal Position 6 | 1 | 0 | 1 | ↑ | P1-25 | P2-41(V6) | Rotation No.(+/- 30000) |
| | | | | | P1-26 | | Pulse No.(+/- max cnt) |
| Internal Position 7 | 1 | 1 | 0 | ↑ | P1-27 | P2-42(V7) | Rotation No.(+/- 30000) |
| | | | | | P1-28 | | Pulse No.(+/- max cnt) |
| Internal Position 8 | 1 | 1 | 1 | ↑ | P1-29 | P2-43(V8) | Rotation No.(+/- 30000) |
| | | | | | P1-30 | | Pulse No.(+/- max cnt) |

0: indicates OFF (Normally Open);

1: indicates ON (Normally Closed)

The users can set the value of these 8 groups of commands (P1-15 ~ P1-30) freely. The command can be absolute position command (P1-33 =0) or relative position command (P1-33 =1).

For example:

Set P1-33 to 1 (Absolute position command)

(The new setting will be effective after the servo drive is restarted (after switching power off and on))

Set P1-15 to 1 (rotation number)

Set P1-16 to 0 (pulse number)

The command of internal position 1: P1-15 Rotation No. + P1-16 Pulse No.

Set P1-17 to 10 (rotation number)

Set P1-18 to 0 (pulse number)

The command of internal position 2: P1-17 Rotation No. + P1-18 Pulse No.

Set P1-19 to -10 (rotation number)

Set P1-20 to 0 (pulse number)

The command of internal position 3: P1-19 Rotation No. + P1-20 Pulse No.

Set P1-21 to 100 (rotation number)

Set P1-22 to 0 (pulse number)

The command of internal position 4: P1-21 Rotation No. + P1-22 Pulse No.

Set P1-23 to -1000 (rotation number)

Set P1-24 to 0 (pulse number)

The command of internal position 5: P1-23 Rotation No. + P1-24 Pulse No.

Set P1-25 to 0 (rotation number)

Set P1-26 to 100 (pulse number)

The command of internal position 6: P1-25 Rotation No. + P1-26 Pulse No.

Set P1-27 to 0 (rotation number)

Set P1-28 to 1000 (pulse number)

The command of internal position 7: P1-27 Rotation No. + P1-28 Pulse No.

Set P1-29 to -10 (rotation number)

Set P1-30 to 2500 (pulse number)

The command of internal position 8: P1-29 Rotation No. + P1-30 Pulse No.

| Input command | Rotation direction |
|---------------|--------------------|
| + | CCW |
| - | CW |

STEP 3:


1. The users can use DI1 to enable the servo drive (Servo ON).
2. Set DI2 (CTRG) to be ON, it indicates the command of internal position 1 (P1-15 Rotation No. + P1-16 Pulse No.) 1 turn is selected, and the motor has rotated one turn at this time.
3. Set DI3 (POS0) to be ON first and then enable DI2 (CTRG) to be ON, it indicates the command of internal position 2 (P1-17 Rotation No. + P1-18 Pulse No.) 10 turn is selected, and the motor has rotated ten turns.
4. Set DI3 (POS0), DI4 (POS1) and DI5 (POS2) to be ON first and then enable DI2 (CTRG) to be ON, it indicates the command of internal position 8 (P1-29 Rotation No. + P1-30 Pulse No.) 10.25turn is selected, and the motor has rotated 10.25 turns.
5. Repeat the action of (3), (4), (5) freely.
6. When the users want to stop the speed trial run, use DI1 to disable the servo drive (Servo OFF).

5.6 Tuning Procedure


Estimate the ratio of Load Inertia to Servo Motor Inertia (J_{load} / J_{motor}): JOG Mode

| | |
|---|----------------|
| 1. After wiring is completed, when power is connected to the AC servo drive, the right side display will show on the LCD display. | RL E 14 |
| 2. Press (M) key to enter into parameter mode. | P0 - 00 |
| 3. Press (S) key twice to select parameter group. | P2 - 00 |
| 4. Press (▲) key to view each parameter and select parameter P2-17. | P2 - 17 |
| 5. Press (ENT) key to display the parameter value as shown on the right side. | 2 1 |
| 6. Press (S) key twice, and press (▲) key. Then, press (ENT) key to display the parameter value as shown on the right side. | 12 1 |
| 7. Press (▲) key to view each parameter and select parameter P2-30. | P2 - 30 |
| 8. Press (ENT) key to display the parameter value as shown on the right side. | 0 |
| 9. Select parameter value 1. Use (▲) key to cycle through the available settings. | 1 |
| 10. Press (ENT) key to write parameter value to the drive, and the right side display will show on the LCD display. | NO - EE |
| 11. At this time, the servo drive is ON and the right side display will appear next. | 0 |
| 12. Press (▼) key three times to select the ratio of Load Inertia to Servo Motor Inertia (J_{load} / J_{motor}). | JL |
| 13. Display the current ratio of Load Inertia to Servo Motor Inertia (J_{load} / J_{motor}). (5.0 is default setting.) | 5.0 |
| 14. Press (M) key to select parameter mode. | P2 - 30 |
| 15. Press (S) key twice to select parameter group. | P4 - 00 |
| 16. Press (▲) key to select user parameter P4-05. | P4 - 05 |
| 17. Press (ENT) key and JOG speed 20r/min will be displayed. Press (▲) and (▼) key to increase and decrease JOG speed. To press (S) key one time can add one digit number. | 20 ↓ 200 |
| 18. Select desired JOG speed, press (ENT) key and it will show the right side display. | JOG |
| 19. Pressing (▲) key is forward rotation and pressing (▼) key is reverse rotation. | |
| 20. Execute JOG operation in low speed first. After the machine is running smoothly, then execute JOG operation in high speed. | |
| 21. The ratio of Load Inertia to Servo Motor Inertia (J_{load} / J_{motor}) cannot be shown in the display of JOG parameter P4-05 operation. Please press (M) key twice continuously and the users can see the ratio of Load Inertia to Servo Motor Inertia (J_{load} / J_{motor}). Then, execute JOG operation again, press (M) key once and press (ENT) key twice to view the display on the keypad. Check if the value of J_{load} / J_{motor} is adjusted to a fixed value and displayed on the keypad after acceleration and deceleration repeatedly. | |

5.6.1 Tuning Flowchart




5.6.2 Load Inertia Estimation Flowchart



5.6.3 Easy Mode Tuning Flowchart

Set P2-31 to 1 (Easy Mode, for Lexium 23C series only, Lexium 23M series does not support this mode) P2-31 Auto and Easy Mode Selection (Default setting is 4)

Settings:



Lexium 23C series:

This parameter allows the users to set the stiffness setting of easy mode and the responsiveness level of auto-tuning mode. Users can control the stiffness and responsiveness according to application condition. When the setting value is higher, the stiffness and the responsiveness is higher.

A: Stiffness setting of easy mode

B: Responsiveness level of auto-tuning mode

Lexium 23M series:

This parameter allows the users to set the responsiveness level setting of auto-tuning mode. Users can control the responsiveness according to application condition. When the setting value is higher, the responsiveness is higher.

A: No function

B: Responsiveness level of auto-tuning mode

In Easy Mode, the value "A" indicates the stiffness setting. When the setting value is higher, the control stiffness is also higher

Adjust P2-31: Increase the setting value of P2-31. Increase the value "A" to add the control stiffness or reduce the noise.

Adjust P2-25: According to the setting value of P2-31 add and adjust the control stiffness.

Continuously adjust until the satisfactory performance is achieved, and then the tuning is completed.





Table 5.A Stiffness Setting in Easy Mode (P2-31 value "A") and the setting of P2-00, P2-25

| Level (P2-31) | | Load Range (J _{load} / J _{motor}) | Max. Load Corresponding Responsiveness | KPP (P2-00) | NLP (P2-25) | Remark |
|-----------------------------------|---|--|--|----------------|----------------|--|
| Low Responsiveness Level | 1 | 50-100 | 5Hz | 5 | 50 | The setting of P2-00 and P2-25 must be inputted manually |
| | 2 | 30-50 | 8Hz | 8 | 31 | |
| | 3 | 20-30 | 11Hz | 11 | 33 | |
| | 4 | 16-20 | 15Hz | 15 | 16 | |
| Medium Responsiveness Level | 5 | 12-16 | 20Hz | 20 | 12 | The setting of P2-00 and P2-25 must be inputted manually |
| | 6 | 8-12 | 27Hz | 27 | 9 | |
| | 7 | 5-8 | 40Hz | 40 | 6 | |
| | 8 | 2-5 | 60Hz | 60 | 4 | |
| | 9 | 0-2 | 115Hz | 115 | 2 | |
| High Responsiveness Level | A | 0-2 | 127Hz | 127 | 1 | The setting of P2-00 and P2-25 must be inputted manually |
| | B | 2-8 | 103Hz | 103 | 2 | |
| | C | 8-15 | 76Hz | 76 | 3 | |
| | D | 15-25 | 62Hz | 62 | 4 | |
| | E | 25-50 | 45Hz | 45 | 5 | |
| | F | 50-100 | 36Hz | 36 | 6 | |

5.6.4 AutoMode (PI) Tuning Flowchart

Set P2-31 to 2 (AutoMode (PI) [Continuous adjustment])
P2-31 Auto and Easy Mode Selection (Default setting is 4)

Settings:



Lexium 23C series:

This parameter allows the users to set the stiffness setting of easy mode and the responsiveness level of auto-tuning mode. Users can control the stiffness and responsiveness according to application condition. When the setting value is higher, the stiffness and the responsiveness is higher.

A: Stiffness setting of easy mode

B: Responsiveness level of auto-tuning mode

Lexium 23M series:

This parameter allows the users to set the responsiveness level setting of auto-tuning mode. Users can control the responsiveness according to application condition. When the setting value is higher, the responsiveness is higher.

A: No function

B: Responsiveness level of auto-tuning mode

In AutoMode (PI), the value "B" indicates the responsiveness setting. When the setting value is higher, the responsiveness is faster.

Adjust P2-31: Increase the setting value of P2-31. Increase the value "B" to speed the responsiveness or reduce the noise.

Adjust P2-25: According to the setting value of P2-31 speed and adjust the responsiveness.

Continuously adjust until the satisfactory performance is achieved, and then the tuning is completed.




Table 5.B P2-31 Value "B" Setting in AutoMode (PI) and the setting of P2-00, P2-25


| P2-31 value responsiveness level of auto-tuning mode | Speed Loop Responsive | Recommended Setting Value of P2-25 |
|--|-----------------------|------------------------------------|
| 0 | 20Hz | 13 |
| 1 | 30Hz | 9 |
| 2 | 40Hz | 6 |
| 3 | 60Hz | 4 |
| 4 | 85Hz | 3 |
| 5 | 120Hz | 3 |
| 6 | 160Hz | 2 |
| 7 | 200Hz | 1 |
| 8 | 250Hz | 1 |
| 9 and above | 300Hz | 0 |

5.6.5 AutoMode (PDFF) Tuning Flowchart

Set P2-31 to 4 (AutoMode (PDFF) [Continuous adjustment])

P2-31 Auto and Easy Mode Selection (Default setting is 4)

Settings:



Lexium 23C series:

This parameter allows the users to set the stiffness setting of easy mode and the responsiveness level of auto-tuning mode. Users can control the stiffness and responsiveness according to application condition. When the setting value is higher, the stiffness and the responsiveness is higher.

A: Stiffness setting of easy mode

B: Responsiveness level of auto-tuning mode

Lexium 23M series:

This parameter allows the users to set the responsiveness level setting of auto-tuning mode. Users can control the responsiveness according to application condition. When the setting value is higher, the responsiveness is higher.

A: No function

B: Responsiveness level of auto-tuning mode

In AutoMode (PDFF), the value "B" indicates the responsiveness setting. When the setting value is higher, the responsiveness is faster.

Adjust P2-31: Increase the setting value of P2-31. Increase the value "B" to speed the responsiveness or reduce the noise.

Continuously adjust until the satisfactory performance is achieved, and then the tuning is completed.




Table 5.C P2-31 Value "B" Setting in AutoMode (PDFF) and the Speed Loop Responsiveness.

| P2-31 value responsiveness level of auto-tuning mode | Speed Loop Responsiveness | P2-31 value responsiveness level of auto-tuning mode | Speed Loop Responsiveness |
|--|---------------------------|--|---------------------------|
| 0 | 20Hz | 8 | 120Hz |
| 1 | 30Hz | 9 | 140Hz |
| 2 | 40Hz | A | 160Hz |
| 3 | 50Hz | B | 180Hz |
| 4 | 60Hz | C | 200Hz |
| 5 | 70Hz | D | 220Hz |
| 6 | 80Hz | E | 260Hz |
| 7 | 100Hz | F | 300Hz |

5.6.6 Limit of Load Inertia Estimation

The accel. / decel. time for reaching 2000r/min must be below 1 second. The rotation speed must be above 200r/min. The load inertia must be 100 multiple or less of motor inertia. The change of external force and the inertia ratio can not be too much. In AutoMode (P2-32 is set to 3 or 5), it will stop estimating the load inertia. The measured load inertia value will not be saved when the power is cut off. When re-apply the power to the drive every time, the setting value of P1-37 is equal to the initial value of load inertia value. But, the measured inertia value will be memorized in P1-37 automatically when:

- (1) Switching AutoMode #2 to AutoMode #3
 - (2) Switching AutoMode #4 to AutoMode #5
-

5.6.7 Relationship between Tuning Modes and Parameters

| Tuning Mode | P2-32 | AutoSet Parameter | User-defined Parameter | Gain Value |
|--|------------------------|---|--|----------------------|
| Manual Mode | 0 (Default setting) | None | P2-00 (Proportional Position Loop Gain) P2-04 (Proportional Speed Loop Gain) P2-06 (Speed Integral Compensation) P2-25 (Low-pass Filter Time Constant of Resonance Suppression) | Fixed |
| Easy Mode | 1 | P2-04 P2-06 P2-26 | P2-31 Value A (Level of Stiffness) P2-00 (Proportional Position Loop Gain) P2-25 (Low-pass Filter Time Constant of Resonance Suppression) | Fixed |
| AutoMode (PI) [Continuous] | 2 | P2-00 P2-04 P2-06 | P2-31 Value B (Level of Responsiveness) P2-25 (Low-pass Filter Time Constant of Resonance Suppression) | Continuous Adjusting |
| AutoMode (PI) [Fixed Inertia] (The inertia ratio is determined by P1-37) | 3 | P2-00 P2-04 P2-06 | P1-37 (Ratio of Load Inertia to Servo Motor Inertia [J_{load} / J_{motor}]) P2-31 Value B (Level of Responsiveness) P2-25 (Low-pass Filter Time Constant of Resonance Suppression) | Fixed |
| AutoMode (PDFF) [Continuous] | 4 | P2-00 P2-04 P2-06 P2-25 P2-26 | P2-31 Value B (Level of Responsiveness) | Continuous Adjusting |
| AutoMode (PDFF) [Fixed Inertia] (The inertia ratio is determined by P1-37) | 5 | P2-00 P2-04 P2-06 P2-25 P2-26 | P1-37 (Ratio of Load Inertia to Servo Motor Inertia [J_{load} / J_{motor}]) P2-31 Value B (Level of Responsiveness) | Fixed |

When switching mode #3 to #0, the setting value of P2-00, P2-04 and P2-06 will change to the value that measured in #3 auto-tuning mode.

When switching mode #5 to #0, the setting value of P2-00, P2-04, P2-06, P2-25 and P2-26 will change to the value that measured in #5 auto-tuning mode.

Note: Lexium 23M series does not support Easy mode.

5.6.8 Gain Adjustment in Manual Mode

The position and speed responsiveness selection is depending on and determined by the the control stiffness of machinery and conditions of applications. Generally, high reponsiveness is essential for the high frequency positioning control of mechanical facilities and the applications of high precision process system. However, the higher responsiveness may easily result in the resonance of machinery system. Therefore, for the applications of high responsiveness, the machinery system with control stiffness is needed to avoid the resonance. Especially when adjusting the responsiveness of unfamiliar machinery system, the users can gradually increase the gain setting value to improve responsiveness untill the resonance occurs, and then decrease the gain setting value. The relevant parameters and gain adjusting methods are described as follows:

- KPP, Parameter P2-00 Proportional Position Loop Gain

This parameter is used to determine the responsiveness of position loop (position loop gain). It could be used to increase stiffness, expedite position loop response and reduce position error.

When the setting value of KPP is higher, the response to the position command is quicker, the position error is less and the settling time is also shorter. However, if the setting value is over high, the machinery system may generate vibration or noise, or even overshoot during positioning. The position loop responsiveness is calculated as follows:

$$\text{Position Loop Responsiveness (Hz)} = \frac{KPP}{2\pi}$$

- KVP, Parameter P2-04 Proportional Speed Loop Gain

This parameter is used to determine the responsiveness of speed loop (speed loop gain). It could be used to expedite speed loop response. When the setting value of KVP is higher, the response to the speed command is quicker. However, if the setting value is over high, it may result in the resonance of machinery system. The responsiveness of speed loop must be higher than the 4~6 times of the responsiveness of position loop. If responsiveness of position loop is higher than the responsiveness of speed loop, the machinery system may generate vibration or noise, or even overshoot during positioning. The speed loop responsiveness is calculated as follows:

Lexium 23C Series:

$$\text{Speed Loop Responsiveness } f_v = \left(\frac{KVP}{2\pi} \right) \times \frac{1}{(1+JL/JM)} \text{ Hz}$$

Lexium 23M Series:

$$\text{Speed Loop Responsiveness } f_v = \left(\frac{KVP}{2\pi} \right) \times \left[\frac{(1+P1-37/10)}{(1+JL/JM)} \right] \text{ Hz}$$

JM: Motor Inertia

JL: Load Inertia

P1-37: 0.1 times

When the value of P1-37 (no matter it is the measured load inertia value or the set load inertia value) is equal to the actual load inertia value, the actual speed

$$\text{loop responsiveness will be: } f_v = \frac{KVP}{2\pi} \text{ Hz}$$

- **KVI, Parameter P2-06 Speed Integral Compensation**
If the setting value of KVI is higher, the capability of decreasing the speed control deviation is better. However, if the setting value is over high, it may easily result in the vibration of machinery system. The recommended setting value is as follows:

$$\text{KVI (Parameter P2-06)} \leq 1.5 \times \text{Speed Loop Responsiveness}$$

- **NLP, Parameter P2-25 Low-pass Filter Time Constant of Resonance Suppression**
When the value of (J_load / J_motor) is high, the responsiveness of speed loop may decrease. At this time, the users can increase the setting value of KVP (P2-04) to keep the responsiveness of speed loop. However, when increasing the setting value of KVP (P2-04), it may easily result in the vibration of machinery system. Please use this parameter to suppress or eliminate the noise of resonance. If the setting value of NLP is higher, the capability of improving the noise of resonance is better. However, if the setting value is over high, it may easily lead to the instability of speed loop and overshoot of machinery system. The recommended setting value is as follows:

$$\text{NLP (Parameter P2-25)} \leq \frac{1000}{4 \times \text{Speed Loop Responsiveness (Hz)}}$$

- **DST, Parameter P2-26 External Anti-Interference Gain**
This parameter is used to enhance the anti-interference capability and reduce the occurrence of overshoot. The default setting is 0 (Disabled). It is not recommended to use it in manual mode only when performing a few tuning on the value gotten through P2-32 AutoMode (PDFF) (setting value is 5, mode 5) automatically (The setting value of P2-26 will change to the value that measured in mode 5 (AutoMode (PDFF)) when switching mode 5 ((AutoMode (PDFF)) to mode 0 (Manual mode)).
- **PFG, Parameter P2-02 Position Feed Forward Gain**
This parameter is used to reduce position error and shorten the positioning settling time. However, if the setting value is over high, it may easily lead to the overshoot of machinery system. If the value of electronic gear ratio (1-44 /1-45) is over than 10, the machinery system may also easily generate vibration or noise.

Control Modes of Operation



6

At a Glance

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|----------------------------|------|
| Control Modes of Operation | 114 |
| Position Control Mode | 115 |
| Speed Control Mode | 130 |
| Torque Control Mode | 148 |
| Control Modes Selection | 152 |
| Others | 155 |

6.1 Control Modes of Operation

The Lexium 23 servo drives series can be programmed to provide six single and five dual modes of operation. Their operation and description is listed in the following table.

| Mode | | Code | Description |
|-------------|---------------------------|------|--|
| Single Mode | External Position Control | Pt | Position control for the servo motor is achieved via an external pulse command. |
| | Internal Position Control | Pr | Position control for the servo motor is achieved via by 8 commands stored within the servo controller. Execution of the 8 positions is via Digital Input (DI) signals. |
| | Speed Control | S | Speed control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command. Control of the internal speed parameters is via the Digital Inputs (DI). (A maximum of three speeds can be stored internally). |
| | Internal Speed Control | Sz | Speed control for the servo motor is only achieved via parameters set within the controller. Control of the internal speed parameters is via the Digital Inputs (DI). (A maximum of three speeds can be stored internally). |
| | Torque Control | T | Torque control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command. Control of the internal torque parameters is via the Digital Inputs (DI). (A maximum of three torque levels can be stored internally). |
| | Internal Torque Control | Tz | Torque control for the servo motor is only achieved via parameters set within the controller. Control of the internal torque parameters is via the Digital Inputs (DI). (A maximum of three torque levels can be stored internally). |
| Dual Mode | | Pt-S | Either Pt or S control mode can be selected via the Digital Inputs (DI) |
| | | Pt-T | Either Pt or T control mode can be selected via the Digital Inputs (DI) |
| | | Pr-S | Either Pr or S control mode can be selected via the Digital Inputs (DI) |
| | | Pr-T | Either Pr or T control mode can be selected via the Digital Inputs (DI) |
| | | S-T | Either S or T control mode can be selected via the Digital Inputs (DI) |

The steps of changing mode:

- (1) Switching the servo drive to Servo Off status. Turning SON signal of digit input to be off can complete this action.
 - (2) Using parameter P1-01. (Refer to chapter 7).
 - (3) After the setting is completed, cut the power off and restart the drive again.
- The following sections describe the operation of each control mode, including control structure, command source and loop gain adjustment, etc.

6.2 Position Control Mode

The position control mode (Pt or Pr mode) is usually used for the applications requiring precision positioning, such as industry positioning machine, indexing table etc. Lexium 23 servo drives series servo drives support two kinds of command sources in position control mode. One is an external pulse train (Pt: Position Terminals, External Position Control) and the other is internal parameter (Pr: Position Register, i.e. internal parameters P1-15 to P1-30, Internal Position Control). The external pulse train with direction which can control the rotation angle of servo motor. The max. input frequency for the external pulse command is 500Kpps and it is equal to rotation speed of 3000r/min.

In order to provide a convenient position control function, Lexium 23 servo drive provides eight internal preset parameters for position control. There are two setting methods of internal parameters, one is to set different position command into these eight internal parameters before operation and then use POS0~POS2 of DI signals of CN1 to perform positioning control. The other setting method is to use serial communication to change the setting value of these eight internal parameters.

To make the servo motor and load operate more smoothly, Lexium 23 servo drive also provide complete Position Spine Line (P-curve) profile for position control mode. For the closed-loop positioning, speed control loop is the principal part and the auxiliary parameters are position loop gain and feed forward compensation. The users can also select three kinds of tuning mode (Manual/Auto/Easy modes) to perform gain adjustment.

This Section 6.2 mainly describes the applicability of loop gain adjustment and feed forward compensation.

6.2.1 Command Source of Position (Pt) Control Mode

The command source of P mode is external pulse train input form terminals. There are three types of pulse input and each pulse type is with logic type (positive (+), negative (-)). They all can be set in parameter P1-00. Please refer to the following relevant parameters:

| P1-00▲ | PTT | External Pulse Input Type | Communication Addr.: 0100H |
|--------|-----|---------------------------|----------------------------|
|--------|-----|---------------------------|----------------------------|

Default: 2

Related Section:

Applicable Control Mode: Pt

Section 6.2.1


Unit: N/A

Range: 00 ~ 132 (Lexium 23C series)


00 ~ 1132 (Lexium 23M series)

Settings:

Lexium 23C series:



Lexium 23M series:



- A: Pulse type
 - A=0: AB phase pulse (4x)
 - A=1: CW + CCW pulse
 - A=2: Pulse + Direction
 - Other setting: Reversed
- B: Input pulse filter
 - B=0: 500Kpps
 - B=1: 200Kpps
 - B=2: 150Kpps
 - B=3: 80Kpps

This setting is used to suppress or reduce the chatter caused by the noise, etc. However, if the instant input pulse filter frequency is over high, the frequency that exceeds the setting value will be regarded as noise and filtered.

- C: Logic type

| Pulse Type | 0=Positive Logic | | 1=Negative Logic | |
|-------------------|------------------|---------|------------------|---------|
| | Forward | Reverse | Forward | Reverse |
| AB phase pulse | | | | |
| CW + CCW pulse | | | | |
| Pulse + Direction | | | | |

| Input pulse interface | Max. input pulse frequency |
|-----------------------|----------------------------|
| Line driver | 500Kpps |
| Open collector | 200Kpps |

- D: Source of pulse command

| Setting value | Input pulse interface | Max. input pulse frequency | Remark |
|---------------|----------------------------------|----------------------------|---|
| 0 | Line driver | 500Kpps | CN1 Terminal Identification: PULSE, /PULSE, SIGN, /SIGN |
| | Open collector | 200Kpps | |
| 1 | Line driver for high-speed pulse | 4Mpps | CN1 Terminal Identification: HPULSE, /HPULSE, HSIGN, /HSIGN |

Note: High-speed pulse function (max. input pulse frequency 4Mpps) is for Lexium 23M only.

Position pulse can be input from these terminals, PULSE (41), /PULSE (43) and SIGN (37), /SIGN (36).

It can be an open-collector circuit or line driver circuit. For the detail wiring, please refer to 3.6.1.

6.2.2 Command Source of Position (Pr) Control Mode

The command sources of Pr mode are P1-15, P1-16 to P1-29, P1-30 these eight built-in parameters.

According to parameter P1-33, the users can select: a) Absolute or b) Incremental position control.


Using with external I/O signals (CN1, POS 0 to POS 2 and CTRG) can select one of the eight built-in parameters to be position command. Please refer to the table below:

| Position Command | POS2 | POS1 | POS0 | CTRG | Parameters | Description | Moving Speed Register |
|------------------|------|------|------|------|------------|-----------------------------|-----------------------|
| P1 | 0 | 0 | 0 | ↑ | P1-15 | Rotation number (+/- 30000) | P2-36 (V1) |
| | | | | | P1-16 | Pulses (+/- max cnt) | |
| P2 | 0 | 0 | 1 | ↑ | P1-17 | Rotation number (+/- 30000) | P2-37 (V2) |
| | | | | | P1-18 | Pulses (+/- max cnt) | |
| P3 | 0 | 1 | 0 | ↑ | P1-19 | Rotation number (+/- 30000) | P2-38(V3) |
| | | | | | P1-20 | Pulses (+/- max cnt) | |
| P4 | 0 | 1 | 1 | ↑ | P1-21 | Rotation number (+/- 30000) | P2-39(V4) |
| | | | | | P1-22 | Pulses (+/- max cnt) | |
| P5 | 1 | 0 | 0 | ↑ | P1-23 | Rotation number (+/- 30000) | P2-40(V5) |
| | | | | | P1-24 | Pulses (+/- max cnt) | |
| P6 | 1 | 0 | 1 | ↑ | P1-25 | Rotation number (+/- 30000) | P2-41(V6) |
| | | | | | P1-26 | Pulses (+/- max cnt) | |
| P7 | 1 | 1 | 0 | ↑ | P1-27 | Rotation number (+/- 30000) | P2-42(V7) |
| | | | | | P1-28 | Pulses (+/- max cnt) | |
| P8 | 1 | 1 | 1 | ↑ | P1-29 | Rotation number (+/- 30000) | P2-43(V8) |
| | | | | | P1-30 | Pulses (+/- max cnt) | |

State of POS0~2: 0 indicates the contact is OFF (Normally Open)


1 indicates the contact is ON (Normally Closed)

CTRG↑: the instant time when the contact changes from 0 (open) to 1 (closed). The application of absolute and incremental position control is various and multiple. This kind of position control is equal to a simple sequence control. Users can easily complete the cycle running by using the above table. For example, the position command, P1 is 10 turns and P2 is 20 turns. Give the position command P1 first and then give the position command P2. The difference between absolute and incremental position control is shown as the figure below:




6.2.3 Structure of Position Control Mode

Basic Structure:




In order to pursue the goal of perfection in position control, the pulse signal should be modified through position command processing and the structure is shown as the figure below:

Lexium 23C Series:




Lexium 23M Series:



Using parameter can select Pr mode and Pt mode. Electronic gear ratio can be set in both two modes to set proper position revolution. Lexium 23 series servo drives also provide S-curve and lowpass filter, which are used whenever the motor and load need to be operated more smoothly. As for the information of electronic gear ratio, S-curve and low-pass filter, please refer to the following sections 6.2.4, 6.2.5 and 6.2.6.


Pulse Inhibit Input Function (INHIBIT)


This function is activated via digital inputs (Please refer to parameter P2-10 ~ P2-17 and DI INHP in Table 7.A). When the drive is in position mode, if INHP is activated, the external pulse input command is not valid and the motor will stop.



6.2.4 S-curve Filter for Position Control

The S-curve filter is for the position smoothing of motion command. Using S-curve filter can run the servo motor more smoothly in response to a sudden position command. Since the speed and acceleration curve are both continuous and the time for the servo motor to accelerate is short, using Scurve filter not only can improve the performance when servo motor accelerate or decelerate but also can make motor to operate more smoothly (from mechanical view). When the load is change, the motor usually run not smoothly when starts to run and stop due to the friction and inertia change. At this moment, users can increase Accel/Decel S-curve constant (TSL), Accel time constant (TACC) and Decel time constant (TDEC) to improve the performance. Because the speed and angle acceleration are continuous when position command is changed to pulse signal input, so it is not needed to use Scurve filter.





S-curve characteristics and Time relationship (Deceleration)

Relevant parameters:

| P1-34 | TACC | Acceleration Time | Communication Addr.: 0122H |
|-------|---|-------------------|---|
| | Default: 200 Related Section: Applicable Control Mode: Pr, S Unit: ms Range: 1 ~ 20000 Settings: 1st to 3rd step acceleration time. It is used to determine the acceleration time to accelerate from 0 to its rated motor speed. (When P1-36 is set to 0: Accel/Decel function is disabled, i.e. P1-34, P1-35 is disabled.) | | Related Section: P1-35, P1-36, Section 6.3.3 |
| P1-35 | TDEC | Deceleration Time | Communication Addr.: 0123H |
| | Default: 200 Applicable Control Mode: Pr, S Unit: ms Range: 1 ~ 20000 Settings: 1st to 3rd step deceleration time. It is used to determine the deceleration time to decelerate from its rated motor speed to 0. (When P1-36 is set to 0: Accel/Decel function is disabled, i.e. P1-34, P1-35 is disabled.) | | Related Section: P1-34, P1-36, Section 6.3.3 |

| P1-36 | TSL | Accel /Decel S-curve | Communication Addr.: 0124H |
|-------|-----|----------------------|----------------------------|
|-------|-----|----------------------|----------------------------|

Pr mode Default: 20 (See Note 2)

Other mode Default: 0

Unit: ms

Range: 0 - 10000 (0: Disabled)

Related Section:

P1-34, P1-35,


Section 6.2.4 (Pr mode),

Section 6.3.3 (S mode)

Settings:

This parameter is used to make the motor run more smoothly when startup and windup. Using this parameter can improve the motor running stability.

Speed



TSL: P1-36, Accel /Decel S-curve

TACC: P1-34, Acceleration time

TDEC: P1-35, Deceleration time

Total acceleration time = TACC + TSL

Total deceleration time = TDEC + TSL

Note:

- 1) If the control of the servo motor is achieved via internal parameters, the command curve should be defined by the users. Therefore, when the command source is internal parameter, ensure that the setting value of P1-36 is not set to 0 or the servo motor will not accelerate or decelerate during operation.
- 2) So if users change the control mode to Pr mode and switching power off and on, the servo drive of parameter P1-36 will auto set the value to 20.

6.2.5 Electronic Gear Ratio

Relevant parameters:

| P1-44▲ | GR1 | Electronic Gear Ratio (1st Numerator) (N1) | Communication Addr.: 012CH |
|--------|-----|--|----------------------------|
|--------|-----|--|----------------------------|

Default: 1

Applicable Control Mode: Pt, Pr

Unit: pulse

Range: 1 ~ 32767

Settings:

Multiple-step electronic gear numerator setting. Please refer to P2-60-P2-62.

Related Section:

Section 6.2.5

| P1-45▲ | GR2 | Electronic Gear Ratio (Denominator) | Communication Addr.: 012DH |
|--------|-----|-------------------------------------|----------------------------|
|--------|-----|-------------------------------------|----------------------------|

Default: 1

Applicable Control Mode: Pt, Pr


Unit: pulse

Range: 1 ~ 32767

Settings:

Electronic gear denominator setting.


Please set electronic gear ratio when the servo drive is Off. As the wrong setting may cause motor to run chaotically (out of control) and it may lead to personnel injury, therefore, ensure to observe the following rule when setting P1-44, P1-45. The electronic gear ratio setting (Please also see P1-44, P2-60 ~ P2-62):



The electronic gear ratio setting range must be within: $1/50 < N/M < 200$.

The electronic gear function provides easy travel distance ratio change. However, the over high electronic gear ratio will command the motor to move not smoothly. At this time, the users can use lowpass filter parameter to improve this kind of situation. For example, assume that the electronic gear ratio is equal to 1 and the encoder pulse per revolution is 10000ppr, if the electronic gear ratio is changed to 0.5, then the motor will rotate one pulse when the command from external controller is two pulses.

For example, after the proper electronic gear ratio is set, the reference travel distance is 1 $\mu\text{m}/\text{pulse}$, the machinery will become easier to be used.




| | Electronic Gear Ratio | Corresponding travel distance per pulse |
|--|------------------------|--|
| When the electronic gear ratio is not used | $= \frac{1}{1}$ | $= \frac{3 \times 1000}{4 \times 2500} = \frac{3000}{10000} = \mu\text{m}$ |
| When the electronic gear ratio is not used | $= \frac{10000}{3000}$ | $= 1 \mu\text{m}$ |

6.2.6 Low-pass Filter


Relevant parameters:

| P1-08 | PFLT | Smooth Constant of Position Command (Lowpass Filter) | Communication Addr.: 0108H |
|-------|-------------------------------|--|----------------------------|
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: Pt | | Section 6.2.6 |
| | Unit: 10ms | | |
| | Range: 0 ~ 1000 (0: Disabled) | | |



6.2.7 Timing Chart of Position (Pr) Control Mode

In Pr mode, position command source is DI signal from CN1, i.e. selected by POS0~POS2 and CTRG. Please refer to 6-2-2 to see the relationship between DI signals and parameters. The following figure is shown the timing chart of Pr mode:



6.2.8 Position Loop Gain Adjustment

Before performing position control (setting position control block diagram), the users should complete the speed control setting by using Manual mode (parameter P-32) since the position loop contains speed loop. Then, adjust the Proportional Position Loop Gain, KPP (parameter P2-00) and Position Feed Forward Gain, PFG (parameter P2-02). Or use Auto mode to adjust the gain of speed and position control block diagram automatically.

- 1) Proportional Position Loop Gain: To increase this gain can enhance the position loop responsiveness.
- 2) Position Feed Forward Gain: To increase this gain can reduce the position track error during operation.

The position loop responsiveness cannot exceed the speed loop responsiveness, and it is recommended that the speed loop responsiveness should be at least four times faster than the position loop responsiveness. This also means that the setting value of Proportional Speed Loop Gain, KVP should be at least four times faster than Proportional Position Loop Gain, KPP.

The equation is shown as follows:

$$f_p < \frac{f_v}{4}, \quad f_v : \text{Speed Loop Responsiveness (Hz)}, \quad f_p : \text{Position Loop Responsiveness (Hz)}$$

$$KPP = 2 \times \pi \times f_p$$

For example, the desired position loop responsiveness is equal to 20 Hz.

Then, $KPP = 2 \times \pi \times 20 = 125 \text{ rad/s}$.

Relevant parameters:

| P2-00 | KPP | Proportional Position Loop Gain | Communication Addr.: 0200H |
|-------|---|---------------------------------|----------------------------|
| | Default: 35 | | Related Section: |
| | Applicable Control Mode: Pt, Pr | | Section 6.2.8 |
| | Unit: rad/s | | |
| | Range: 0 - 1023 | | |
| | Settings: | | |
| | This parameter is used to set the position loop gain. It can increase stiffness, expedite position loop response and reduce position error. However, if the setting value is over high, it may generate vibration or noise. | | |

| P2-02 | PFG | Position Feed Forward Gain | Communication Addr.: 0202H |
|-------|-----|----------------------------|----------------------------|
|-------|-----|----------------------------|----------------------------|

Default: 5000

Related Section:

Applicable Control Mode: Pt, Pr

Section 6.2.8

Unit: 0.0001


Range: 10 ~ 20000

Settings:

This parameter is used to set the feed forward gain when executing position control command.



When using position smooth command, increase gain can improve position track deviation.

When not using position smooth command, decrease gain can improve the resonance condition of mechanical system. However, if the setting value is over high, it may generate vibration or noise.



When the value of Proportional Position Loop Gain, KPP is too great, the position loop responsiveness will be increased and it will result in small phase margin. If this happens, the rotor of motor will oscillate.

At this time, the users have to decrease the value of KPP until the rotor of motor stop oscillating. When there is an external torque command interrupted, over low KPP value will let the motor cannot overcome the external strength and fail to meet the requirement of reasonable position track error demand. Adjust feed forward gain, PFG (P2-02) to efficiently reduce the dynamic position track error.



6.3 Speed Control Mode

The speed control mode (S or Sz) is usually used on the applications of precision speed control, such as CNC machine, etc. Lexium 23 series servo drives support two kinds of command sources in speed control mode. One is external analog signal and the other is internal parameter. The external analog signal is from external voltage input and it can control the speed of servo motor. There are two usage of internal parameter, one is set different speed command in three speed control parameters before operation and then using SPDO and SPD1 of CN1 DI signal perform switching. The other usage is using serial communication to change the setting value of parameter.

Beside, in order to make the speed command switch more smoothly, Lexium 23 series servo drives also provide complete S-curve profile for speed control mode. For the closed-loop speed control, Lexium 23 series servo drives provide gain adjustment function and an integrated PI or PDFF controller. Besides, three modes of tuning technology (Manual/Auto/Easy) are also provided for the users to select (parameter P2-32).

There are three turning modes for gain adjustment: Manual, Auto and Easy modes.

- Manual Mode: User-defined loop gain adjustment. When using this mode, all auto and auxiliary function will be disabled.
- Auto Mode: Continuous adjustment of loop gains according to measured inertia, with ten levels of system bandwidth. The parameter set by user is default value.
- Easy Mode: Robust for wide range of external load inertia change, with ten levels of system stiffness.

Using easy mode can immediately suppress the interference of external load and mechanical resonance and also stand for the load inertia change.

6.3.1 Command Source of Speed Control Mode

Speed command Sources:

- 1) External analog signal: External analog voltage input, -10V to +10V
- 2) Internal parameter: P1-09 to P1-11


| Speed Command | CN1 DI signal | | Command Source | | Command | Range |
|---------------|---------------|------|--------------------|----|--------------------------|--------------------|
| | SPD1 | SPD0 | | | | |
| S1 | 0 | 0 | Mode | S | Voltage between VREF-GND | +/-10 V |
| | | | | Sz | N/A | Speed command is 0 |
| S2 | 0 | 1 | Internal parameter | | P1-09 | +/- 5000 r/min |
| S3 | 1 | 0 | | | P1-10 | +/- 5000 r/min |
| S4 | 1 | 1 | | | P1-11 | +/- 5000 r/min |

- State of SPD0-1: 0: indicates OFF (Normally Open); 1: indicates ON (Normally Closed)
- When SPD0 and SPD1 are both = 0 (OFF), if the control mode of operation is Sz, then the speed command is 0. Therefore, if the users do not use analog voltage as speed command, the users can choose Sz mode and avoid the zero point drift problem of analog voltage signal. If the speed control mode is S mode, then the command is the analog voltage between V-REF and GND. The setting range of the input voltage is from -10V to +10V and the corresponding motor speed is adjustable (Please see parameter P1-40).
- When at least one of SPD0 and SPD1 is not 0 (OFF), the speed command is internal parameter (P1-09 to P1-11). The command is valid (enabled) after either SPD0 or SPD1 is changed.

The speed command that is described in this section not only can be taken as speed command in speed control mode (S or Sz mode) but also can be the speed limit input command in torque control mode (T or Tz mode).


6.3.2 Structure of Speed Control Mode

Basic Structure:



In the figure above, the speed command processing is used to select the command source of speed control according to chapter 6.3.1, including proportional gain (P1-40) and S-curve filter smoothing strategy of speed control. The speed control block diagram is used to manage the gain parameters of the servo drive and calculate the current input provided to motor instantaneously. The resonance suppression block diagram is used to suppress the resonance of mechanical system.

The function and structure of speed command processing is shown as the figure below:



The command source is selected according to the state of SPD0, SPD1 and parameter P1-01 (S or Sz).

Whenever the command signal needs to be more smoothly, we recommend the users to use S-curve and low-pass filter.


6.3.3 Smoothing Strategy of Speed Control Mode

S-curve Filter

The S-curve filter is a speed smoothing command which provides 3 steps accel / decel S-curve to smooth the speed command change of the motor during acceleration and deceleration. Using S-curve filter can let the servo motor run more smoothly in response to a sudden speed command change.

Since the speed and acceleration curve are both continuous, in order to avoid the mechanical resonance and noise may occur due to a sudden speed command (differentiation of acceleration), using S-curve filter not only can improve the performance when servo motor accelerate or decelerate but also can make the motor run more smoothly. S-curve filter parameters include P1-34 Acceleration Time (TACC), P1-35 Deceleration Time (TDEC) and Accel /Decel S-curve (TSL), and the users can use these three parameters to improve the motor performance during acceleration, deceleration and operation.

Lexium 23 series servo drives also support the time calculation of completing speed command. T (ms) is the operation (running) time. S (r/min) is absolute speed command, i.e. the absolute value (the result) after starting speed subtracts the final speed.



S-curve characteristics and Time relationship


Relevant parameters:

| P1-34 | TACC | Acceleration Time | Communication Addr.: 0122H |
|-------|---|-------------------|-----------------------------|
| | Default: 200 | | Related Section: |
| | Applicable Control Mode: Pr, S | | P1-35, P1-36, Section 6.3.3 |
| | Unit: ms | | |
| | Range: 1 - 20000 | | |
| | Settings: | | |
| | 1st to 3rd step acceleration time. | | |
| | It is used to determine the acceleration time to accelerate from 0 to its rated motor speed. (When P1-36 is set to 0: Accel/Decel function is disabled, i.e. P1-34, P1-35 is disabled.) | | |

| P1-35 | TDEC | Deceleration Time | Communication Addr.: 0123H |
|-------|---|-------------------|-----------------------------|
| | Default: 200 | | Related Section: |
| | Applicable Control Mode: Pr, S | | P1-34, P1-36, Section 6.3.3 |
| | Unit: ms | | |
| | Range: 1 ~ 20000 | | |
| | Settings: | | |
| | 1st to 3rd step deceleration time. | | |
| | It is used to determine the deceleration time to decelerate from its rated motor speed to 0. (When P1-36 is set to 0: Accel/Decel function is disabled, i.e. P1-34, P1-35 is disabled.) | | |

| P1-36 | TSL | Accel /Decel S-curve | Communication Addr.: 0124H |
|-------|---|----------------------|----------------------------|
| | Pr mode Default: 20 (See Note 2) | | Related Section: |
| | Other mode Default: 0 | | P1-34, P1-35, |
| | Unit: ms | | Section 6.2.4 (Pr mode), |
| | Range: 0 ~ 10000 (0: Disabled) | | Section 6.3.3 (S mode) |
| | Settings: | | |
| | This parameter is used to make the motor run more smoothly when startup and windup. | | |
| | Using this parameter can improve the motor running stability. | | |

Speed



TSL: P1-36, Accel /Decel S-curve

TACC: P1-34, Acceleration time

TDEC: P1-35, Deceleration time

Total acceleration time = TACC + TSL


Total deceleration time = TDEC + TSL

Note:

- 1) If the control of the servo motor is achieved via internal parameters, the command curve should be defined by the users. Therefore, when the command source is internal parameter, ensure that the setting value of P1-36 is not set to 0 or the servo motor will not accelerate or decelerate during operation.
- 2) So if users change the control mode to Pr mode and switching power off and on, the servo drive of parameter P1-36 will auto set the value to 20.

Analog Speed Command S-curve Filter

Lexium 23 series servo drives also provide Analog Speed Command S-curve Filter for the smoothing in response to a sudden analog input signal.



The analog speed command S-curve filter is for the smoothing of analog input signal and its function is the same as the S-curve filter. The speed and acceleration curve of analog speed command S-curve filter are both continuous. The above figure shows the curve of analog speed command S-curve filter and the users can see the ramp of speed command is different during acceleration and deceleration. Also, the users can see the difference of input command tracking and can adjust time setting by using parameter P1-34, P1-35, P1-36 to improve the actual motor performance according to actual condition.

Analog Speed Command Low-pass Filter

Analog Speed Command Low-pass Filter is used to eliminate high frequency response and electrical interference from an analog speed command and it is also with smoothing function.

Relevant parameters:

| | | | |
|--------------|-------------|--|-----------------------------------|
| P1-06 | SFLT | Accel / Decel Smooth Constant of Analog Speed Command (Low-pass Filter) | Communication Addr.: 0106H |
|--------------|-------------|--|-----------------------------------|

Default: 0

Applicable Control Mode: S


Unit: ms

Range: 0 - 1000 (0: Disabled)

Related Section:


Section 6.3.3

Note: If the setting value of parameter P1-06 is set to 0, it indicates the function of this parameter is disabled and the command is just By-Pass.



6.3.4 Analog Speed Input Scaling


The analog voltage between V_REF and GND determines the motor speed command. Using with parameter P1-40 (Max. Analog Speed Command) can adjust the speed control ramp and its range.



Relevant parameters:

| P1-40▲ | VCM | Max. Analog Speed Command or Limit | Communication Addr.: 0128H |
|--------|--|------------------------------------|----------------------------|
| | Default: rated speed | | Related Section: |
| | Applicable Control Mode: S/T | | Section 6.3.4, P1-55 |
| | Unit: r/min | | |
| | Range: 0 - 10000 | | |
| | Settings: | | |
| | In Speed mode, this parameter is used to set the speed at the maximum input voltage (10V) of the analog speed command. | | |
| | In Torque mode, this parameter is used to set the speed at the maximum input voltage (10V) of the analog speed limit. | | |
| | For example, in speed mode, if P1-40 is set to 3000 and the input voltage is 10V, it indicates that the speed command is 3000 r/min. If P1-40 is set to 3000, but the input voltage is changed to 5V, then the speed command is changed to 1500 r/min. | | |
| | $\text{Speed command / limit} = \text{Input voltage} \times \text{setting} / 10$ | | |

6.3.5 Timing Chart of Speed Control Mode




Note:

- 1) OFF indicates normally open and ON indicates normally closed.
- 2) When speed control mode is S_z , the speed command $S1=0$; when speed control mode is S , the speed command $S1$ is external analog voltage input (Please refer to P1-01).
- 3) After Servo ON, the users can select command according to the state of SPD0~1.

6.3.6 Speed Loop Gain Adjustment

The function and structure of speed control mode is shown as the figure below:

Lexium 23C Series:



5: AutoMode (PDFF) [Fix the ratio of Load Inertia to servo motor inertia and response level can be adjusted]

PI : Proportional - Integral control

PDFF : Pseudo-Derivative Feedback and Feedforward

Explanation of Auto-tuning:

1. When switching mode #2 or #4 to #3 or #5, the system will save the measured load inertia value automatically and memorized in P1-37. Then, set the corresponding parameters according to this measured load inertia value.
2. When switching mode #2 or #4 to #0, it indicates all automatically measured load inertia value will be aborted, and all setting of parameters will be returned to original setting value in #0 manual mode.
3. When switching mode #0 to #3 or #5, enter the appropriate load inertia value in P1-37.
4. When switching mode #3 to #0, the setting value of P2-00, P2-04 and P2-06 will change to the value that measured in #3 auto-tuning mode.
5. When switching mode #5 to #0, the setting value of P2-00, P2-04, P2-06, P2-25 and P2-26 will change to the value that measured in #5 auto-tuning mode

Manual Mode

When Tuning Mode Settings of P2-32 is set to 0, the users can define the proportional speed loop gain (P2-04), speed integral gain (P2-06) feed forward gain (P2-07) and ratio of load inertia to servo motor Inertia (1-37). Please refer to the following description:

- Proportional gain: Adjust this gain can increase the position loop responsiveness.
- Integral gain: Adjust this gain can enhance the low-frequency stiffness of speed loop and eliminate the steady error. Also, reduce the value of phase margin. Over high integral gain will result in the unstable servo system.
- Feed forward gain: Adjust this gain can decrease the phase delay error

Relevant parameters:


| P1-04 | KVP | Proportional Speed Loop Gain | Communication Addr.: 0204H |
|-------|--|------------------------------|----------------------------|
| | Default: 500 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 6.3.6 |
| | Unit: rad/s | | |
| | Range: 0 - 20000 (Lexium 23C series) | | |
| | 0 - 4095 (Lexium 23M series) | | |
| | Settings: | | |
| | This parameter is used to set the speed loop gain. When the value of proportional speed loop gain is increased, it can expedite speed loop response. However, if the setting value is over high, it may generate vibration or noise. | | |

| P2-06 | KVI | Speed Integral Compensation | Communication Addr.: 0206H |
|--|-----|-----------------------------|-----------------------------------|
| Default: 100 Applicable Control Mode: ALL Unit: N/A Range: 0 ~ 4095 (Lexium 23C series) 0 ~ 1023 (Lexium 23M series) | | | Related Section: Section 6.3.6 |
| Settings: This parameter is used to set the integral time of speed loop. When the value of speed integral compensation is increased, it can improve the speed response ability and decrease the speed control deviation. However, if the setting value is over high, it may generate vibration or noise. | | | |
| P2-07 | SFG | Speed Feed Forward Gain | Communication Addr.: 0207H |
| Default: 0 Applicable Control Mode: ALL Unit: 0.0001 Range: 0 ~ 20000 | | | Related Section: Section 6.3.6 |
| Settings: This parameter is used to set the feed forward gain when executing speed control command. When using speed smooth command, increase gain can improve speed track deviation. When not using speed smooth command, decrease gain can improve the resonance condition of mechanical system. | | | |



In theory, stepping response can be used to explain proportional gain (KVP), integral gain (KVI) and feed forward gain (KVF). Now we use frequency area and time area respectively to explain the logic.

Frequency Domain



STEP 1: Set the value of KVI=0, the value of KVF=0 and adjust the value of KVP.




STEP 2: Fix the value of KVP and adjust the value of KVI.




STEP 3: Select the value of KVI, if the value of phase margin is too small, re-adjust the value of KVP again to obtain the value, 45deg of phase margin.




Time Domain



When the value of KVP is greater, the value of the responsiveness is also greater and the raising time is shorter. However, when the value of phase margin is over low, it is not helpful to steady error. But it is helpful to dynamic tracking error.



When the value of KVI is greater, the value of low-frequency gain is also greater and the value of steady error is nearly zero (0). However, the value of phase margin will reduce quite substantially. It is helpful to steady error. But it is not helpful to dynamic tracking error.



When the value of KVF is nearly to 1 and the forward compensation is more complete, then the value of dynamic tracking error will become very small. However, when the value of KVF is too great, it may cause vibration.

In general, the equipment, such as spectrum analyzer is needed and used to analyze when using frequency domain method and the users also should have this kind of analysis technology. However, when using time domain method, the users only need to prepare an oscilloscope. Therefore, the general users usually use time domain method with the analog DI/DO terminal provided by the servo drive to adjust what is called as PI (Proportional and Integral) type controller. As for the performance of torque shaft load, input command tracking and torque shaft load have the same responsiveness when using frequency domain method and time domain method. The users can reduce the responsiveness of input command tracking by using input command low-pass filter.


Easy Mode (for Lexium 23C series only, Lexium 23M series does not support this mode)

When P2-32 is set to 1, the easy mode function is activated. In order to enhance the performance of servo system, Lexium 23C series servo drive provide "Robust Control Technology" when the users select the easy mode of tuning technology. The following introduces the basic structure.

The servo motor with inertia change will operate and be close to ideal reference mode due to the feedback inside of current loop and the torque load will give the compensation immediately inside of the current loop. When the permissible inertia change is greater, it will be much easier to influence the performance of servo system. For the strong functionality and robust control of Lexium 23 servo system, the easy mode provides servo system can be robust for the wide range of external load inertia change, with 16 levels of system stiffness and responsiveness. Users only need to set parameter P2-31 to select 16 levels of system stiffness and responsiveness. The value is higher, the stiffness is more increased and the responsiveness is higher.

Relevant parameters:

| P2-31 | AUT1 | Auto Mode Responsiveness Level | Communication Addr.: 021FH |
|-------|--|--------------------------------|----------------------------|
| | Default: 44 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 5.6, Section 6.3.6 |
| | Unit: N/A | | |
| | Range: 0 - FF (0 ~ FF: 0 indicates the lowest setting and F indicates the highest setting (total 16 settings available)) | | |
| | Settings: | | |



Lexium 23C series:

This parameter allows the users to set the stiffness setting of easy mode and the responsiveness level of auto-tuning mode. Users can control the stiffness and responsiveness according to application condition. When the setting value is higher, the stiffness and the responsiveness is higher.

A: Stiffness setting of easy mode

B: Responsiveness level of auto-tuning mode

Lexium 23M series:

This parameter allows the users to set the responsiveness level setting of auto-tuning mode.

Users can control the responsiveness according to application condition. When the setting value is higher, the responsiveness is higher.

A: No function

B: Responsiveness level of auto-tuning mode

Note:

1) This parameter is activated by P2-32.


2) Please refer to Section 5.6 for the tuning procedure and the related settings.

Stiffness Setting in Easy Mode (P2-31 value "A") and the setting of P2-00, P2-25

| Level (P2-31 Value A) | | Load Range (J_load /J_motor) | Max. Load Corresponding Responsiveness | KPP (P2-00) | NLP (P2-25) | Remark |
|-----------------------------------|---|---------------------------------|--|----------------|----------------|---|
| Low Responsiveness Level | 1 | 50~100 | 5Hz | 5 | 50 | The setting value of P2-00 and P2- 25 must be inputted manually |
| | 2 | 30~50 | 8Hz | 8 | 31 | |
| | 3 | 20~30 | 11Hz | 11 | 33 | |
| | 4 | 16~20 | 15Hz | 15 | 16 | |
| Medium Responsiveness Level | 5 | 12~16 | 20Hz | 20 | 12 | The setting value of P2-00 and P2- 25 must be inputted manually |
| | 6 | 8~12 | 27Hz | 27 | 9 | |
| | 7 | 5~8 | 40Hz | 40 | 6 | |
| | 8 | 2~5 | 60Hz | 60 | 4 | |
| | 9 | 0~2 | 115Hz | 115 | 2 | |
| High Responsiveness Level | A | 0~2 | 127Hz | 127 | 1 | The setting value of P2-00 and P2- 25 must be inputted manually |
| | B | 2~8 | 103Hz | 103 | 2 | |
| | C | 8~15 | 76Hz | 76 | 3 | |
| | D | 15~25 | 62Hz | 62 | 4 | |
| | E | 25~50 | 45Hz | 45 | 5 | |
| | F | 50~100 | 36Hz | 36 | 6 | |

Auto Mode (Continuous adjustment)

This Auto Mode provides continuous adjustment of loop gains according to measured inertia automatically. It is suitable when the load inertia is fixed or the load inertia change is small and is not suitable for wide range of load inertia change. The period of adjustment time is different depending on the acceleration and deceleration of servo motor. To change the stiffness and responsiveness, please use parameter P2-31.




6.3.7 Resonance Suppression

The resonance of mechanical system may occur due to excessive system stiffness or frequency response. However, this kind of resonance condition can be improved, suppressed, even can be eliminated by using low-pass filter (parameter P2-25) and notch filter (parameter P2-23, P2-24) without changing control parameter.


Relevant parameters:

| | | | |
|--------------|--|--|-----------------------------------|
| P2-23 | NCF | Notch Filter (Resonance Suppression) | Communication Addr.: 0217H |
| | Default: 1000 Applicable Control Mode: ALL Unit: Hz Range: 50 ~ 1000 Settings: This parameter is used to set resonance frequency of mechanical system. It can be used to suppress the resonance of mechanical system. If P2-24 is set to 0, this parameter is disabled. | | Related Section: Section 6.3.7 |
| P2-24 | DPH | Notch Filter Attenuation Rate (Resonance Suppression) | Communication Addr.: 0218H |
| | Default: 0 Applicable Control Mode: ALL Unit: dB Range: 0 ~ 32 Settings: 0: Disabled | | Related Section: Section 6.3.7 |
| P2-25 | NLP | Low-pass Filter Time Constant (Resonance Suppression) | Communication Addr.: 0219H |
| | Default: 2 (1kW and below models) or 5 (above 1kW models) Applicable Control Mode: ALL Unit: ms Range: 0 ~ 1000 Settings: 0: Disabled This parameter is used to set low-pass filter time constant of resonance suppression. | | Related Section: Section 6.3.7 |




Low-pass filter

Please use parameter P2-25. The figure below shows the resonant open-loop gain.



When the low-pass filter (parameter P2-25) is adjusted from 0 to high value, the value of Low-pass frequency (BW) will become smaller (see the figure below). The resonant condition is improved and the frequency response and phase margin will also decrease.




Notch Filter


Usually, if the users know the resonance frequency, we recommend the users can eliminate the resonance conditions directly by using notch filter (parameter P2-23, P2-24). However, the range of frequency setting is from 50 to 1000Hz only and the range of resonant attenuation is 0-32 dB only.

Therefore, if the resonant frequency is out of this range, we recommend the users to use low-pass filter (parameter P2-25) to improve resonant condition. Please refer to the following figures and explanation to know how to use notch filter and low-pass filter to improve resonant condition.

Use Notch Filter to suppress resonance



Use Low-pass Filter to suppress resonance



When the low-pass filter (parameter P2-25) is adjusted from 0 to high value, the value of Low-pass frequency will become smaller (see the figure on page 6-26). The resonant condition is improved but the frequency response and phase margin will also decrease and the system may become unstable.

Therefore, if the users know the resonance frequency, the users can eliminate the resonance conditions directly by using notch filter (parameter P2-23, P2-24). Usually, if the resonant frequency can be recognized, we recommend the users can directly use notch filter (parameter P2-23, P2-24) to eliminate the resonance. However, if the resonant frequency will drift or drift out of the notch filter range, we recommend the users not to use notch filter and use low-pass filter to improve resonant conditions.

6.4 Torque Control Mode

The torque control mode (T or Tz) is usually used on the applications of torque control, such as printing machine, spinning machine, twister, etc. Lexium 23 series servo drives support two kinds of command sources in torque control mode. One is external analog signal and the other is internal parameter. The external analog signal is from external voltage input and it can control the torque of servo motor. The internal parameters are from P1-12 to P1-14 which are used to be the torque command in torque control mode.

6.4.1 Command Source of Torque Control Mode

Torque command Sources:

- 1) External analog signal: External analog voltage input, -10V to +10V
- 2) Internal parameter: P1-12 to P1-14


The command source selection is determined by the DI signal of CN1 connector.

| Torque Command | DI signal of CN1 | | Command Source | | Content | Range | |
|----------------|------------------|------|--------------------|----|------------------------|---------------------------|---------|
| | TCM1 | TCM0 | | | | | |
| T1 | 0 | 0 | Mode | T | External analog signal | Voltage between T-REF-GND | +/-10 V |
| | | | | Tz | None | Torque command is 0 | 0 |
| T2 | 0 | 1 | Internal parameter | | P1-12 | +/-300 % | |
| T3 | 1 | 0 | | | P1-13 | +/-300 % | |
| T4 | 1 | 1 | | | P1-14 | +/-300 % | |

- State of TCM0~1: 0: indicates OFF (Normally Open); 1: indicates ON (Normally Closed)
- When TCM0 and TCM1 are both 0 (OFF), if the control mode of operation is Tz, then the command is 0. Therefore, if the users do not use analog voltage as torque command, the users can choose Tz mode to operation torque control to avoid the zero point drift problem of analog voltage. If the control mode of operation is T, then the command is the analog voltage between T-REF and GND. The setting range of the input voltage is from -10V to +10V and the corresponding torque is adjustable (see parameter P1-41).
- When at least one of TCM0 and TCM1 is not 0 (OFF), the torque command is internal parameter. The command is valid (enabled) after either TCM0 or TCM1 is changed.
The torque command that is described in this section not only can be taken as torque command in torque control mode (T or Tz mode) but also can be the torque limit input command in position mode (P mode) and speed control mode (S or Sz mode).


6.4.2 Structure of Torque Control Mode

Basic Structure:



The torque command processing is used to select the command source of torque control according to chapter 6.4.1, including max. analog torque command (parameter P1-41) and smoothing strategy of torque control mode. The current control block diagram is used to manage the gain parameters of the servo drive and calculate the current input provided to motor instantaneously. As the current control block diagram is too complicated, setting the parameters of current control block diagram is not allowed.

The function and structure of torque command processing is shown as the figure below:




The command source is selected according to the state of TCM0, TCM1 and parameter P1-01 (T or Tz).

Whenever the command signal needs to be more smoothly, we recommend the users to use proportional gain (scalar) and low-pass filter to adjust torque.

6.4.3 Smoothing Strategy of Torque Control Mode


Relevant parameters:

| P1-07 | TFLT | Smooth Constant of Analog Torque Command (Low-pass Filter) | Communication Addr.: 0107H |
|-------|--|--|----------------------------|
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: T | | Section 6.4.3 |
| | Unit: ms | | |
| | Range: 0 ~ 1000 (0: Disabled) | | |
| | Note: If the setting value of parameter P1-07 is set to 0, it indicates the function of this parameter is disabled and the command is just By-Pass. | | |



6.4.4 Analog Torque Input Scaling

The analog voltage between T_REF and GND controls the motor torque command. Using with parameter P1-41 can adjust the torque control ramp and its range.



Relevant parameters:

| | | | |
|---------------|------------|--|-----------------------------------|
| P1-41▲ | TCM | Max. Analog Torque Command or Limit | Communication Addr.: 0129H |
|---------------|------------|--|-----------------------------------|

Default: 100

Related Section:

Applicable Control Mode: ALL

Section 6.4.4

Unit: %

Range: 0 ~ 1000

Settings:


In Torque mode, this parameter is used to set the output torque at maximum input voltage (10V) of analog torque command.

In Position and Speed mode, this parameter is used to set output torque at maximum input voltage (10V) of analog torque limit

For example, in torque mode, if P1-41 is set to 100 and the input voltage is 10V, it indicates that the torque command is 100% rated torque. If P1-41 is set to 100, but the input voltage is changed to 5V, then the torque command is changed to 50% rated torque.

$\text{Torque command / limit} = \text{Input voltage} \times \text{setting} / 10 (\%)$

6.4.5 Timing Chart of Torque Control Mode



Note:

- 1) OFF indicates normally open and ON indicates normally closed.
- 2) When torque control mode is Tz, the torque command T1=0; when torque control mode is T, the speed command T1 is external analog voltage input (Please refer to P1-01).
- 3) After Servo ON, the users can select command according to the state of TCM0~1.

6.5 Control Modes Selection

Except signal control mode operation, Lexium 23 series servo drives also provide Pt-S, Pr-S, ST, Pt-T, Pr-T these five multiple modes for the users to select.

- 1) Speed / Position mode selection: Pt-S, Pr-S
- 2) Speed / Torque mode selection: S-T
- 3) Torque / Position mode selection: Pt-T, Pr-T

| Mode | Name | Code | Description |
|-----------|------|------|---|
| Dual Mode | Pt-S | 06 | Either Pt or S control mode can be selected via the Digital Inputs (DI) |
| | Pt-T | 07 | Either Pt or T control mode can be selected via the Digital Inputs (DI) |
| | Pr-S | 08 | Either Pr or S control mode can be selected via the Digital Inputs (DI) |
| | Pr-T | 09 | Either Pr or T control mode can be selected via the Digital Inputs (DI) |
| | S-T | 10 | Either S or T control mode can be selected via the Digital Inputs (DI) |

Sz and Tz mode selection is not provided. In order to avoid using too much DI inputs, we recommend that the users can use external analog signal as input command in speed and torque mode to reduce the use of DI inputs (SPD0~1 or TCM0~1). In position mode, we recommend that the users can use Pt mode to input pulse to reduce the use of DI inputs (POS0~2).

Please refer to table 3.B and table 3.C in section 3.3.2 to see the default pin number of DI/DO signal.

6.5.1 Speed / Position Control Mode Selection

Pt-S Mode / Pr-S Mode:

The command source of Pt-S mode is from external input pulse. The command source of Pr-S mode is from internal parameters (P1-15 to P1-30). The speed command can be the external analog voltage or internal parameters (P1-09 to P1-11). The speed and position mode switching is controlled by the S-P signal. The selection will be more complicated when the position of Pr-S mode and speed command are both selected through DI signal.

The timing chart of speed / position control mode selection is shown as the figure below:




Figure 1. : Speed / Position Control Mode Selection

In speed mode (when S-P is ON), speed command is selected by SPD0-1 and CTRG is disabled at this time. When switching to the position mode (when S-P is OFF), the position command is not determined (it needs to wait that CTRG is on the rising edge), so the motor stop running. Once CTRG is on the rising edge, position command will be selected according to POS0-2 and the motor will immediately move to the determined position. After S-P is ON, it will immediately return to speed mode.

For the relationship between DI signal and selected command in each mode, please refer to the introduction of single mode.

6.5.2 Speed / Torque Control Mode Selection

S-T Mode:

The speed command can be the external analog voltage or internal parameters (P1-09 to P1-11) and SPD0-1 is used to select speed command. The same as speed command, the torque command can be the external analog voltage or internal parameters (P1-12 to P1-14) and TCM0-1 is used to select torque command. The speed and torque mode switching is controlled by the S-T signal. The timing chart of speed / torque control mode selection is shown as the figure below:




Figure 2. : Speed / Torque Control Mode Selection

In torque mode (when S-T is ON), torque command is selected by TCM0-1. When switching to the speed mode (when S-T is OFF), the speed command is selected by SPD0-1, and then the motor will immediately rotate following the command. After S-T is ON again, it will immediately return to torque mode.

6.5.3 Torque / Position Control Mode Selection

Pt-T Mode / Pr-T Mode:

The command source of Pt-T mode is from external input pulse. The command source of Pr-T mode is from internal parameters (P1-15 to P1-30). The torque command can be the external input pulse or internal parameters (P1-12 to P1-14). The torque and position mode switching is controlled by T-P signal. The selection will be more complicated when the position of Pr-T mode and torque command are both selected through DI signal.

The timing chart of speed / position control mode selection is shown as the figure below:




Figure 3. : Torque / Position Control Mode Selection


In position mode (when T-P is ON), the motor will start to count pulse and operate following the external pulse command. When switching to the torque mode (when T-P is OFF), it will stop counting pulse even if the pulse command is continuously sent out. The torque command is determined by TCMO-1 and the motor will rotate following the command. After T-P is ON again, it will immediately return to position mode.

For the relationship between DI signal and selected command in each mode, please refer to the introduction of single mode.

6.6 Others


6.6.1 Speed Limit

The max. servo motor speed can be limited by using parameter P1-55 no matter in position, speed or torque control mode. The command source of speed limit command is the same as speed command. It can be the external analog voltage but also can be internal parameters (P1-09 to P1-11). For more information of speed command source, please refer to chapter 6.3.1. The speed limit only can be used in torque mode (T mode) to limit the servo motor speed. When the torque command is the external analog voltage, there should be surplus DI signal that can be treated as SPD0~1 and be used to select speed limit command (internal parameter). If there is not enough DI signal, the external voltage input can be used as speed limit command. When the Disable / Enable Speed Limit Function Settings in parameter P1-02 is set to 1, the speed limit function is activated. The timing chart of speed limit is shown as the figure below:



6.6.2 Torque Limit

The command source of torque limit command is the same as torque command. It can be the external analog voltage but also can be internal parameters (P1-12 to P1-14). For more information of torque command source, please refer to chapter 6.4.1. The torque limit only can be used in position mode (Pt and Pr mode) and speed mode (S mode) to limit the output torque of servo motor. When the position command is the external pulse and speed command is the external analog voltage, there should be surplus DI signal that can be treated as TCM0~1 used to select torque limit command (internal parameter). If there is not enough DI signal, the external voltage input can be used as torque limit command. When the Disable / Enable Torque Limit Function Settings in parameter P1-02 is set to 1, the torque limit function is activated. The timing chart of torque limit is shown as the figure below:



6.6.3 Regenerative Resistor

● Built-in Regenerative Resistor

When the output torque of servo motor in reverse direction of motor rotation speed, it indicates that there is a regenerative power returned from the load to the servo drive. This power will be transmitted into the capacitance of DC Bus and result in rising voltage. When the voltage has risen to some high voltage, the servo system need to dissipate the extra energy by using a regenerative resistor. Lexium 23 series servo drives provide a built-in regenerative resistor and the users also can connect to external regenerative resistor if more regenerative capacity is needed. The following table shows the specifications of the servo drive 扭 built-in regenerative resistor and the amount of regenerative power (average value) that it can process.

| Built-in Regenerative Resistor Specifications | | | | |
|---|------------------------------------|-----------------------------------|--|---------------------------------|
| Servo Drive (kW) | Resistance (Ohm) (parameter P1-52) | Capacity (Watt) (parameter P1-53) | Regenerative Power processed by built-in regenerative resistor (Watt) *1 | Min. Allowable Resistance (Ohm) |
| 0.1 | 40 | 60 | 30 | 40 |
| 0.2 | 40 | 60 | 30 | 40 |
| 0.4 | 40 | 60 | 30 | 20 |
| 0.75 | 40 | 60 | 30 | 20 |
| 1.0 | 40 | 60 | 30 | 20 |
| 1.5 | 40 | 60 | 30 | 20 |
| 2.0 | 20 | 120 | 60 | 10 |
| 3.0 | 20 | 120 | 60 | 10 |
| 4.5 | 20 | 100 | 60 | 10 |

When the regenerative power exceeds the processing capacity of the servo drive, install an external regenerative resistor. Please pay close attention on the following notes when using a regenerative resistor.

1. Make sure that the settings of resistance (parameter P1-52) and capacity (parameter P1-53) is set correctly.
2. When the users want to install an external regenerative resistor, ensure that its resistance value is the same as the resistance of built-in regenerative resistor. If combining multiple small-capacity regenerative resistors in parallel to increase the regenerative resistor capacity, make sure that the resistance value of the regenerative resistor should comply with the specifications listed in the above table.
3. In general, when the amount of regenerative power (average value) that can be processed is used at or below the rated load ratio, the resistance temperature will increase to 120 °C or higher (on condition that when the regeneration continuously occurred). For safety reasons, forced air cooling is good way that can be used to reduce the temperature of the regenerative resistors. We also recommend the users to use the regenerative resistors with thermal switches. As for the load characteristics of the regenerative resistors, please check with the manufacturer.

● External Regenerative Resistor

When using external regenerative resistor, connect it to PA/+ and PBe, and make sure the circuit between PA/+ and PBi is open. We recommend the users should use the external regenerative resistor that the resistance value following the above table (Built-in Regenerative Resistor Specifications). We ignore the dissipative power of IGBT (Insulated Gate Bipolar Transistor) in order to let the users easily calculate the capacity of regenerative resistor. In the following sections, we will describe Regenerative Power Calculation Method and Simple Calculation Method for calculating the regenerative power capacity of external regenerative resistors.

● Regenerative Power Calculation Method

(1) Without Load

When there is no external load torque, if the servo motor repeats operation, the returned regenerative power generated when braking will be transmitted into the capacitance of DC bus. After the capacitance voltage exceeds some high value, regenerative resistor can dissipate the remained regenerative power.

Use the table and procedure described below to calculate the regenerative power.

Lexium 23C Series

| Servo Drive (kW) | | Rotor Inertia J (kg. m ²) | Regenerative power from empty load 3000r/min to stop Eo (joule) | Max. regenerative power of capacitance Ec (joule) |
|------------------|------|---------------------------------------|---|---|
| Low Inertia | 0.1 | 0.03E-4 | 0.15 | 3 |
| | 0.2 | 0.18E-4 | 0.89 | 4 |
| | 0.4 | 0.34E-4 | 1.68 | 8 |
| | 0.75 | 1.08E-4 | 5.34 | 14 |
| | 1.0 | 2.60E-4 | 12.86 | 18 |
| | 1.5 | 3.60E-4 | 17.80 | 18 |
| | 2.0 | 4.70E-4 | 23.24 | 21 |
| Medium Inertia | 3.0 | 11.6E-4 | 57.36 | 28 |
| | 1.0 | 5.98E-4 | 29.57 | 18 |
| | 1.5 | 8.79E-4 | 43.47 | 18 |
| | 2.0 | 15.8E-4 | 78.13 | 21 |
| | 3.0 | 43.3E-4 | 214.1 | 28 |

Lexium 23M Series

| Servo Drive (kW) | | Rotor Inertia J (kg. m ²) | Regenerative power from empty load 3000r/min to stop Eo (joule) | Max. regenerative power of capacitance Ec (joule) |
|------------------|-----|---------------------------------------|---|---|
| 4.5 | 3 | 54.95 | 217.73 | 28 |
| | 3.5 | 54.80 | 270.98 | 28 |
| | 4.5 | 77.75 | 384.47 | 28 |

$$E_o = J \times \omega_r^2 / 182 \text{ (joule)}, \quad \omega_r : \text{r/min}$$

If the load inertia is $N \times$ motor inertia, the regenerative power will be $(N+1) \times E_0$ when servo motor brakes from 3000r/min to 0. Then, the regenerative resistor can dissipate: $(N+1) \times E_0 - E_c$ (joule). If the time of repeat operation cycle is T sec, then the regenerative power = $2 \times ((N+1) \times E_0 - E_c) / T$. The calculating procedure is as follows:

| Step | Procedure | Equation and Setting Method |
|------|--|--|
| 1 | Set the capacity of regenerative resistor to the maximum | Change the value of P1-53 to maximum |
| 2 | Set the operation cycle T | Input by the users |
| 3 | Set motor speed wr | Input by the users or read via P0-02 Drive State Display |
| 4 | Set load/motor inertia ratio N | Input by the users or read via P0-02 Drive State Display |
| 5 | Calculate the max. regenerative power E_0 | $E_0 = J \times wr^2 / 182$ |
| 6 | Set the regenerative power E_c that can be absorbed | Refer to the table above |
| 7 | Calculate the required regenerative power capacity | $2 \times (N+1) \times E_0 - E_c / T$ |

For example:


If we use 400W servo drive, the time of repeat operation cycle is $T = 0.4$ sec, max. motor speed is 3000r/min, the load inertia = $7 \times$ motor inertia, then the necessary the power of regenerative resistor = $2 \times ((7+1) \times 1.68 - 8) / 0.4 = 27.2W$. If the calculation result is smaller than regenerative power, we recommend the users to use the built-in 60W regenerative resistor. Usually the built-in regenerative resistor provided by Lexium 23 series servo drives can meet the requirement of general application when the external load inertia is not excessive.

The users can see when the capacity of regenerative resistor is too small, the accumulated power will be larger and the temperature will also increase. The fault, ALE05 may occur if the temperature is over high. The following figure shows the actual operation of regenerative resistor.

(2) With Load

When there is an external load torque, servo motor is in reverse rotation when external load greater than motor torque. Servo motor is usually in forward rotation and the motor torque output direction is the same as the rotation direction. However, there is still some special condition. If the motor output torque is in the reverse direction of rotation, the servo motor is also in the reverse direction of rotation. The external power is input into the servo drive through servo motor. The Figure 6.21 below is an example.

The users can see the motor is in forward rotation at constant speed when a sudden external load torque change and great power is transmitted to regenerative resistor rapidly.



External load torque in reverse direction: $T_L \times \omega_r$ T_L : External load torque
 For the safety, we strongly recommend the users should select the proper resistance value according to the load.

For example:

When external load torque is a +70% rated torque and rotation speed reaches 3000r/min, if using 400W servo drive (rated torque: 1.27Nt-m), then the users need to connect a external regenerative resistor which power is $2 \times (0.7 \times 1.27) \times (3000 \times 2 \times \pi / 60) = 560W, 40 \Omega$.

• Simple Calculation Method

The users can select the adequate regenerative resistors according to the allowable frequency required by actual operation and the allowable frequency when the servo motor runs without load. The allowable frequency when the servo motor run without load is the maximum frequency that can be operated during continuous operation when servo motor accelerate from 0r/min to rated speed and decelerate from rated speed down to 0r/min. The allowable frequencies when the servo motor run without load are summarized in the following table.

Lexium 23C Series

| Allowable frequency when the servo motor runs without load (times/min) and uses built-in regenerative resistor | | | | | | | | | |
|---|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Motor Capacity (kW) | 0.1 | 0.2 | 0.3 | 0.4 | 0.4 | 0.5 | 0.6 | 0.75 | 0.9 |
| | BCH0 401O | BCH0 601O | BCH1 301M | BCH0 602O | BCH1 801O | BCH1 301N | BCH1 302M | BCH0 802O | BCH1 303M |
| Servo Motor | 12133 | 2022 | 43 | 1275 | 519 | 43 | 42 | 312 | 31 |

| Allowable frequency when the servo motor runs without load (times/min) and uses built-in regenerative resistor | | | | | | | | | |
|---|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Motor Capacity (kW) | 1.0 | 1.0 | 1.5 | 2.0 | 2.0 | 2.0 | 3.0 | 3.5 | 4.5 |
| | BCH1 001O | BCH1 302N | BCH1 303N | BCH1 002O | BCH1 304N | BCH1 801N | BCH1 802M | BCH1 802N | BCH1 803M |
| Servo Motor | 137 | 42 | 32 | 83 | 24 | 10 | 11 | 11 | 8 |

When the servo motor runs with load, the allowable frequency will change according to the changes of the load inertia and rotation speed. Use the following equation to calculate the allowable frequency.

$$\text{Allowable frequency} = \frac{\text{Allowable frequency when servo motor run without load}}{m+1} \times \left(\frac{\text{Rated speed}}{\text{Operating speed}} \right)^2 \frac{\text{times}}{\text{min}}$$

$m = \text{load/motor inertia ratio}$

The users can select the adequate external regenerative resistors according to the allowable frequency by referring to the table below:

Lexium 23C Series

| Allowable frequency when the servo motor run without load (times/min) and uses external regenerative resistor | | | | | | | | |
|--|-----|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Motor Capacity(kW) Recommended Regenerative Resistor Specifications | 0.1 | 0.2 | 0.3 | 0.4 | 0.4 | 0.5 | 0.6 | 0.75 |
| | | BCH0 401O | BCH0 601O | BCH1 301M | BCH0 602O | BCH0 801O | BCH1 301N | BCH1 302M |
| VW3M7111 | | | 292 | 8608 | 3506 | 291 | 283 | 2110 |
| VW3M7112 | | | 729 | | 8765 | 729 | 708 | 5274 |

| Allowable frequency when the servo motor run without load (times/min) and uses external regenerative resistor | | | | | | | |
|--|-----|--------------|--------------|--------------|--------------|--------------|--------------|
| Motor Capacity(kW) Recommended Regenerative Resistor Specifications | 0.9 | 1 | 1 | 1.5 | 2 | 2 | 2 |
| | | BCH1 303M | BCH1 001O | BCH1 302N | BCH1 303N | BCH1 002O | BCH1 304N |
| VW3M7111 | 213 | 925 | 283 | 213 | 562 | 163 | 68 |
| VW3M7112 | 533 | 2312 | 708 | 533 | 1406 | 408 | 171 |

Lexium 23M Series

| Allowable frequency when the servo motor run without load (times/min) and uses external regenerative resistor | | | |
|--|-----|----------|-----|
| Motor Capacity(kW) Recommended Regenerative Resistor Specifications | 3.0 | | 4.5 |
| | | BCH1802M | |
| 3kW 10Ω | 331 | | 234 |

When the regenerative resistor capacity is not enough, the users can connect to multiple the same capacity regenerative resistors in parallel to increase it.

Note: Regarding the selection of regenerative resistor, please refer to the table of regenerative resistor specifications described in Appendix.

6.6.4 Analog Monitor

Users can use analog monitor to observe the required analog voltage signals. Lexium 23 series servo drives provide two analog channels, they are PIN No. 15 and 16 of CN1 connector. The parameters relative to analog monitor are shown below.

Relevant parameters:

| | | | |
|--------------|------------|------------------------------|-----------------------------------|
| P0-03 | MON | Analog Monitor Output | Communication Addr.: 0003H |
|--------------|------------|------------------------------|-----------------------------------|

Default: 01

Related Section:


Applicable Control Mode: ALL

Section 4.3.5

Unit: N/A

Range: 00 ~ 55

Settings:



AB: (A: CH1; B: CH2)

0: Motor speed (+/-8V / maximum motor speed)

1: Motor torque (+/-8V / maximum torque)

2: Pulse command frequency (+8Volts / 650Kpps) (Lexium 23C series)

Pulse command frequency (+8Volts / 4.5Mpps) (Lexium 23M series)

3: Speed command (+/-8Volts / maximum speed command)

4: Torque command (+/-8Volts / maximum torque command)


5: V_BUS voltage (+/-8Volts / 450V)

Note: For the setting of analog output voltage proportion, refer to the P1-04 and P1-05.

Example:

P0-03 = 01 (CH1 is speed analog output)

Motor speed = (Max. motor speed x V1/8) x P1-04/100, when the output voltage value of CH1 is V1.

| P1-03 | AOUT | Pulse Output Polarity Setting | Communication Addr.: 0103H |
|-------|------|---|---|
| | | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 - 1 Settings: | Related Section: Section 3.3.3 |
| | |  | |
| | | A: Monitor analog output polarity A=0: MON1(+), MON2(+) A=1: MON1(+), MON2(-) A=2: MON1(-), MON2(+) A=3: MON1(-), MON2(-) | B: Position pulse output polarity B=0: Forward output B=1: Reverse output |


| P1-04 | MON1 | Analog Monitor Output Proportion 1 (CH1) | Communication Addr.: 0104H |
|-------|------|--|-----------------------------------|
| | | Default: 100 Applicable Control Mode: ALL Unit: % (full scale) Range: 0 - 100 | Related Section: Section 6.4.4 |

| P1-05 | MON2 | Analog Monitor Output Proportion 2 (CH2) | Communication Addr.: 0414H |
|-------|------|--|-----------------------------------|
| | | Default: 100 Applicable Control Mode: ALL Unit: % (full scale) Range: 0 - 100 | Related Section: Section 6.4.4 |

| P4-20 | DOF1 | Analog Monitor Output Drift Adjustment (CH1) | Communication Addr.: 0414H |
|-------|------|---|---------------------------------------|
| | | Default: Factory setting Applicable Control Mode: ALL Unit: mV Range: -800-800 Settings: When P2-08 is set to 10, users cannot reset this parameter. | Related Section: Section 6.4.4 |
| P4-21 | DOF2 | Analog Monitor Output Drift Adjustment (CH2) | Communication Addr.: 0415H |
| | | Default: Factory setting Applicable Control Mode: ALL Unit: mV Range: -800-800 Settings: When P2-08 is set to 10, users cannot reset this parameter. | Related Section: N/A Section 6.4.4 |

For example, when the users want to observe the analog voltage signal of channel 1, if the monitor output setting range is 8V per 325Kpps, then it is needed to change the setting value of parameter P1-04 (Analog Monitor Output Proportion 1) to 50 (=325Kpps/Max. input frequency). Other related parameters setting include parameter P0-03 (A=3) and P1-03 (A=0-3, output polarity setting). In general, when output voltage value of Ch1 is V1, the pulse command frequency is equal to $(\text{Max. input frequency} \times V1/8) \times P1-04/100$.

Because there is an offset value of analog monitor output voltage, the zero voltage level of analog monitor output does not match to the zero point of setting value. We recommend the users can use Analog Monitor Output Drift Adjustment, DOF1 (parameter P4-20) and DOF2 (parameter P4-21) to improve this condition. The maximum output voltage range of analog monitor output is $\pm 8V$. If the output voltage exceed its limit, it is still limited within the range of $\pm 8V$. The revolution provided by Lexium 23 series servo drives is 10bit, approximated to 13mv/LSB.




6.6.5 Electromagnetic Brake

When the servo drive is operating, if the digital output BRKR is set to Off, it indicates the electromagnetic brake is disabled and motor is stop running and locked. If the digital output BRKR is set to ON, it indicates electromagnetic brake is enabled and motor can run freely.

There are two parameters that affect the electromagnetic brake. One is parameter P1-42 (MBT1) and the other is parameter P1-43 (MBT2). The users can use these two parameters to set the On and Off delay time of electromagnetic brake. The electromagnetic brake is usually used in perpendicular axis (Zaxis) direction to reduce the large energy generated from servo motor. Using electromagnetic brake can avoid the load may slip since there is no motor holding torque when power is off. Without using electromagnetic brake may reduce the life of servo motor. To avoid malfunction, the electromagnetic brake should be activated after servo system is off (Servo Off).

If the users desire to control electromagnetic brake via external controller, not by the servo drive, the users must execute the function of electromagnetic brake during the period of time when servo motor is braking. The braking strength of motor and electromagnetic brake must be in the same direction when servo motor is braking. Then, the servo drive will operate normally. However, the servo drive may generate larger current during acceleration or at constant speed and it may be the cause of overload (servo fault).


Timing chart for using servo motor with electromagnetic brake:



BRKR output timing explanation:


1. When SERVO OFF (when DI SON is not activated), the BRKR output goes Off (electromagnetic brake is locked) after the delay time set by P1-43 is reached and the motor speed is still higher than the setting value of P1-38.
2. When SERVO OFF (when DI SON is not activated), the BRKR output goes Off (electromagnetic brake is locked) if the delay time set by P1-43 is not reached and the motor speed is still lower than the setting value of P1-38.

Electromagnetic Brake Wiring Diagram

**Note:**

- 1) Please refer to Chapter 3 Connections and Wiring for more wiring information.
- 2) The BRKR signal is used to control the brake operation. The VDD DC24V power supply of the servo drive can be used to power the relay coil (Relay). When BRKR signal is ON, the motor brake will be activated.
- 3) Please note that the coil of brake has no polarity.
- 4) The power supply for brake is DC24V. Never use it for VDD, the +24V source voltage.

The timing charts of control circuit power and main circuit power:



Servo Parameters



At a Glance

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|-----------------------------|------|
| Definition | 170 |
| Parameters Summary | 171 |
| Detailed Parameter Listings | 190 |

7.1 Definition

There are following five groups for drive parameters:

| | |
|----------------------------------|------------------|
| Group 0: Monitor parameter | (example: P0-xx) |
| Group 1: Basic parameter | (example: P1-xx) |
| Group 2: Extension parameter | (example: P2-xx) |
| Group 3: Communication parameter | (example: P3-xx) |
| Group 4: Diagnosis parameter | (example: P4-xx) |

Abbreviation of control modes:

Pt : Position control mode (command from external signal)

Pr : Position control mode (command from internal signal)

S : Speed control mode

T : Torque control mode

Explanation of symbols (marked after parameter)

(★) Read-only register, such as P0-00, P0-01, P4-00.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled), such as P1-00, P2-32.

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on), such as P1-01, P1-33.

(■) Parameter setting values are not retained when power is off, such as P3-06.

7.2 Parameters Summary

7.2.1 Parameters List by Group

Group 0: PO-xx

| Monitor Parameters | | | | | | | | |
|--------------------|-------|------------------------------------|-----------------|------|--------------|----|---|---|
| Parameter | Name | Function | Default | Unit | Control Mode | | | |
| | | | | | Pt | Pr | S | T |
| PO-00★ | VER | Firmware Version | Factory setting | N/A | ○ | ○ | ○ | ○ |
| PO-01★ | ALE | Drive Fault Code | N/A | N/A | ○ | ○ | ○ | ○ |
| PO-02 | STS | Drive Status | 00 | N/A | ○ | ○ | ○ | ○ |
| PO-03 | MON | Analog Monitor Output | 01 | N/A | ○ | ○ | ○ | ○ |
| PO-04 | CM1 | Status Monitor 1 | 0 | N/A | ○ | ○ | ○ | ○ |
| PO-05 | CM2 | Status Monitor 2 | 0 | N/A | ○ | ○ | ○ | ○ |
| PO-06 | CM3 | Status Monitor 3 | 0 | N/A | ○ | ○ | ○ | ○ |
| PO-07 | CM4 | Status Monitor 4 | 0 | N/A | ○ | ○ | ○ | ○ |
| PO-08 | CM5 | Status Monitor 5 | 0 | N/A | ○ | ○ | ○ | ○ |
| PO-09 | MAP0 | Block Data Read / Write Register 0 | 407H | N/A | ○ | ○ | ○ | ○ |
| PO-10 | MAP1 | Block Data Read / Write Register 1 | 10FH | N/A | ○ | ○ | ○ | ○ |
| PO-11 | MAP2 | Block Data Read / Write Register 2 | 110H | N/A | ○ | ○ | ○ | ○ |
| PO-12 | MAP3 | Block Data Read / Write Register 3 | 224H | N/A | ○ | ○ | ○ | ○ |
| PO-13 | MAP4 | Block Data Read / Write Register 4 | 111H | N/A | ○ | ○ | ○ | ○ |
| PO-14 | MAP5 | Block Data Read / Write Register 5 | 112H | N/A | ○ | ○ | ○ | ○ |
| PO-15 | MAP6 | Block Data Read / Write Register 6 | 225H | N/A | ○ | ○ | ○ | ○ |
| PO-16 | MAP7 | Block Data Read / Write Register 7 | 109H | N/A | ○ | ○ | ○ | ○ |
| PO-17 | SVSTS | Servo Output Status Display | N/A | N/A | ○ | ○ | ○ | ○ |

Explanation of symbols (marked after parameter)

- (★) Read-only register.
- (▲) Parameter cannot be set when Servo On (when the servo drive is enabled).
- (●) Parameter is effective only after the servo drive is restarted (after switching power off and on).
- (■) Parameter setting values are not retained when power is off.

Group 1: P1-xx

| Basic Parameters | | | | | | | | |
|------------------|----------------------------------|--|--------------|-----------------------|--------------|----|---|---|
| Parameter | Name | Function | Default | Unit | Control Mode | | | |
| | | | | | Pt | Pr | S | T |
| P0-00▲ | PTT | External Pulse Input Type | 2 | N/A | O | | | |
| P0-01● | CTL | Control Mode and Output Direction | 0 | pulse r/min N-m | O | O | O | O |
| P1-02▲ | PSTL | Speed and Torque Limit | 0 | N/A | O | O | O | O |
| P1-03 | AOUT | Pulse Output Polarity Setting | 0 | N/A | O | O | O | O |
| P1-04 | MON1 | Analog Monitor Output Proportion 1 (CH1) | 100 | % | O | O | O | O |
| P1-05 | MON2 | Analog Monitor Output Proportion 2 (CH2) | 100 | % | O | O | O | O |
| P1-06 | SFLT | Accel / Decel Smooth Constant of Analog Speed Command (Low-pass Filter) | 0 | ms | | | O | |
| P1-07 | TFLT | Smooth Constant of Analog Torque Command (Low-pass Filter) | 0 | ms | | | | O |
| P1-08 | PFLT | Smooth Constant of Position Command (Low-pass Filter) | 0 | ms | O | | | |
| P1-09 ~ P1-11 | SP1 ~ 3 | 1st ~ 3rd Speed Command 1st ~ 3rd Speed Limit | 100 ~ 300 | r/min | | | O | O |
| P1-12 ~ P1-14 | TQ1 ~ 3 | 1st ~ 3rd Torque Command 1st ~ 3rd Torque Limit | 100 | % | | | O | O |
| P1-15 ~P1-30 | PO1H ~ PO8H PO1L ~ PO8L | 1st ~ 8th Position command for Rotation 1st ~ 8th Position command for Pulse | 0 0 | N/A N/A | | O | | |
| P1-31 | Reserved | | | | | | | |
| P1-32 | LSTP | Motor Stop Mode Selection | 0 | N/A | O | O | O | O |
| P1-33● | POSS | Position Control Mode (Pr) | 0 | N/A | | O | | |
| P1-34 | TACC | Acceleration Time | 200 | ms | | O | O | |
| P1-35 | TDEC | Deceleration Time | 200 | ms | | O | O | |
| P1-36 | TSL | Accel /Decel S-curve | 0 | ms | | O | O | |
| P1-37 | GDR | Ratio of Load Inertia to Servo Motor Inertia | 5.0 | times | O | O | O | O |
| P1-38 | ZSPD | Zero Speed Range Setting | 10 | r/min | O | O | O | O |
| P1-39 | SSPD | Target Motor Speed | 3000 | r/min | O | O | O | O |

| Basic Parameters | | | | | | | | |
|--|----------|---|-------------|-------|--------------|----|---|---|
| Parameter | Name | Function | Default | Unit | Control Mode | | | |
| | | | | | Pt | Pr | S | T |
| P1-40▲ | VCM | Max. Analog Speed Command or Limit | rated speed | r/min | | | 0 | 0 |
| P1-41▲ | TCM | Max. Analog Torque Command or Limit | 100 | % | 0 | 0 | 0 | 0 |
| P1-42 | MBT1 | On Delay Time of Electromagnetic Brake | 0 | ms | 0 | 0 | 0 | 0 |
| P1-43 | MBT2 | OFF Delay Time of Electromagnetic Brake | 0 | ms | 0 | 0 | 0 | 0 |
| P1-44▲ | GR1 | Electronic Gear Ratio (1st Numerator) (N1) | 1 | pulse | 0 | 0 | | |
| P1-45▲ | GR2 | Electronic Gear Ratio (Denominator) | 1 | pulse | 0 | 0 | | |
| P1-46▲ | GR3 | Encoder Output Pulse Number | 1 | pulse | 0 | 0 | 0 | 0 |
| P1-47 | HMOV | Homing Mode | 00 | N/A | 0 | 0 | 0 | 0 |
| P1-48 | HSPD1 | 1st Speed Setting of High Speed Homing | 1000 | r/min | 0 | 0 | 0 | 0 |
| P1-49 | HSPD2 | 2nd Speed Setting of Low Speed Homing | 50 | r/min | 0 | 0 | 0 | 0 |
| P1-50 | HOF1 | Homing Offset Rotation Number | 0 | rev | 0 | 0 | 0 | 0 |
| P1-51 | HOF2 | Homing Offset Pulse Number | 0 | pulse | 0 | 0 | 0 | 0 |
| P1-52 | RES1 | Regenerative Resistor Value | N/A | Ohm | 0 | 0 | 0 | 0 |
| P1-53 | RES2 | Regenerative Resistor Capacity | N/A | Watt | 0 | 0 | 0 | 0 |
| P1-54 | PER | Positioning Completed Width | 100 | pulse | 0 | 0 | | |
| P1-55 | MSPD | Maximum Speed Limit | rated speed | r/min | 0 | 0 | 0 | 0 |
| P1-56 | OVW | Output Overload Warning Time | 120 | % | 0 | 0 | 0 | 0 |
| P1-57 | Reserved | | | | | | | |
| P1-58 | Reserved | | | | | | | |
| P1-62 | COKT | Delay Time of Internal Position Command Completed Output Signal | 0 | ms | | 0 | | |
| Parameters for Lexium 23M series only | | | | | | | | |
| P1-59 | MFLT | Analog Speed Linear Filter | 120 | % | | | 0 | |
| P1-60 | GR7 | High Resolution Electronic Gear Ratio | 7 | - | 0 | | | |
| P1-61 | GR8 | High Resolution Output Pulse Number | 7 | - | 0 | | | |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

Group 2: P2-xx

| Extension Parameters | | | | | | | | |
|----------------------|------|---|---------|------------------------|--------------|----|---|---|
| Parameter | Name | Function | Default | Unit | Control Mode | | | |
| | | | | | Pt | Pr | S | T |
| P2-00 | KPP | Proportional Position Loop Gain | 35 | rad/s | ○ | ○ | | |
| P2-01 | PPR | Position Loop Gain Switching Rate | 100 | % | ○ | ○ | | |
| P2-02 | KPF | Position Feed Forward Gain | 5000 | 0.0001 | ○ | ○ | | |
| P2-03 | PPF | Smooth Constant of Position Feed Forward Gain | 5 | ms | ○ | ○ | | |
| P2-04 | KVP | Proportional Speed Loop Gain | 500 | rad/s | ○ | ○ | ○ | ○ |
| P2-05 | SPR | Speed Loop Gain Switching Rate | 100 | % | ○ | ○ | ○ | ○ |
| P2-06 | KVI | Speed Integral Compensation | 100 | N/A | ○ | ○ | ○ | ○ |
| P2-07 | SFG | Speed Feed Forward Gain | 0 | 0.0001 | ○ | ○ | ○ | ○ |
| P2-08■ | PCTL | Special Factory Setting | 0 | N/A | ○ | ○ | ○ | ○ |
| P2-09 | DRT | Bounce Filter | 2 | 2ms | ○ | ○ | ○ | ○ |
| P2-10 | DI1 | Digital Input Terminal 1 (DI1) | 101 | N/A | ○ | ○ | ○ | ○ |
| P2-11 | DI2 | Digital Input Terminal 2 (DI2) | 104 | N/A | ○ | ○ | ○ | ○ |
| P2-12 | DI3 | Digital Input Terminal 3 (DI3) | 116 | N/A | ○ | ○ | ○ | ○ |
| P2-13 | DI4 | Digital Input Terminal 4 (DI4) | 117 | N/A | ○ | ○ | ○ | ○ |
| P2-14 | DI5 | Digital Input Terminal 5 (DI5) | 102 | N/A | ○ | ○ | ○ | ○ |
| P2-15 | DI6 | Digital Input Terminal 6 (DI6) | 22 | N/A | ○ | ○ | ○ | ○ |
| P2-16 | DI7 | Digital Input Terminal 7 (DI7) | 23 | N/A | ○ | ○ | ○ | ○ |
| P2-17 | DI8 | Digital Input Terminal 8 (DI8) | 21 | N/A | ○ | ○ | ○ | ○ |
| P2-18 | DO1 | Digital Output Terminal 1 (DO1) | 101 | N/A | ○ | ○ | ○ | ○ |
| P2-19 | DO2 | Digital Output Terminal 2 (DO2) | 103 | N/A | ○ | ○ | ○ | ○ |
| P2-20 | DO3 | Digital Output Terminal 3 (DO3) | 109 | N/A | ○ | ○ | ○ | ○ |
| P2-21 | DO4 | Digital Output Terminal 4 (DO4) | 105 | N/A | ○ | ○ | ○ | ○ |
| P2-22 | DO5 | Digital Output Terminal 5 (DO5) | 7 | N/A | ○ | ○ | ○ | ○ |
| P2-23 | NCF | Notch Filter (Resonance Suppression) | 1000 | Hz | ○ | ○ | ○ | ○ |
| P2-24 | DPH | Notch Filter Attenuation Rate (Resonance Suppression) | 0 | dB | ○ | ○ | ○ | ○ |
| P2-25 | NLP | Low-pass Filter Time Constant (Resonance Suppression) | 2 or 5 | ms | ○ | ○ | ○ | ○ |
| P2-26 | DST | External Anti-Interference Gain | 0 | 0.001 | ○ | ○ | ○ | ○ |
| P2-27 | GCC | Gain Switching Control Selection | 0 | N/A | ○ | ○ | ○ | ○ |
| P2-28 | GUT | Gain Switching Time Constant | 10 | 10ms | ○ | ○ | ○ | ○ |
| P2-29 | GPE | Gain Switching Condition | 10000 | pulse Kpps r/min | ○ | ○ | ○ | ○ |
| P2-30■ | INH | Auxiliary Function | 0 | N/A | ○ | ○ | ○ | ○ |
| P2-31■ | AUT1 | Auto Mode Responsiveness Level | 44 | N/A | ○ | ○ | ○ | ○ |
| P2-32▲ | AUT2 | Tuning Mode Selection | 0 | N/A | ○ | ○ | ○ | ○ |
| P2-33▲ | INF | Easy Setting of Input Filter | 0 | N/A | ○ | ○ | ○ | ○ |

| Extension Parameters | | | | | | | | |
|----------------------|----------------|---|---------|-------|--------------|----|---|---|
| Parameter | Name | Function | Default | Unit | Control Mode | | | |
| | | | | | Pt | Pr | S | T |
| P2-34 | SDEV | Overspeed Warning Condition | 5000 | r/min | | | O | |
| P2-35 | PDEV | Excessive Error Warning Condition | 30000 | pulse | O | O | | |
| P2-36 - P2-43 | POV1 - POV8 | Moving Speed Setting of 1st ~ 8th Position | 1000 | r/min | | O | | |
| P2-44 | DOM | Digital Output Mode Setting | 0 | N/A | | O | | |
| P2-45 | DOD | Combination Output Signal Delay Time | 1 | 4ms | | O | | |
| P2-46 | FSN | Feed Step Number | 6 | N/A | | O | | |
| P2-47 | PED | Position Deviation Clear Delay Time | 0 | 20ms | | O | | |
| P2-48 | BLAS | Backlash Compensation of Feed Step Control | 0 | pulse | | O | | |
| P2-49 | SJIT | Speed Detection Filter and Jitter Suppression | 0 | sec | O | O | O | O |
| P2-50 | DCLR | Pulse Deviation Clear Mode | 0 | N/A | O | O | | |
| P2-51 | SRON | Servo | 0 | N/A | O | O | O | O |
| P2-52 | ATM0 | Timer 0 of Auto Mode | 0 | sec | | O | | |
| P2-53 | ATM1 | Timer 1 of Auto Mode | 0 | sec | | O | | |
| P2-54 | ATM2 | Timer 2 of Auto Mode | 0 | sec | | O | | |
| P2-55 | ATM3 | Timer 3 of Auto Mode | 0 | sec | | O | | |
| P2-56 | ATM4 | Timer 4 of Auto Mode | 0 | sec | | O | | |
| P2-57 | ATM5 | Timer 5 of Auto Mode | 0 | sec | | O | | |
| P2-58 | ATM6 | Timer 6 of Auto Mode | 0 | sec | | O | | |
| P2-59 | ATM7 | Timer 7 of Auto Mode | 0 | sec | | O | | |
| P2-60 | GR4 | Electronic Gear Ratio (2nd Numerator) (N2) | 1 | pulse | O | O | | |
| P2-61 | GR5 | Electronic Gear Ratio (3rd Numerator) (N3) | 1 | pulse | O | O | | |
| P2-62 | GR6 | Electronic Gear Ratio (4th Numerator) (N4) | 1 | pulse | O | O | | |
| P2-63 | TSCA | Proportion Value Setting | 0 | times | O | O | O | |
| P2-64 | TLMOD | Torque Limit Mixed Mode | 0 | N/A | O | O | O | |
| P2-65 | GBIT | Special Function | 0 | N/A | O | O | O | |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

Group 3: P3-xx

| Communication Parameters | | | | | | | | |
|--------------------------|------|--------------------------------------|---------|-------|--------------|----|---|---|
| Parameter | Name | Function | Default | Unit | Control Mode | | | |
| | | | | | Pt | Pr | S | T |
| P3-00 | ADR | Communication Address Setting | 1 | N/A | ○ | ○ | ○ | ○ |
| P3-01 | BRT | Transmission Speed | 1 | bps | ○ | ○ | ○ | ○ |
| P3-02 | PTL | Communication Protocol | 0 | N/A | ○ | ○ | ○ | ○ |
| P3-03 | FLT | Transmission Fault Treatment | 0 | N/A | ○ | ○ | ○ | ○ |
| P3-04 | CWD | Communication Time Out Detection | 0 | sec | ○ | ○ | ○ | ○ |
| P3-05 | CMM | Communication Selection | 0 | N/A | ○ | ○ | ○ | ○ |
| P3-06■ | SDI | Digital Input Communication Function | 0 | N/A | ○ | ○ | ○ | ○ |
| P3-07 | CDT | Communication Response Delay Time | 0 | 0.5ms | ○ | ○ | ○ | ○ |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

Group 4: P4-xx

| Diagnosis Parameters | | | | | | | | |
|----------------------|------|--|-----------------|-------|--------------|----|---|---|
| Parameter | Name | Function | Default | Unit | Control Mode | | | |
| | | | | | Pt | Pr | S | T |
| P4-00★ | ASH1 | Fault Record (N) | 0 | N/A | 0 | 0 | 0 | 0 |
| P4-01★ | ASH2 | Fault Record (N-1) | 0 | N/A | 0 | 0 | 0 | 0 |
| P4-02★ | ASH3 | Fault Record (N-2) | 0 | N/A | 0 | 0 | 0 | 0 |
| P4-03★ | ASH4 | Fault Record (N-3) | 0 | N/A | 0 | 0 | 0 | 0 |
| P4-04★ | ASH5 | Fault Record (N-4) | 0 | N/A | 0 | 0 | 0 | 0 |
| P4-05 | JOG | JOG Operation | 20 | r/min | 0 | 0 | 0 | 0 |
| P4-06▲■ | FOT | Force Output Control | 0 | N/A | 0 | 0 | 0 | 0 |
| P4-07■ | ITST | Input Status or Force Input Control | N/A | N/A | 0 | 0 | 0 | 0 |
| P4-08 | PKEY | Digital Keypad Input of Servo Drive | N/A | N/A | 0 | 0 | 0 | 0 |
| P4-09★ | MOT | Output Status Display | N/A | N/A | 0 | 0 | 0 | 0 |
| P4-10▲ | CEN | Adjustment Function | 0 | N/A | 0 | 0 | 0 | 0 |
| P4-11 | SOF1 | Analog Speed Input Drift Adjustment 1 | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-12 | SOF2 | Analog Speed Input Drift Adjustment 2 | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-13 | TOF1 | Analog Torque Drift Adjustment 1 | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-14 | TOF2 | Analog Torque Drift Adjustment 2 | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-15 | COF1 | Current Detector Drift Adjustment (V1 phase) | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-16 | COF2 | Current Detector Drift Adjustment (V2 phase) | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-17 | COF3 | Current Detector Drift Adjustment (W1 phase) | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-18 | COF4 | Current Detector Drift Adjustment (W2 phase) | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-19 | TIGB | IGBT NTC Calibration | Factory setting | N/A | 0 | 0 | 0 | 0 |
| P4-20 | DOF1 | Analog Monitor Output Drift Adjustment (CH1) | 0 | mV | 0 | 0 | 0 | 0 |
| P4-21 | DOF2 | Analog Monitor Output Drift Adjustment (CH2) | 0 | mV | 0 | 0 | 0 | 0 |
| P4-22 | SAO | Analog Speed Input Offset | 0 | mV | | | 0 | |
| P4-23 | TAO | Analog Torque Input Offset | 0 | mV | | | | 0 |

7.2.2 Parameters List by Function

| Monitor and General Use | | | | | | | | | |
|-------------------------|-------|--|-----------------|------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P0-00★ | VER | Firmware Version | Factory setting | N/A | O | O | O | O | - |
| P0-01★ | ALE | Drive Fault Code | N/A | N/A | O | O | O | O | 10.1 |
| P0-02 | STS | Drive Status | 00 | N/A | O | O | O | O | 4.3.5 |
| P0-03 | MON | Analog Monitor Output | 01 | N/A | O | O | O | O | 4.3.5 |
| P0-04 | CM1 | Status Monitor 1 | 0 | N/A | O | O | O | O | 4.3.5 |
| P0-05 | CM2 | Status Monitor 2 | 0 | N/A | O | O | O | O | 4.3.5 |
| P0-06 | CM3 | Status Monitor 3 | 0 | N/A | O | O | O | O | 4.3.5 |
| P0-07 | CM4 | Status Monitor 4 | 0 | N/A | O | O | O | O | 4.3.5 |
| P0-08 | CM5 | Status Monitor 5 | 0 | N/A | O | O | O | O | 4.3.5 |
| P0-09 | MAP0 | Block Data Read / Write Register 0 | 407H | N/A | O | O | O | O | - |
| P0-10 | MAP1 | Block Data Read / Write Register 1 | 10FH | N/A | O | O | O | O | - |
| P0-11 | MAP2 | Block Data Read / Write Register 2 | 110H | N/A | O | O | O | O | - |
| P0-12 | MAP3 | Block Data Read / Write Register 3 | 224H | N/A | O | O | O | O | - |
| P0-13 | MAP4 | Block Data Read / Write Register 4 | 111H | N/A | O | O | O | O | - |
| P0-14 | MAP5 | Block Data Read / Write Register 5 | 112H | N/A | O | O | O | O | - |
| P0-15 | MAP6 | Block Data Read / Write Register 6 | 225H | N/A | O | O | O | O | - |
| P0-16 | MAP7 | Block Data Read / Write Register 7 | 109H | N/A | O | O | O | O | - |
| P0-17 | SVSTS | Servo Output Status Display | N/A | N/A | O | O | O | O | - |
| P1-03 | AOUT | Pulse Output Polarity Setting | 0 | N/A | O | O | O | O | 3.3.3 |
| P1-04 | MON1 | Analog Monitor Output Proportion 1 (CH1) | 100 | % | O | O | O | O | 6.4.4 |
| P1-05 | MON2 | Analog Monitor Output Proportion 2 (CH2) | 100 | % | O | O | O | O | 6.4.4 |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

| Smooth Filter and Resonance Suppression | | | | | | | | | |
|---|------|--|---------|------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P1-06 | SFLT | Accel / Decel Smooth Constant of Analog Speed Command (Lowpass Filter) | 0 | ms | | | | O | 6.3.3 |
| P1-07 | TFLT | Smooth Constant of Analog Torque Command (Low-pass Filter) | 0 | ms | | | O | | 6.4.3 |
| P1-08 | PFLT | Smooth Constant of Position Command (Low-pass Filter) | 0 | ms | O | | | | 6.2.6 |
| P1-34 | TACC | Acceleration Time | 200 | ms | | O | O | | 6.3.3 |
| P1-35 | TDEC | Deceleration Time | 200 | ms | | O | O | | 6.3.3 |
| P1-36 | TSL | Accel /Decel S-curve | 0 | ms | | O | O | | 6.2.4 6.3.3 |
| P2-23 | NCF | Notch Filter (Resonance Suppression) | 1000 | Hz | O | O | O | O | 6.3.7 |
| P2-24 | DPH | Notch Filter Attenuation Rate (Resonance Suppression) | 0 | dB | O | O | O | O | 6.3.7 |
| P2-25 | NLP | Low-pass Filter Time Constant (Resonance Suppression) | 2 or 5 | ms | O | O | O | O | 6.3.7 |
| P2-33▲ | INF | Easy Setting of Input Filter | 0 | N/A | O | O | O | O | 6.3.6 |
| P2-49 | SJIT | Speed Detection Filter and Jitter Suppression | 0 | sec | O | O | O | O | - |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

| Gain and Switch | | | | | | | | | |
|-----------------|------|---|---------|------------------------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P2-00 | KPP | Proportional Position Loop Gain | 35 | rad/s | O | O | | | 6.2.8 |
| P2-01 | PPR | Position Loop Gain Switching Rate | 100 | % | O | O | | | - |
| P2-02 | KPF | Position Feed Forward Gain | 5000 | 0.0001 | O | O | | | 6.2.8 |
| P2-03 | PFF | Smooth Constant of Position Feed Forward Gain | 5 | ms | O | O | | | - |
| P2-04 | KVP | Proportional Speed Loop Gain | 500 | rad/s | O | O | O | O | 6.3.6 |
| P2-05 | SPR | Speed Loop Gain Switching Rate | 100 | % | O | O | O | O | - |
| P2-06 | KVI | Speed Integral Compensation | 100 | N/A | O | O | O | O | 6.3.6 |
| P2-07 | SFG | Speed Feed Forward Gain | 0 | 0.0001 | | O | O | O | 6.3.6 |
| P2-26 | DST | External Anti-Interference Gain | 0 | 0.001 | O | O | O | O | - |
| P2-27 | GCC | Gain Switching Control Selection | 0 | N/A | O | O | O | O | - |
| P2-28 | GUT | Gain Switching Time Constant | 10 | 10ms | O | O | O | O | - |
| P2-29 | GPE | Gain Switching Condition | 10000 | pulse Kpps r/min | O | O | O | O | - |
| P2-31■ | AUT1 | Auto Mode Responsiveness Level | 44 | N/A | O | O | O | O | 6.3.6 |
| P2-32▲ | AUT2 | Tuning Mode Selection | 0 | N/A | O | O | O | O | 6.3.6 |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

| Position Control | | | | | | | | | |
|--|------------|--|---------|-----------------------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P1-01● | CTL | Control Mode and Output Direction | 0 | pulse r/min N.M | O | O | O | O | 6.1 |
| P1-02▲ | PSTL | Speed and Torque Limit | 0 | N/A | O | O | O | O | 6.6 |
| P1-46▲ | GR3 | Encoder Output Pulse Number | 1 | pulse | O | O | O | O | - |
| P1-55 | MSPD | Maximum Speed Limit | rated | r/min | O | O | O | O | - |
| P1-12- P1-14 | TQ1 - 3 | 1st ~ 3rd Torque Command 1st ~ 3rd Torque Limit | 100 | % | O | O | O | O | 6.4.1 |
| P2-50 | DCLR | Pulse Deviation Clear Mode | 0 | N/A | O | O | | | - |
| External pulse control command (Pt mode) | | | | | | | | | |
| P1-00▲ | PTT | External Pulse Input Type | 2 | N/A | O | | | | 6.2.1 |
| P1-44▲ | GR1 | Electronic Gear Ratio (1st Numerator) (N1) | 1 | pulse | O | O | | | 6.2.5 |
| P1-45▲ | GR2 | Electronic Gear Ratio (Denominator) | 1 | pulse | O | O | | | 6.3.6 |
| P2-60 | GR4 | Electronic Gear Ratio (2nd Numerator) (N2) | 1 | pulse | O | O | | | Table 7.A |
| P2-61 | GR5 | Electronic Gear Ratio (3rd Numerator) (N3) | 1 | pulse | O | O | | | Table 7.A |
| P2-62 | GR6 | Electronic Gear Ratio (4th Numerator) (N4) | 1 | pulse | O | O | | | Table 7.A |

| Position Control | | | | | | | | | |
|--|-------------|---|---------|-------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| Internal pulse control command (Pr mode) | | | | | | | | | |
| P1-15 ~ P1-30 | PO1H ~ PO8H | 1st ~ 8th Position command for Rotation | 0 | N/A | O | | | | 6.2.2 |
| | PO1L ~ PO8L | 1st ~ 8th Position command for Pulse | | | | | | | |
| P2-36 ~ P2-43 | POV1 ~ POV8 | Moving Speed Setting of 1st ~ 8th Position | 1000 | r/min | O | | | | 6.2.2 |
| P1-33● | POSS | Position Control Mode (Pr) | 0 | N/A | O | | | | 6.2.2 |
| P1-47 | HMOV | Homing Mode | 0 | N/A | O | O | O | O | 12.8 |
| P1-48 | HSPD1 | 1st Speed Setting of High Speed Homing | 1000 | r/min | O | O | O | O | 12.8 |
| P1-49 | HSPD2 | 2nd Speed Setting of Low Speed Homing | 50 | r/min | O | O | O | O | 12.8 |
| P1-50 | HOF1 | Homing Offset Rotation Number | 0 | rev | O | O | O | O | - |
| P1-51 | HOF2 | Homing Offset Pulse Number | 0 | pulse | O | O | O | O | - |
| P1-62 | COKT | Delay Time of Internal Position Command Completed Output Signal | 0 | ms | | O | | | - |

| Position Control | | | | | | | | | |
|------------------|------|--|---------|-------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P2-45 | DOD | Combination Output Signal Delay Time | 1 | 4ms | | O | | | 12.6 |
| P2-46 | FSN | Feed Step Number | 6 | N/A | | O | | | 12.6 |
| P2-47 | PED | Position Deviation Clear Delay Time | 0 | 20ms | | O | | | 12.6 |
| P2-48 | BLAS | Backlash Compensation of Feed Step Control | 0 | pulse | | O | | | 12.6 |
| P2-52 | ATM0 | Timer 0 of Auto Mode | 0 | sec | | O | | | - |
| P2-53 | ATM1 | Timer 1 of Auto Mode | 0 | sec | | O | | | - |
| P2-54 | ATM2 | Timer 2 of Auto Mode | 0 | sec | | O | | | - |
| P2-55 | ATM3 | Timer 3 of Auto Mode | 0 | sec | | O | | | - |
| P2-56 | ATM4 | Timer 4 of Auto Mode | 0 | sec | | O | | | - |
| P2-57 | ATM5 | Timer 5 of Auto Mode | 0 | sec | | O | | | - |
| P2-58 | ATM6 | Timer 6 of Auto Mode | 0 | sec | | O | | | - |
| P2-59 | ATM7 | Timer 7 of Auto Mode | 0 | sec | | O | | | - |

Explanation of symbols (marked after parameter)

- (★) Read-only register.
- (▲) Parameter cannot be set when Servo On (when the servo drive is enabled).
- (●) Parameter is effective only after the servo drive is restarted (after switching power off and on).
- (■) Parameter setting values are not retained when power is off.

| Speed Control | | | | | | | | | |
|-----------------|-----------|-------------------------------------|-------------|-----------------------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P1-01● | CTL | Control Mode and Output Direction | 0 | pulse r/min N.M | O | O | O | O | 6.1 |
| P1-02▲ | PSTL | Speed and Torque Limit | 0 | N/A | O | O | O | O | 6.6 |
| P1-46▲ | GR3 | Encoder Output Pulse Number | 1 | pulse | O | O | O | O | - |
| P1-55 | MSPD | Maximum Speed Limit | rated speed | r/min | O | O | O | O | - |
| P1-09- P1-11 | SP1-3 | 1st - 3rd Speed Command | 100 - 300 | r/min | | | O | O | 6.3.1 |
| | | 1st - 3rd Speed Limit | | | | | | | |
| P1-12- P1-14 | TQ1-3 | 1st - 3rd Torque Command | 100 | % | O | O | O | O | 6.6.2 |
| | | 1st - 3rd Torque Limit | | | | | | | |
| P1-40▲ | VCM | Max. Analog Speed Command or Limit | rated speed | r/min | | | O | O | 6.3.4 |
| P1-41▲ | TCM | Max. Analog Torque Command or Limit | 100 | % | O | O | O | O | - |
| P2-63 | TSCA | Proportion Value Setting | 0 | times | O | O | O | | - |
| P2-64 | TLMO D | Torque Limit Mixed Mode | 0 | N/A | O | O | O | | - |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

| Torque Control | | | | | | | | | |
|-----------------|-------|-------------------------------------|-------------|-----------------------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P1-01● | CTL | Control Mode and Output Direction | 0 | pulse r/min N.M | O | O | O | O | 6.1 |
| P1-02▲ | PSTL | Speed and Torque Limit | 0 | N/A | O | O | O | O | 6.6 |
| P1-46▲ | GR3 | Encoder Output Pulse Number | 1 | pulse | O | O | O | O | - |
| P1-55 | MSPD | Maximum Speed Limit | rated speed | r/min | O | O | O | O | - |
| P1-09- P1-11 | SP1-3 | 1st ~ 3rd Speed Command | 100 ~ 300 | r/min | | | O | O | 6.6.1 |
| | | 1st ~ 3rd Speed Limit | | | | | | | |
| P1-12- P1-14 | TQ1-3 | 1st ~ 3rd Torque Command | 100 | % | O | O | O | O | 6.4.1 |
| | | 1st ~ 3rd Torque Limit | | | | | | | |
| P1-40▲ | VCM | Max. Analog Speed Command or Limit | rated speed | r/min | | | O | O | - |
| P1-41▲ | TCM | Max. Analog Torque Command or Limit | 100 | % | O | O | O | O | 6.4.4 |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

Digital I/O and relative input output setting

| Digital I/O | | | | | | | | | |
|-------------|------|---|---------|-------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P2-09 | DRT | Bounce Filter | 2 | 2ms | O | O | O | O | Table 7.A |
| P2-10 | DI1 | Digital Input Terminal 1 (DI1) | 101 | N/A | O | O | O | O | |
| P2-11 | DI2 | Digital Input Terminal 2 (DI2) | 104 | N/A | O | O | O | O | |
| P2-12 | DI3 | Digital Input Terminal 3 (DI3) | 116 | N/A | O | O | O | O | |
| P2-13 | DI4 | Digital Input Terminal 4 (DI4) | 117 | N/A | O | O | O | O | |
| P2-14 | DI5 | Digital Input Terminal 5 (DI5) | 102 | N/A | O | O | O | O | |
| P2-15 | DI6 | Digital Input Terminal 6 (DI6) | 22 | N/A | O | O | O | O | |
| P2-16 | DI7 | Digital Input Terminal 7 (DI7) | 23 | N/A | O | O | O | O | |
| P2-17 | DI8 | Digital Input Terminal 8 (DI8) | 21 | N/A | O | O | O | O | Table 7.B |
| P2-18 | DO1 | Digital Output Terminal 1 (DO1) | 101 | N/A | O | O | O | O | |
| P2-19 | DO2 | Digital Output Terminal 2 (DO2) | 103 | N/A | O | O | O | O | |
| P2-20 | DO3 | Digital Output Terminal 3 (DO3) | 109 | N/A | O | O | O | O | |
| P2-21 | DO4 | Digital Output Terminal 4 (DO4) | 105 | N/A | O | O | O | O | |
| P2-22 | DO5 | Digital Output Terminal 5 (DO5) | 7 | N/A | O | O | O | O | |
| P1-38 | ZSPD | Zero Speed Range Setting | 10 | r/min | O | O | O | O | |
| P1-39 | SSPD | Target Motor Speed | 3000 | r/min | O | O | O | O | |
| P1-42 | MBT1 | On Delay Time of Electromagnetic Brake | 0 | ms | O | O | O | O | 6.6.5 |
| P1-43 | MBT2 | OFF Delay Time of Electromagnetic Brake | 0 | ms | O | O | O | O | 6.6.5 |
| P1-54 | PER | Positioning Completed Width | 100 | pulse | O | O | | | - |
| P1-56 | OVW | Output Overload Warning Time | 120 | % | O | O | O | O | - |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

| Communication | | | | | | | | | |
|---------------|------|--------------------------------------|---------|-------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P3-00 | ADR | Communication Address Setting | 1 | N/A | 0 | 0 | 0 | 0 | 8.2 |
| P3-01 | BRT | Transmission Speed | 1 | bps | 0 | 0 | 0 | 0 | 8.2 |
| P3-02 | PTL | Communication Protocol | 0 | N/A | 0 | 0 | 0 | 0 | 8.2 |
| P3-03 | FLT | Transmission Fault Treatment | 0 | N/A | 0 | 0 | 0 | 0 | 8.2 |
| P3-04 | CWD | Communication Time Out Detection | 0 | sec | 0 | 0 | 0 | 0 | 8.2 |
| P3-05 | CMM | Communication Selection | 0 | N/A | 0 | 0 | 0 | 0 | 8.2 |
| P3-06■ | SDI | Digital Input Communication Function | 0 | N/A | 0 | 0 | 0 | 0 | 8.2 |
| P3-07 | CDT | Communication Response Delay Time | 0 | 0.5ms | 0 | 0 | 0 | 0 | - |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

| Diagnosis | | | | | | | | | |
|-----------|------|--|-----------------|-------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P4-00★ | ASH1 | Fault Record (N) | 0 | N/A | 0 | 0 | 0 | 0 | 4.4.1 |
| P4-01★ | ASH2 | Fault Record (N-1) | 0 | N/A | 0 | 0 | 0 | 0 | 4.4.1 |
| P4-02★ | ASH3 | Fault Record (N-2) | 0 | N/A | 0 | 0 | 0 | 0 | 4.4.1 |
| P4-03★ | ASH4 | Fault Record (N-3) | 0 | N/A | 0 | 0 | 0 | 0 | 4.4.1 |
| P4-04★ | ASH5 | Fault Record (N-4) | 0 | N/A | 0 | 0 | 0 | 0 | 4.4.1 |
| P4-05 | JOG | JOG Operation | 20 | r/min | 0 | 0 | 0 | 0 | 4.4.2 |
| P4-06▲■ | FOT | Force Output Control | 0 | N/A | 0 | 0 | 0 | 0 | 4.4.4 |
| P4-07■ | ITST | Input Status or Force Input Control | N/A | N/A | 0 | 0 | 0 | 0 | 4.4.5 |
| P4-08 | PKEY | Digital Keypad Input of Servo Drive | N/A | N/A | 0 | 0 | 0 | 0 | - |
| P4-09★ | MOT | Output Status Display | N/A | N/A | 0 | 0 | 0 | 0 | 4.4.6 |
| P4-10▲ | CEN | Adjustment Function | 0 | N/A | 0 | 0 | 0 | 0 | - |
| P4-11 | SOF1 | Analog Speed Input Drift Adjustment 1 | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-12 | SOF2 | Analog Speed Input Drift Adjustment 2 | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-13 | TOF1 | Analog Torque Drift Adjustment 1 | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-14 | TOF2 | Analog Torque Drift Adjustment 2 | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-15 | COF1 | Current Detector Drift Adjustment (V1 phase) | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-16 | COF2 | Current Detector Drift Adjustment (V2 phase) | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-17 | COF3 | Current Detector Drift Adjustment (W1 phase) | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-18 | COF4 | Current Detector Drift Adjustment (W2 phase) | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-19 | TIGB | IGBT NTC Calibration | Factory setting | N/A | 0 | 0 | 0 | 0 | - |
| P4-20 | DOF1 | Analog Monitor Output Drift Adjustment (CH1) | 0 | mV | 0 | 0 | 0 | 0 | 6.4.4 |
| P4-21 | DOF2 | Analog Monitor Output Drift Adjustment (CH2) | 0 | mV | 0 | 0 | 0 | 0 | 6.4.4 |
| P4-22 | SAO | Analog Speed Input Offset | 0 | mV | | | 0 | | - |
| P4-23 | TAO | Analog Torque Input Offset | 0 | mV | | | | 0 | - |

| Others | | | | | | | | | |
|--|----------|--|---------|-------|--------------|----|---|---|--------------------------------|
| Parameter | Name | Function | Default | Unit | Control Mode | | | | Related Section of User Manual |
| | | | | | Pt | Pr | S | T | |
| P1-31 | Reserved | | | | | | | | |
| P1-32 | LSTP | Motor Stop Mode Selection | 0 | N/A | O | O | O | O | - |
| P1-37 | GDR | Ratio of Load Inertia to Servo Motor Inertia | 5.0 | times | O | O | O | O | 6.3.6 |
| P1-52 | RES1 | Regenerative Resistor Value | - | Ohm | O | O | O | O | 6.6.3 |
| P1-53 | RES2 | Regenerative Resistor Capacity | - | Watt | O | O | O | O | 6.6.3 |
| P1-57 | Reserved | | | | | | | | |
| P1-58 | Reserved | | | | | | | | |
| P2-08■ | PCTL | Special Factory Setting | 0 | N/A | O | O | O | O | - |
| P2-30■ | INH | Auxiliary Function | 0 | N/A | O | O | O | O | - |
| P2-34 | SDEV | Overspeed Warning Condition | 5000 | r/min | | | O | | - |
| P2-35 | PDEV | Excessive Error Warning Condition | 30000 | pulse | O | O | | | - |
| P2-51 | SRON | Servo ON | 0 | N/A | O | O | O | O | 12.6 |
| P2-63 | TSCA | Proportion Value Setting | 0 | times | O | O | O | | - |
| P2-65 | GBIT | Special Function | 0 | N/A | O | O | O | | - |
| Parameters for Lexium 23M series only | | | | | | | | | |
| P1-59 | MFLT | Analog Speed Linear Filter | 120 | % | | | O | | - |
| P1-60 | GR7 | High Resolution Electronic Gear Ratio | 7 | - | O | | | | 6.2.3 |
| P1-61 | GR8 | High Resolution Output Pulse Number | 7 | - | O | | | | - |

Explanation of symbols (marked after parameter)

(★) Read-only register.

(▲) Parameter cannot be set when Servo On (when the servo drive is enabled).

(●) Parameter is effective only after the servo drive is restarted (after switching power off and on).

(■) Parameter setting values are not retained when power is off.

7.3 Detailed Parameter Listings

Group 0: PO-xx Monitor Parameters

| PO-00★ | VER | Firmware Version | Communication Addr.: 0000H |
|---------------|------------|-------------------------|-----------------------------------|
|---------------|------------|-------------------------|-----------------------------------|

Default: Factory setting

Related Section: N/A

Applicable Control Mode: ALL

Unit: N/A

Range: N/A

| PO-01★ | ALE | Drive Fault Code | Communication Addr.: 0001H |
|---------------|------------|-------------------------|-----------------------------------|
|---------------|------------|-------------------------|-----------------------------------|

Default: Factory setting

Related Section:

Applicable Control Mode: ALL

Chapter 10

Unit: N/A

Range: 00 ~ 23 (Lexium 23C series)

00 ~ 25 (Lexium 23M series)

Settings:

01: Overcurrent

02: Overvoltage

03: Undervoltage

04: Reserved (Lexium 23C Series)

"Mismatch" error (Lexium 23M Series)

05: Regeneration error

06: Overload

07: Overspeed

08: Abnormal pulse control command

09: Excessive deviation

10: Watch dog fault

11: Position detector fault

12: Adjustment error

13: Emergency stop

14: Reverse limit error

15: Forward limit error

16: IGBT temperature error

17: Memory error

18: DSP communication error

19: Serial communication error

20: Serial communication time out

21: DSP to MCU command write-in error

22: Input power phase loss

23: Pre-overload warning

24: Encoder Error (Lexium 23M Series only)

25: Encoder Error (Lexium 23M Series only)

| PO-02 | STS | Drive Status | Communication Addr.: 0002H |
|-------|--|--------------|----------------------------|
| | Default: 00 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 4.3.5 |
| | Unit: N/A | | |
| | Range: 00 - 16 (Lexium 23C series) | | |
| | 00 - 19 (Lexium 23M series) | | |
| | Settings: | | |
| | 00: Motor feedback pulse number (absolute value) [pulse] | | |
| | 01: Motor feedback rotation number (absolute value) [rev] | | |
| | 02: Pulse counts of pulse command [pulse] | | |
| | 03: Rotation number of pulse command [rev] | | |
| | 04: Position error counts [pulse] | | |
| | 05: Input frequency of pulse command [r/min] (Lexium 23C series) | | |
| | Input frequency of pulse command [Kpps] (Lexium 23M series) | | |
| | 06: Motor speed [r/min] | | |
| | 07: Speed input command [Volt] | | |
| | 08: Speed input command [r/min] | | |
| | 09: Torque input command [Volt] | | |
| | 10: Torque input command [%] | | |
| | 11: Average load [%] | | |
| | 12: Peak load [%] | | |
| | 13: Main circuit voltage [Volt] | | |
| | 14: Ratio of load inertia to motor inertia [time] | | |
| | 15: Motor feedback pulse number (relative value) / Position latch pulse number [pulse] | | |
| | 16: Motor feedback rotation number (relative value) / Position latch rotation number [rev] | | |
| | 17: Reserved (Lexium 23M series only) | | |
| | 18: High resolution pulse number [pulse] (Lexium 23M series only) | | |
| | 19: Absolute pulse number (use Z pulse as home) [pulse] (Lexium 23M series only) | | |

| | | | |
|--------------|------------|------------------------------|-----------------------------------|
| P0-03 | MON | Analog Monitor Output | Communication Addr.: 0003H |
|--------------|------------|------------------------------|-----------------------------------|


Default: 01

Applicable Control Mode: ALL

Unit: N/A

Range: 00 ~ 55

Settings:



AB: (A: CH1; B: CH2)

0: Motor speed (+/-8V / maximum motor speed)

2: Pulse command frequency (+8Volts / 650Kpps) (Lexium 23C series)

Pulse command frequency (+8Volts / 4.5Mpps) (Lexium 23M series)

3: Speed command (+/-8Volts / maximum speed command)

4: Torque command (+/-8Volts / maximum torque command)

5: V_BUS voltage (+/-8Volts / 450V)

Note: For the setting of analog output voltage proportion, refer to the P1-04 and P1-05.

Example:

P0-03 = 01 (CH1 is speed analog output)

Motor speed = (Max. motor speed × V1/8) × P1-04/100, when the output voltage value of CH1 is V1.

| | | | |
|--------------|------------|-------------------------|-----------------------------------|
| P0-04 | CM1 | Status Monitor 1 | Communication Addr.: 0004H |
|--------------|------------|-------------------------|-----------------------------------|

Default: 0

Applicable Control Mode: ALL

Unit: N/A

Range: 0 ~ 16

Settings:

Select the desired drive status through communication setting or the keypad (please refer to P0-02). The drive status can be read from the communication address of this parameter via communication port.

For example:

Set P0-04 to 1 and then all consequent reads of P0-04 will return the motor feedback rotation number in revolution.

| | | | |
|--------------|---|-------------------------|-----------------------------------|
| P0-05 | CM2 | Status Monitor 2 | Communication Addr.: 0005H |
| | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 - 16 Settings: See P0-04 for explanation. | | Related Section: Section 4.3.5 |
| P0-06 | CM3 | Status Monitor 3 | Communication Addr.: 0006H |
| | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 - 16 Settings: See P0-04 for explanation. | | Related Section: Section 4.3.5 |
| P0-07 | CM4 | Status Monitor 4 | Communication Addr.: 0007H |
| | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 - 17 Settings: Select the desired drive status through communication setting or the keypad (please refer to P0-02). The drive status can be read from the communication address of this parameter via communication port. If users set this parameter to 17, the status of DI signal can be read. | | Related Section: Section 4.3.5 |
| P0-08 | CM5 | Status Monitor 5 | Communication Addr.: 0008H |
| | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 - 17 Settings: Select the desired drive status through communication setting or the keypad (please refer to P0-02). The drive status can be read from the communication address of this parameter via communication port. If users set this parameter to 17, the status of DO signal can be read. | | Related Section: Section 4.3.5 |

| | | | |
|---|-------------|---|-----------------------------------|
| P0-09 | MAP0 | Block Data Read / Write Register 0 | Communication Addr.: 0009H |
| Default: 407H | | Related Section: N/A | |
| Applicable Control Mode: ALL | | | |
| Unit: N/A | | | |
| Range: 100H - 417H | | | |
| Settings: | | | |
| Set the register address in HEX that users want to read and write by using the keypad. Users can enter the desired register address (0100H - 0417H) into P0-09 to P0-16 (0009H - 0010H). Then, users can read and write up to 8 continuous specified block data from the communication address 0009H to 0010H through the communication port. | | | |
| For example, if setting P0-09 to 407 by using the keypad, when the users read and write the data from communication address 0009H, it means that the read and write value is the setting value of parameter P4-07. | | | |
| P0-10 | MAP1 | Block Data Read / Write Register 1 | Communication Addr.: 000AH |
| Default: 10FH | | Related Section: N/A | |
| Applicable Control Mode: ALL | | | |
| Unit: N/A | | | |
| Range: 100H - 417H | | | |
| Settings: See P0-09 for explanation. | | | |
| P0-11 | MAP2 | Block Data Read / Write Register 2 | Communication Addr.: 000BH |
| Default: 110H | | Related Section: N/A | |
| Applicable Control Mode: ALL | | | |
| Unit: N/A | | | |
| Range: 100H - 417H | | | |
| Settings: See P0-09 for explanation. | | | |
| P0-12 | MAP3 | Block Data Read / Write Register 3 | Communication Addr.: 000CH |
| Default: 224H | | Related Section: N/A | |
| Applicable Control Mode: ALL | | | |
| Unit: N/A | | | |
| Range: 100H - 417H | | | |
| Settings: See P0-09 for explanation. | | | |

| | | | |
|--------------------------------------|------------------------------|---|-----------------------------------|
| P0-13 | MAP4 | Block Data Read / Write Register 4 | Communication Addr.: 000DH |
| | Default: 111H | | Related Section: N/A |
| | Applicable Control Mode: ALL | | |
| | Unit: N/A | | |
| | Range: 100H ~ 417H | | |
| Settings: See P0-09 for explanation. | | | |
| P0-14 | MAP5 | Block Data Read / Write Register 5 | Communication Addr.: 000EH |
| | Default: 112H | | Related Section: N/A |
| | Applicable Control Mode: ALL | | |
| | Unit: N/A | | |
| | Range: 100H ~ 417H | | |
| Settings: See P0-09 for explanation. | | | |
| P0-15 | MAP6 | Block Data Read / Write Register 6 | Communication Addr.: 000FH |
| | Default: 225H | | Related Section: N/A |
| | Applicable Control Mode: ALL | | |
| | Unit: N/A | | |
| | Range: 100H ~ 417H | | |
| Settings: See P0-09 for explanation. | | | |
| P0-16 | MAP7 | Block Data Read / Write Register 7 | Communication Addr.: 0010H |
| | Default: 109H | | Related Section: N/A |
| | Applicable Control Mode: ALL | | |
| | Unit: N/A | | |
| | Range: 100H ~ 417H | | |
| Settings: See P0-09 for explanation. | | | |


| PO-17★ | SVSTS | SVSTS Servo Output Status Display | Communication Addr.: 000EH |
|--------|--|-----------------------------------|-------------------------------|
| | Default: N/A Applicable Control Mode: ALL Unit: N/A Range: N/A Settings: | | Related Section: Table 7.B |
| | This parameter is used to display the digital output signal of the servo drive. The servo output status display will show in hexadecimal format. | | |
| | Bit0: SRDY (Servo ready) | | |
| | Bit1: SON (Servo On) | | |
| | Bit2: ZSPD (At Zero speed) | | |
| | Bit3: TSPD (At Speed reached) | | |
| | Bit4: TPOS (At Positioning completed) | | |
| | Bit5: TQL (At Torque limit) | | |
| | Bit6: Reserved | | |
| | Bit7: Reserved | | |
| | Bit8: OLW (Output overload warning) | | |
| | Bit9: WARN (Servo warning activated) | | |
| | Bit10: CMDOK (Internal position command completed) | | |
| | Bit11: Reserved | | |
| | Bit12: Reserved | | |
| | Bit13: ALRM (Servo alarm activated) | | |
| | Bit14: BRKR (Electromagnetic brake control) | | |
| | Bit15: HOME (Homing completed) | | |
| | The servo output status display can be monitored through communication also. | | |

Group 1: P1-xx Basic Parameters


| P1-00▲ | PTT | External Pulse Input Type | Communication Addr.: 0100H |
|--------|------------|-------------------------------------|----------------------------|
| | Default: 2 | Applicable Control Mode: Pt | Related Section: |
| | Unit: N/A | Range: 00 - 132 (Lexium 23C series) | Section 6.2.1 |
| | | 00 - 1132 (Lexium 23M series) | |

Settings:

Lexium 23C series:



Lexium 23M series:

● **A: Pulse type**

A=0: AB phase pulse (4x)

A=1: CW + CCW pulse

A=2: Pulse + Direction

Other setting: Reversed

● **B: Input pulse filter**

B=0: 500Kpps








B=1: 200Kpps

B=2: 150Kpps

B=3: 80Kpps

This setting is used to suppress or reduce the chatter caused by the noise, etc. However, if the instant input pulse filter frequency is over high, the frequency that exceeds the setting value will be regarded as noise and filtered.

● C: Logic type

| Pulse Type | 0=Positive Logic | | 1=Negative Logic | |
|-------------------|---|---|--|--|
| | Forward | Reverse | Forward | Reverse |
| AB phase pulse |  |  |  |  |
| CW + CCW pulse |  |  |  |  |
| Pulse + Direction |  |  |  |  |

| Input pulse interface | Max. input pulse frequency |
|-----------------------|----------------------------|
| Line driver | 500Kpps |
| Open collector | 200Kpps |

● D: Source of pulse command

| Setting value | Input pulse interface | Max. input pulse frequency | Remark |
|---------------|----------------------------------|----------------------------|---|
| 0 | Line driver | 500Kpps | CN1 Terminal Identification: PULSE, /PULSE, SIGN, /SIGN |
| | Open collector | 200Kpps | |
| 1 | Line driver for high-speed pulse | 4Mpps | CN1 Terminal Identification: HPULSE, /HPULSE, HSIGN, /HSIGN |

Note: High-speed pulse function (max. input pulse frequency 4Mpps) is for Lexium 23M only.

| | | | |
|--------------|------------|--|-----------------------------------|
| P1-01 | CTL | Control Mode and Output Direction | Communication Addr.: 0101H |
|--------------|------------|--|-----------------------------------|

Default: 00

Related Section:


Applicable Control Mode: ALL

Section 6.1

Unit: pulse (P mode), r/min (S mode), N-m (T mode)

Range: 0 - 1110

Settings:







- A: Control mode settings
- B: Torque output direction settings

Control mode settings:

| | Pt | Pr | S | T | Sz | Tz |
|----|----|----|---|---|----|----|
| 00 | ▲ | | | | | |
| 01 | | ▲ | | | | |
| 02 | | | ▲ | | | |
| 03 | | | | ▲ | | |
| 04 | | | | | ▲ | |
| 05 | | | | | | ▲ |
| 06 | ▲ | | ▲ | | | |
| 07 | ▲ | | | ▲ | | |
| 08 | | ▲ | ▲ | | | |
| 09 | | ▲ | | ▲ | | |
| 10 | | | ▲ | ▲ | | |

Torque output direction settings:

| | 0 | 1 |
|---------|---|---|
| Forward |  CCW |  CW |
| Reverse |  CW |  CCW |

- C=1: When switching to different mode, DIO (P2-10 - P2-22) can be reset to be the default value of the mode you switch to.
- C=0: When switching to different mode, the setting value of DIO (P2-10 - P2-22) will remain the same and will not be changed.

| | | | |
|---------------|-------------|-------------------------------|-----------------------------------|
| P1-02▲ | PSTL | Speed and Torque Limit | Communication Addr.: 0102H |
|---------------|-------------|-------------------------------|-----------------------------------|


Default: 00

Applicable Control Mode: ALL

Unit: N/A


Range: 0 ~ 11

Settings:




- A=0: Disable speed limit function
A=1: Enable speed limit function (It is available in torque mode)


Other: Reserved



- B=0: Disable torque limit function
B=1: Enable torque limit function (It is available in position and speed mode)

Other: Reserved



| | | | |
|--|--|--|-----------------------------------|
| P1-03 | AOUT | Pulse Output Polarity Setting | Communication Addr.: 0103H |
| | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 ~ 1 Settings: | | Related Section: Section 3.3.3 |
|  | | | |
| A: Monitor analog output polarity A=0: MON1(+), MON2(+) A=1: MON1(+), MON2(-) A=2: MON1(-), MON2(+) A=3: MON1(-), MON2(-) B: Position pulse output polarity B=0: Forward output B=1: Reverse output | | | |
| P1-04 | MON1 | Analog Monitor Output Proportion 1 (CH1) | Communication Addr.: 0104H |
| | Default: 100 Applicable Control Mode: ALL Unit: % (full scale) Range: 0 ~ 100 | | Related Section: Section 6.4.4 |
| P1-05 | MON2 | Analog Monitor Output Proportion 2 (CH2) | Communication Addr.: 0105H |
| | Default: 100 Applicable Control Mode: ALL Unit: % (full scale) Range: 0 ~ 100 | | Related Section: Section 6.4.4 |
| P1-06 | SFLT | Accel / Decel Smooth Constant of Analog Speed Command (Low-pass Filter) | Communication Addr.: 0106H |
| | Default: 0 Applicable Control Mode: S Unit: ms Range: 0 ~ 1000 (0: Disabled) | | Related Section: Section 6.3.3 |

| | | | |
|--------------|--|---|-----------------------------------|
| P1-07 | TFLT | Smooth Constant of Analog Torque Command (Low-pass Filter) | Communication Addr.: 0107H |
| | Default: 0 Applicable Control Mode: T Unit: ms Range: 0 ~ 1000 (0: Disabled) | | Related Section: Section 6.4.3 |
| P1-08 | PFLT | Smooth Constant of Position Command (Low-pass Filter) | Communication Addr.: 0108H |
| | Default: 0 Applicable Control Mode: Pt Unit: 10ms Range: 0 ~ 1000 (0: Disabled) | | Related Section: Section 6.2.6 |
| P1-09 | SP1 | 1st Speed Command or Limit | Communication Addr.: 0109H |
| | Default: 100 Applicable Control Mode: S, T Unit: r/min Range: -5000 ~ +5000 Settings: 1st Speed Command In Speed mode, this parameter is used to set speed 1 of internal speed command. For the decimal place setting of internal speed command, please refer to P2-63. 1st Speed Limit In Torque mode, this parameter is used to set speed limit 1 of internal speed command. | | Related Section: Section 6.3.1 |
| P1-10 | SP2 | 2nd Speed Command or Limit | Communication Addr.: 010AH |
| | Default: 200 Applicable Control Mode: S, T Unit: r/min Range: -5000 ~ +5000 Settings: 2nd Speed Command In Speed mode, this parameter is used to set speed 2 of internal speed command. For the decimal place setting of internal speed command, please refer to P2-63. 2nd Speed Limit In Torque mode, this parameter is used to set speed limit 2 of internal speed command. | | Related Section: Section 6.3.1 |

| | | | |
|--------------|---|------------------------------------|-----------------------------------|
| P1-11 | SP3 | 3rd Speed Command or Limit | Communication Addr.: 010BH |
| | Default: 300 Applicable Control Mode: S, T Unit: r/min Range: -5000 ~ +5000 Settings: 3rd Speed Command In Speed mode, this parameter is used to set speed 3 of internal speed command. For the decimal place setting of internal speed command, please refer to P2-63. 3rd Speed Limit In Torque mode, this parameter is used to set speed limit 3 of internal speed command. | | Related Section: Section 6.3.1 |
| P1-12 | TQ1 | 1st Torque Command or Limit | Communication Addr.: 010CH |
| | Default: 100 Applicable Control Mode: T, P/S Unit: % Range: -300 ~ +300 Settings: 1st Torque Command In Torque mode, this parameter is used to set torque 1 of internal torque command. 1st Torque Limit In Position and Speed mode, this parameter is used to set torque limit 1 of internal torque command. Digital output signal TQL is activated when the drive has detected that the motor has reached the torques limits set by either the parameters P1-12 ~ P1-14 of via an external analog voltage. | | Related Section: Section 6.4.1 |
| P1-13 | TQ2 | 2nd Torque Command or Limit | Communication Addr.: 010DH |
| | Default: 100 Applicable Control Mode: T, P/S Unit: % Range: -300 ~ +300 Settings: 2nd Torque Command In Torque mode, this parameter is used to set torque 2 of internal torque command. 2nd Torque Limit In Position and Speed mode, this parameter is used to set torque limit 2 of internal torque command. Digital output signal TQL is activated when the drive has detected that the motor has reached the torques limits set by either the parameters P1-12 ~ P1-14 of via an external analog voltage. | | Related Section: Section 6.4.1 |

| | | | |
|--------------|--|--|-----------------------------------|
| P1-14 | TQ3 | 3rd Torque Command or Limit | Communication Addr.: 010EH |
| | Default: 100 Applicable Control Mode: T, P/S Unit: % Range: -300 ~ +300 Settings: | | Related Section: Section 6.4.1 |
| | 3rd Speed Command In Torque mode, this parameter is used to set torque 3 of internal torque command. | | |
| | 3rd Speed Limit In Position and Speed mode, this parameter is used to set torque limit 3 of internal torque command. Digital output signal TQL is activated when the drive has detected that the motor has reached the torques limits set by either the parameters P1-12 - P1-14 of via an external analog voltage. | | |
| P1-15 | PO1H | 1st Position Command for Rotation | Communication Addr.: 010FH |
| | Default: 0 Applicable Control Mode: Pr Unit: rev Range: -30000 ~ +30000 Settings: | | Related Section: Section 6.2.2 |
| | This parameter is used to set rotation cycle number of internal position 1. | | |
| P1-16 | PO1L | 1st Position Command for Pulse | Communication Addr.: 0110H |
| | Default: 0 Applicable Control Mode: Pr Unit: pulse Range: +/-max. cnt/rev Settings: | | Related Section: Section 6.2.2 |
| | This parameter is used to set rotation pulse number of internal position 1. $\text{Stroke1} = \text{PO1H} \times (\text{cnt/rev}) + \text{PO1L}$ | | |

| | | | |
|--------------|--|--|-----------------------------------|
| P1-17 | PO2H | 2nd Position Command for Rotation | Communication Addr.: 0111H |
| | Default: 0 Applicable Control Mode: Pr Unit: rev Range: -30000 ~ +30000 Settings: This parameter is used to set rotation cycle number of internal position 2. | | Related Section: Section 6.2.2 |
| P1-18 | PO2L | 2nd Position Command for Pulse | Communication Addr.: 0112H |
| | Default: 0 Applicable Control Mode: Pr Unit: pulse Range: +/-max. cnt/rev Settings: This parameter is used to set rotation pulse number of internal position 2. $Stroke2 = PO2H \times (cnt/rev) + PO2L$ | | Related Section: Section 6.2.2 |
| P1-19 | PO3H | 3rd Position Command for Rotation | Communication Addr.: 0113H |
| | Default: 0 Applicable Control Mode: Pr Unit: rev Range: -30000 ~ +30000 Settings: This parameter is used to set rotation cycle number of internal position 3. | | Related Section: Section 6.2.2 |
| P1-20 | PO3L | 3rd Position Command for Pulse | Communication Addr.: 0114H |
| | Default: 0 Applicable Control Mode: Pr Unit: pulse Range: +/-max. cnt/rev Settings: This parameter is used to set rotation pulse number of internal position 3. $Stroke3 = PO3H \times (cnt/rev) + PO3L$ | | Related Section: Section 6.2.2 |

| | | | |
|--------------|--|--|-----------------------------------|
| P1-21 | PO4H | 4th Position Command for Rotation | Communication Addr.: 0115H |
| | Default: 0 Applicable Control Mode: Pr Unit: rev Range: -30000 ~ +30000 Settings: This parameter is used to set rotation cycle number of internal position 4. | | Related Section: Section 6.2.2 |
| P1-22 | PO4L | 4th Position Command for Pulse | Communication Addr.: 0116H |
| | Default: 0 Applicable Control Mode: Pr Unit: pulse Range: +/-max. cnt/rev Settings: This parameter is used to set rotation pulse number of internal position 4. $Stroke4 = PO4H \times (cnt/rev) + PO4L$ | | Related Section: Section 6.2.2 |
| P1-23 | PO5H | 5th Position Command for Rotation | Communication Addr.: 0117H |
| | Default: 0 Applicable Control Mode: Pr Unit: rev Range: -30000 ~ +30000 Settings: This parameter is used to set rotation cycle number of internal position 5. | | Related Section: Section 6.2.2 |
| P1-24 | PO5L | 5th Position Command for Pulse | Communication Addr.: 0118H |
| | Default: 0 Applicable Control Mode: Pr Unit: pulse Range: +/-max. cnt/rev Settings: This parameter is used to set rotation pulse number of internal position 5. $Stroke5 = PO5H \times (cnt/rev) + PO5L$ | | Related Section: Section 6.2.2 |

| | | | |
|---|-----------------------------|--|-----------------------------------|
| P1-25 | PO6H | 6th Position Command for Rotation | Communication Addr.: 0119H |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: Pr | | Section 6.2.2 |
| | Unit: rev | | |
| | Range: -30000 ~ +30000 | | |
| Settings: | | | |
| This parameter is used to set rotation cycle number of internal position 6. | | | |
| P1-26 | PO6L | 6th Position Command for Pulse | Communication Addr.: 011AH |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: Pr | | Section 6.2.2 |
| | Unit: pulse | | |
| | Range: +/-max. cnt/rev | | |
| Settings: | | | |
| This parameter is used to set rotation pulse number of internal position 6. | | | |
| Stroke6 = PO6H x (cnt/rev) + PO6L | | | |
| P1 - 27 | PO7H | 7th Position Command for Rotation | Communication Addr.: 011BH |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: Pr | | Section 6.2.2 |
| | Unit: rev | | |
| | Range: -30000 ~ +30000 | | |
| Settings: | | | |
| This parameter is used to set rotation cycle number of internal position 7. | | | |
| P1-28 | PO7L | 7th Position Command for Pulse | Communication Addr.: 011CH |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: Pr | | Section 6.2.2 |
| | Unit: pulse | | |
| | Range: +/-max. cnt/rev | | |
| Settings: | | | |
| This parameter is used to set rotation pulse number of internal position 7. | | | |
| Stroke7 = PO7H x (cnt/rev) + PO7L | | | |

| | | | |
|--------------|-------------|--|-----------------------------------|
| P1-29 | PO8H | 8th Position Command for Rotation | Communication Addr.: 011DH |
|--------------|-------------|--|-----------------------------------|

Default: 0

Applicable Control Mode: Pr

Unit: rev

Range: -30000 ~ +30000

Settings:

This parameter is used to set rotation cycle number of internal position 8.

Related Section:

Section 6.2.2

| | | | |
|--------------|-------------|---------------------------------------|-----------------------------------|
| P1-30 | PO8L | 8th Position Command for Pulse | Communication Addr.: 011EH |
|--------------|-------------|---------------------------------------|-----------------------------------|

Default: 0

Applicable Control Mode: Pr

Unit: pulse

Range: +/-max. cnt/rev

Settings:

This parameter is used to set rotation pulse number of internal position 8.

$Stroke8 = PO8H \times (cnt/rev) + PO8L$

Related Section:

Section 6.2.2

| | | | |
|----------------|-----------------|--|--|
| P1 - 31 | Reserved | | |
|----------------|-----------------|--|--|

| | | | |
|--------------|-------------|----------------------------------|-----------------------------------|
| P1-32 | LSTP | Motor Stop Mode Selection | Communication Addr.: 0120H |
|--------------|-------------|----------------------------------|-----------------------------------|

Default: 0

Applicable Control Mode: ALL

Unit: N/A


Range: 0 ~ 11

Settings:

This parameter is used to select servo motor stop mode.

When a fault (servo alarm) occurs (except for CWL, CCWL, EMGS and serial communication error), it is used to set servo motor stop mode.

Related Section: N/A



- A=0: Stop instantly
- A=1: Decelerate to stop
- B=0: Use dynamic brake when Servo Off (when the servo drive is Off).
- B=1: Allow servo motor to coast to stop when Servo Off (when the servo drive is Off).

| | | | |
|--------------|---|-----------------------------------|---|
| P1-33 | POSS | Position Control Mode (Pr) | Communication Addr.: 0121H |
| | Default: 0 Applicable Control Mode: Pr Unit: N/A Range: 0 - 6 Settings: This parameter determines the specific type of position control for Pr mode with the internal INDEX number. (Please refer to Chapter 6 and Chapter 12 for explanation and examples.) 0: Absolute positioning mode 1: Incremental positioning mode 2: Forward operation feed step mode 3: Reverse operation feed step mode 4: Shortest path feed step mode 5: Continuous auto-running positioning mode (Absolute) 6: Continuous auto-running positioning mode (Incremental) 7: One-cycle auto-running positioning mode (Absolute) 8: One-cycle auto-running positioning mode (Incremental) This function when changed from absolute to incremental or incremental to absolute only gets registered in the drive after switching power off and on. | | Related Section: Section 6.2.2 |
| P1-34 | TACC | Acceleration Time | Communication Addr.: 0122H |
| | Default: 200 Applicable Control Mode: Pr, S Unit: ms Range: 1 - 20000 Settings: 1st to 3rd step acceleration time. It is used to determine the acceleration time to accelerate from 0 to its rated motor speed. (When P1-36 is set to 0: Accel/Decel function is disabled, i.e. P1-34, P1-35 is disabled.) | | Related Section: P1-35, P1-36, Section 6.3.3 |
| P1-35 | TDEC | Deceleration Time | Communication Addr.: 0123H |
| | Default: 200 Applicable Control Mode: Pr, S Unit: ms Range: 1 - 20000 Settings: 1st to 3rd step deceleration time. It is used to determine the deceleration time to decelerate from its rated motor speed to 0. (When P1-36 is set to 0: Accel/Decel function is disabled, i.e. P1-34, P1-35 is disabled.) | | Related Section: P1-34, P1-36, Section 6.3.3 |

| | | | |
|--------------|------------|-----------------------------|-----------------------------------|
| P1-36 | TSL | Accel /Decel S-curve | Communication Addr.: 0124H |
|--------------|------------|-----------------------------|-----------------------------------|

Pr mode Default: 20 (See Note 2)

Related Section:

Other mode Default: 0

P1-34, P1-35,

Unit: ms

Section 6.2.4 (Pr mode),


Range: 0 ~ 10000 (0: Disabled)

Section 6.3.3 (S mode)

Settings:

This parameter is used to make the motor run more smoothly when startup and windup. Using this parameter can improve the motor running stability.

Speed



TSL: P1-36, Accel /Decel S-curve

TACC: P1-34, Acceleration time

TDEC: P1-35, Deceleration time

Total acceleration time = TACC + TSL

Total deceleration time = TDEC + TSL

Note:

- 1) If the control of the servo motor is achieved via internal parameters, the command curve should be defined by the users. Therefore, when the command source is internal parameter, ensure that the setting value of P1-36 is not set to 0 or the servo motor will not accelerate or decelerate during operation.
- 2) So if users change the control mode to Pr mode and switching power off and on, the servo drive of parameter P1-36 will auto set the value to 20.

| | | | |
|--------------|------------|---|-----------------------------------|
| P1-37 | GDR | Ratio of Load Inertia to Servo Motor Inertia | Communication Addr.: 0125H |
|--------------|------------|---|-----------------------------------|

Default: 5.0 (Lexium 23C series) or 0.00 (Lexium 23M series)

Related Section:

Section 6.3.6

Applicable Control Mode: ALL

Unit: times

Range: 0 ~ 200.0

Settings:


Ratio of load inertia to servo motor inertia: (J_{load} / J_{motor})

| | | | |
|---------------|--|---|--|
| P1-38 | ZSPD | Zero Speed Range Setting | Communication Addr.: 0126H |
| | Default: 10 Applicable Control Mode: ALL Unit: r/min Range: 0 - 200 Settings: This parameter is used to set output range of zero speed signal (ZSPD). ZSPD is activated when the drive senses the motor is equal to or below the Zero Speed Range setting as defined in parameter P1-38. For Example, at default ZSPD will be activated when the drive detects the motor rotating at speed at or below 10 r/min. ZSPD will remain activated until the motor speed increases above 10 r/min. | | Related Section: N/A |
| P1-39 | SSPD | Target Motor Speed | Communication Addr.: 0127H |
| | Default: 3000 Applicable Control Mode: ALL Unit: r/min Range: 0 - 5000 Settings: When target motor speed reaches its preset value, digital output (TSPD) is enabled. When the forward and reverse speed of servo motor is equal and higher than the setting value, the motor will reach the target motor speed, and then TSPD signal will output. TSPD is activated once the drive has detected the motor has reached the Target Motor Speed setting as defined in parameter P1-39. TSPD will remain activated until the motor speed drops below the Target Motor Speed. | | Related Section: N/A |
| P1-40▲ | VCM | Max. Analog Speed Command or Limit | Communication Addr.: 0128H |
| | Default: rated speed Applicable Control Mode: S/T Unit: r/min Range: 0 - 10000 Settings: In Speed mode , this parameter is used to set the speed at the maximum input voltage (10V) of the analog speed command. In Torque mode , this parameter is used to set the speed at the maximum input voltage (10V) of the analog speed limit. For example, in speed mode, if P1-40 is set to 3000 and the input voltage is 10V, it indicates that the speed command is 3000 r/min. If P1-40 is set to 3000, but the input voltage is changed to 5V, then the speed command is changed to 1500 r/min. $\text{Speed command} / \text{limit} = \text{Input voltage} \times \text{setting} / 10$ | | Related Section: Section 6.3.4, P1-55 |

| P1-41▲ | TCM | Max. Analog Torque Command or Limit | Communication Addr.: 0129H |
|--------|---|-------------------------------------|--------------------------------|
| | Default: 100 Applicable Control Mode: ALL Unit: % Range: 0 - 1000 Settings: In Torque mode , this parameter is used to set the output torque at maximum input voltage (10V) of analog torque command. In Position and Speed mode , this parameter is used to set output torque at maximum input voltage (10V) of analog torque limit For example, in torque mode, if P1-41 is set to 100 and the input voltage is 10V, it indicates that the torque command is 100% rated torque. If P1-41 is set to 100, but the input voltage is changed to 5V, then the torque command is changed to 50% rated torque. Torque command / limit = Input voltage x setting/10 (%) | | Related Section: Section 6.4.4 |


| P1-42 | MBT1 | On Delay Time of Electromagnetic Brake | Communication Addr.: 012AH |
|-------|--|--|---|
| | Default: 0 Applicable Control Mode: ALL Unit: ms Range: 0 - 1000 Settings: Used to set the period of time between when the servo drive is On (Servo On) and when electromagnetic brake output signal (BRKR) is activated. | | Related Section: P1-43, Section 6.5.5 BRKR(08) in Table 7.B |

| P1-43 | MBT2 | OFF Delay Time of Electromagnetic Brake | Communication Addr.: 012BH |
|-------|--|---|---|
| | Default: 0 Applicable Control Mode: ALL Unit: ms Range: 0 - 1000 Settings: Used to set the period of time between when the servo drive is Off (Servo Off) and when electromagnetic brake output signal (BRKR) is inactivated. | | Related Section: P1-43, Section 6.5.5 BRKR(08) in Table 7.B |

**Note:**

- 1) When MBT2 delay time has not finished and motor speed is lower than the setting value of P1-38, electromagnetic brake interlock signal (BRKR) is closed.
- 2) When MBT2 delay time has finished and motor speed is still higher than the setting value of P1-38, electromagnetic brake interlock signal (BRKR) is closed.

| P1-44▲ | GR1 | Electronic Gear Ratio (1st Numerator) (N1) | Communication Addr.: 012CH |
|--------|-----|--|-----------------------------------|
| | | Default: 1 Applicable Control Mode: Pt, Pr Unit: pulse Range: 1 ~ 32767 Settings: Multiple-step electronic gear numerator setting. Please refer to P2-60-P2-62. | Related Section: Section 6.2.5 |

| P1-45▲ | GR2 | Electronic Gear Ratio (Denominator) | Communication Addr.: 012DH |
|--------|-----|--|--|
| | | Default: 1 Applicable Control Mode: Pt, Pr Unit: pulse Range: 1 ~ 32767 Settings: Electronic gear denominator setting. Please set electronic gear ratio when the servo drive is Off. As the wrong setting may cause motor to run chaotically (out of control) and it may lead to personnel injury, therefore, ensure to observe the following rule when setting P1-44, P1-45. The electronic gear ratio setting (Please also see P1-44, P2-60 ~ P2-62): <div style="text-align: center; margin: 10px 0;">  <p style="margin: 0;"> f_1 → $\frac{N}{M}$ → Position command $f_2 = f_1 \times \frac{N}{M}$ </p> </div> | Related Section: Section 6.2.5 f1: Pulse input f2: Position command N: Numerator 1, 2, 3, 4, the setting value of P1-44 or P2-60 ~ P2-63 M: Denominator, the setting value of P1-45 The electronic gear ratio setting range must be within: $1/50 < N/M < 200$. |

| | | | |
|---------------|------------|------------------------------------|-----------------------------------|
| P1-46▲ | GR3 | Encoder Output Pulse Number | Communication Addr.: 012EH |
|---------------|------------|------------------------------------|-----------------------------------|

Default: 1

Related Section: N/A

Applicable Control Mode: ALL

Unit: pulse

Range: 1 ~ 125 (with B=0)

10020 ~ 12500 (with B=1)

Settings:



This parameter is used to set the pulse numbers of encoder outputs per motor revolution.

Lexium 23C series:

A: Range of the pulse numbers or the pulse dividing ratio of the encoder outputs

- Range of the setting value: 1 ~ 125 (with B=0) or 20 ~ 2500 (with B=1)

B: Pulse dividing ratio function selection

- When B=0, the setting value A represents the pulse dividing ratio, which is equal to 2500/A. At this time, the range of the setting value A is 1 ~ 125.

For example:

If A=2 and B=0, i.e. P1-46 is set to 2, the pulse dividing ratio is equal to 2500/2 = 1250.

It indicates that the pulse numbers of encoder outputs per motor revolution = 1250 pulses (The encoder will output 1250 pulses per motor revolution)

If A=5 and B=0, i.e. P1-46 is set to 5, the pulse dividing ratio is equal to 2500/5 = 500.

It indicates that the pulse numbers of encoder outputs per motor revolution = 500 pulses (The encoder will output 500 pulses per motor revolution)

- When B=1, the setting value A directly represents the pulse numbers of encoder outputs per motor revolution. At this time, the range of the setting value A is 20 ~ 2500.

If A=1250 and B=1, i.e. P1-46 is set to 1250, the pulse numbers of encoder outputs per motor revolution = 1250 pulses (The encoder will output 1250 pulses per motor revolution)

If A=500 and B=1, i.e. P1-46 is set to 500, the pulse numbers of encoder outputs per motor revolution = 500 pulses (The encoder will output 500 pulses per motor revolution)

Lexium 23M series:

A: Range of the pulse numbers or the pulse dividing ratio of the encoder outputs

- Range of the setting value: 1 ~ 125 (with B=0) or 20 ~ 2500 (with B=1)

B: Pulse dividing ratio function selection

- When B=0, the range of the setting value A is 1 ~ 125, the pulse numbers of

encoder outputs per motor revolution = $\frac{2500}{A} \times \frac{2^7}{2^{P1-61}}$ ($1 \leq A \leq 125$)

For example:

If A=2 and B=0, i.e. P1-46 is set to 2, and P1-61 is set to 7 (Default), the pulse

numbers of encoder outputs per motor revolution $\frac{2500}{2} \times \frac{2^7}{2^7} = 1250$

It indicates that the encoder will output 1250 pulses per motor revolution.

- When B=1, the range of the setting value A is 20 - 2500, the pulse numbers

of encoder outputs per motor revolution $= A \times \frac{2^7}{2^{P1-61}}$ ($1 \leq A \leq 2500$)


If A=500 and B=1, i.e. P1-46 is set to 10500, and P1-61 is set to 7 (Default), the pulse

numbers of encoder outputs per motor revolution $(500) \times \frac{2^7}{2^7} = 500$

It indicates that the encoder will output 500 pulses per motor revolution.

Note:

- 1) The default setting of parameter P1-61 is 7.
- 2) The max. frequency for pulse output is 500Kpps.

| P1-47 | HMOV | Homing Mode | Communication Addr.: 012FH |
|-------|---|-------------|----------------------------|
| | Default: 00 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 12.8 |
| | Unit: N/A | | |
| | Range: 00 - 1225 | | |
| | Settings: | | |
| |  | | |
| | <ul style="list-style-type: none"> ● A=0: Forward homing (CCWL as "Home") ● A=1: Reverse homing (CWL as "Home") ● A=2: Forward homing (ORGP as "Home") ● A=3: Reverse homing (ORGP as "Home") ● A=4: Forward to find Z-phase pulse and regard Z-phase pulse as "Home" ● A=5: Reverse to find Z-phase pulse and regard Z-phase pulse as "Home" ● B=0: Return to find Z-phase pulse during homing ● B=1: Do not return and go forward to find Z-phase pulse during homing ● B=2: Positioning at home sensor position or Z-phase pulse during homing (it only can be used when A=2, 3, 4 or 5) ● C=0: Disable homing function. ● C=1: Enable homing function automatically after power supplies to the servo drive. | | |

- C=2: Enable homing function by SHOM.
- D=0: After detecting "Home", the motor will decelerate and return to "Home".
- D=1: After detecting "Home", the motor will decelerate and stop in the forward direction.
- Other: Reserved

Example:

Power supplies to the servo drive, after servo on, activate SHOM signal. Then, immediately perform the homing function and use ORGP as "Home".

1: Refer to P1-01 for forward and reverse direction

2: To avoid that errors may occur, please perform the settings for CWL and CCWL and enable the function of SHOM first (refer to Table 7.A and P2-10 ~ P2-17).

Then, use with the external limit switches and connect them to the corresponding input contact. If the settings are incorrect or there is no corresponding external limit switch, the drive and motor may not work normally.


3: Set the value of P1-47 to 203.

4: Use external signal to enable the function of SHOM. Then, the drive will command the motor to move to "Home". When ORGP (reference "Home" sensor) is searched, the motor will return in 2nd speed setting, and reverse to find the nearest Z-phase pulse and regard it as "Home".

| | | | |
|--------------|--------------|---|-----------------------------------|
| P1-48 | HSPD1 | 1st Speed Setting of High Speed Homing | Communication Addr.: 0130H |
|--------------|--------------|---|-----------------------------------|

Default: 1000
 Applicable Control Mode: ALL
 Unit: r/min
 Range: 1 ~ 2000
 Settings:

Related Section:
 Section 12.8



| | | | |
|--------------|--------------|--|-----------------------------------|
| P1-49 | HSPD2 | 2nd Speed Setting of Low Speed Homing | Communication Addr.: 0131H |
|--------------|--------------|--|-----------------------------------|

Default: 50
 Applicable Control Mode: ALL
 Unit: r/min
 Range: 1 ~ 500
 Settings:
 Please refer to P1-48.

Related Section:
 Section 12.8

| | | | |
|--------------|-------------|--------------------------------------|-----------------------------------|
| P1-50 | HOF1 | Homing Offset Rotation Number | Communication Addr.: 0132H |
|--------------|-------------|--------------------------------------|-----------------------------------|

Default: 0
 Applicable Control Mode: ALL
 Unit: rev
 Range: -30000 ~ +30000
 Settings:
 Please refer to P1-51.

Related Section:
 Section 12.8

| | | | |
|--------------|-------------|-----------------------------------|-----------------------------------|
| P1-51 | HOF2 | Homing Offset Pulse Number | Communication Addr.: 0133H |
|--------------|-------------|-----------------------------------|-----------------------------------|

Default: 0
 Applicable Control Mode: ALL
 Unit: pulse
 Range: +/-max. cnt/rev

Settings:

When the value of HOF1, HOF2 (P1-50, P1-51) is set to 0, "Home" will be determined as Z-phase pulse or ORGP according to the setting of P1-47. If the value of HOF1, HOF2 (P1-50, P1-51) is not 0, "Home" will be determined as Z-phase pulse or ORGP plus one offset pulse as new "Home" ($HOF1 \times 10000 + HOF2$).

Related Section:
 Section 12.8

| | | | |
|--------------|-------------|------------------------------------|-----------------------------------|
| P1-52 | RES1 | Regenerative Resistor Value | Communication Addr.: 0134H |
|--------------|-------------|------------------------------------|-----------------------------------|

Default: -
 Applicable Control Mode: ALL
 Unit: Ohm
 Range: 10 ~ 750 (Lexium 23C series)
 5 ~ 750 (Lexium 23M series)

Settings:

Lexium 23C series

| Model | Default |
|-----------------|---------|
| 1.5kW and below | 40 |
| above 1.5kW | 40 |

Lexium 23M series

| Model | Default |
|-----------------|---------|
| 4.5kW | 20 |
| 5.5kW and above | 15 |

| P1-53 | RES2 | Regenerative Resistor Capacity | Communication Addr.: 0135H | | | | | | |
|---|--|---|-----------------------------------|---------|-----------------|-----|-----------------|-----|--|
| | Default: - Applicable Control Mode: ALL Unit: Watt Range: 30 ~ 1000 (Lexium 23C series) 0 ~ power of the drive (Lexium 23M series) | | Related Section: Section 6.6.3 | | | | | | |
| Settings: | | | | | | | | | |
| Lexium 23C series | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Model</th> <th>Default</th> </tr> </thead> <tbody> <tr> <td>1.5kW and below</td> <td>60</td> </tr> <tr> <td>above 1.5kW</td> <td>120</td> </tr> </tbody> </table> | Model | Default | 1.5kW and below | 60 | above 1.5kW | 120 | |
| Model | Default | | | | | | | | |
| 1.5kW and below | 60 | | | | | | | | |
| above 1.5kW | 120 | | | | | | | | |
| Lexium 23M series | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Model</th> <th>Default</th> </tr> </thead> <tbody> <tr> <td>4.5kW</td> <td>100</td> </tr> <tr> <td>5.5kW and above</td> <td>0</td> </tr> </tbody> </table> | Model | Default | 4.5kW | 100 | 5.5kW and above | 0 | |
| Model | Default | | | | | | | | |
| 4.5kW | 100 | | | | | | | | |
| 5.5kW and above | 0 | | | | | | | | |
| P1-54 | PER | Positioning Completed Width | Communication Addr.: 0136H | | | | | | |
| | Default: 100 Applicable Control Mode: Pt , Pr Unit: pulse (Lexium 23C series, Pr mode of Lexium 23M series) 1/10000 rev. (Pt mode of Lexium 23M series) Range: 0 ~ 10000 | | Related Section: N/A | | | | | | |
| Settings: | | | | | | | | | |
| In Pt mode, when the error pulse numbers is less than the setting value of parameter P1-54, TPOS (At positioning completed signal) will be activated. In Pr mode, when the difference in pulse number between the target position and the actual position is less than the setting value of parameter P1-54, TPOS (At positioning completed signal) will be activated. | | | | | | | | | |
| P1-55 | MSPD | Maximum Speed Limit | Communication Addr.: 0137H | | | | | | |
| | Default: rated speed Applicable Control Mode: ALL Unit: r/min Range: 0 ~ Max. speed | | Related Section: N/A | | | | | | |
| Settings: | | | | | | | | | |
| This parameter is used to set maximum motor speed. The default setting is rated speed. | | | | | | | | | |

| | | | |
|--------------|------------|-------------------------------------|-----------------------------------|
| P1-56 | OVW | Output Overload Warning Time | Communication Addr.: 0138H |
|--------------|------------|-------------------------------------|-----------------------------------|

Default: 120

Related Section: N/A

Applicable Control Mode: ALL

Unit: %

Range: 0 - 120

Settings:

This parameter is used to set output overload time.

If the setting value of parameter P1-56 is set to 0 ~ 100, the function of parameter P1-56 is enabled. When the motor has reached the output overload time set by parameter P1-56, the motor will send a warning to the drive. After the drive has detected the warning, the DO signal OLW will be activated.

If the setting value of parameter P1-56 exceeds 100, the function of parameter P1-56 is disabled. **tOL** = Permissible Time for Overload x the setting value of parameter P1-56

When overload accumulated time (continuously overload time) exceeds the value of **tOL**, the overload warning signal will output, i.e. DO signal, OLW will be ON. However, if the accumulated overload time (continuous overload time) exceeds the permissible time for overload, the overload alarm (ALE06) will occur.

For example:

If the setting value of parameter P1-56 (Output Overload Warning Time) is 60%, when the permissible time for overload exceeds 8 seconds at 200% rated output, the overload fault (ALE06) will be detected and shown on the LED display.

At this time, **tOL** = 8 x 60% = 4.8 seconds

Result:


When the drive output is at 200% rated output and the drive is continuously overloaded for 4.8 seconds, the overload warning signal will be ON (DO code is 10, i.e. DO signal OLW will be activated) and the overload warning (ALE23) will be displayed. If the drive is continuously overloaded for 8 seconds, the overload alarm will be detected and shown on the LED display (ALE06). Then, Servo Fault signal will be ON (DO signal ALRM will be activated).

| | | |
|--------------|-----------------|-----------------------------------|
| P1-57 | Reserved | Communication Addr.: 0139H |
|--------------|-----------------|-----------------------------------|

| | | |
|--------------|-----------------|-----------------------------------|
| P1-58 | Reserved | Communication Addr.: 013AH |
|--------------|-----------------|-----------------------------------|

| | | | |
|--------------|-------------|-----------------------------------|-----------------------------------|
| P1-59 | MFLT | Analog Speed Linear Filter | Communication Addr.: 013BH |
|--------------|-------------|-----------------------------------|-----------------------------------|

Default: 0
 Applicable Control Mode: S
 Unit: 0.1ms
 Range: 0 ~ 40
 Settings:
 This function is for Lexium 23M series only. This parameter is used to eliminate the noise generated during the operation when the host (external) controller sends the step analog voltage speed command. If the setting value of parameter P1-59 is set to the step holding time, it can facilitate the smooth operation of the motor very effectively.



| | | | |
|--------------|------------|--|-----------------------------------|
| P1-60 | GR7 | High Resolution Electronic Gear Ratio | Communication Addr.: 013CH |
|--------------|------------|--|-----------------------------------|

Default: 7
 Applicable Control Mode: Pt
 Unit: -
 Range: 0 ~ 7
 Settings:
 This function is for Lexium 23M series only. For the models which encoder resolution is 1280000 pulses per motor revolution, using this parameter can enhance the resolution for positioning. The default setting of this parameter is 7. When the ratio of Electronic Gear Numerator to Electronic Gear Denominator is equal to 1 (1:1), each pulse command corresponds to 1/10000 rev. per motor revolution. When P1-60 is set to 0 and the ratio of Electronic Gear Numerator to Electronic Gear Denominator is also equal to 1 (1:1), each pulse command corresponds to 1/1280000 rev. per motor revolution.

| | | | |
|----------------|--|--|---|
| P1-61 | GR8 | High Resolution Output Pulse Number | Communication Addr.: 013DH |
| | Default: 7 Applicable Control Mode: Pt Unit: - Range: 0 ~ 7 Settings: This function is for Lexium 23M series only. Please refer to P1-46 for explanation. | | Related Section: N/A |
| P1-62 | COKT | Delay Time of Internal Position Command Completed Output Signal | Communication Addr.: 013EH |
| | Default: 0 Applicable Control Mode: Pr Unit: ms Range: 0 ~ 200 Settings: This parameter is used to delay the output time of digital output, CMDOK (Internal position command completed output) when the servo drive has detected the internal position command has been completed. If this parameter is set to 0, when DO ZSPD=1, the internal position command which is triggered by DI CTRG will be accepted. If this parameter is not set to 0, when DO CMDOK=1, the internal position command which is triggered by DI CTRG will be accepted. Please see DO CMDOK(12) in Table 7.B for explanation. | | Related Section: DO CMDOK(12) in Table 7.B |
| P1 - 63 | Reserved | | Communication Addr.: 013FH |
| P1 - 64 | Reserved | | Communication Addr.: 0140H |

Group 2: P2-xx Extension Parameters

| | | | |
|--------------|--|--|-----------------------------------|
| P2-00 | KPP | Proportional Position Loop Gain | Communication Addr.: 0200H |
| | Default: 35 Applicable Control Mode: Pt, Pr Unit: rad/s Range: 0 ~ 1023 Settings: This parameter is used to set the position loop gain. It can increase stiffness, expedite position loop response and reduce position error. However, if the setting value is over high, it may generate vibration or noise. | | Related Section: Section 6.2.8 |
| P2-01 | PPR | Position Loop Gain Switching Rate | Communication Addr.: 0201H |
| | Default: 100 Applicable Control Mode: Pt, Pr Unit: % Range: 10 ~ 500 Settings: This parameter is used to set the position gain switching rate when the gain switching condition is satisfied. Please refer to P2-27 for gain switching control selection settings and refer to P2-29 for gain switching condition settings. | | Related Section: N/A |
| P2-02 | PFG | Position Feed Forward Gain | Communication Addr.: 0202H |
| | Default: 5000 Applicable Control Mode: Pt, Pr Unit: 0.0001 Range: 10 ~ 20000 Settings: This parameter is used to set the feed forward gain when executing position control command. When using position smooth command, increase gain can improve position track deviation. When not using position smooth command, decrease gain can improve the resonance condition of mechanical system. However, if the setting value is over high, it may generate vibration or noise. | | Related Section: Section 6.2.8 |

| | | | |
|--------------|---|--|-----------------------------------|
| P2-03 | PFF | Smooth Constant of Position Feed Forward Gain | Communication Addr.: 0203H |
| | Default: 5 Applicable Control Mode: Pt, Pr Unit: ms Range: 2 ~ 100 Settings: When using position smooth command, increase gain can improve position track deviation. When not using position smooth command, decrease gain can improve the resonance condition of mechanical system. | | Related Section: N/A |
| P2-04 | KVP | Proportional Speed Loop Gain | Communication Addr.: 0204H |
| | Default: 500 Applicable Control Mode: ALL Unit: rad/s Range: 0 ~ 20000 (Lexium 23C series) 0 ~ 4095 (Lexium 23M series) Settings: This parameter is used to set the speed loop gain. When the value of proportional speed loop gain is increased, it can expedite speed loop response. However, if the setting value is over high, it may generate vibration or noise. | | Related Section: Section 6.3.6 |
| P2-05 | SPR | Speed Loop Gain Switching Rate | Communication Addr.: 0205H |
| | Default: 100 Applicable Control Mode: ALL Unit: % Range: 10 ~ 500 Settings: This parameter is used to set the speed gain switching rate when the gain switching condition is satisfied. Please refer to P2-27 for gain switching control selection settings and refer to P2-29 for gain switching condition settings. | | Related Section: N/A |
| P2-06 | KVI | Speed Integral Compensation | Communication Addr.: 0206H |
| | Default: 100 Applicable Control Mode: ALL Unit: N/A Range: 0 ~ 4095 (Lexium 23C series) 0 ~ 1023 (Lexium 23M series) Settings: This parameter is used to set the integral time of speed loop. When the value of speed integral compensation is increased, it can improve the speed response ability and decrease the speed control deviation. However, if the setting value is over high, it may generate vibration or noise. | | Related Section: Section 6.3.6 |

| P2-07 | SFG | Speed Feed Forward Gain | Communication Addr.: 0207H |
|---|-------------|--------------------------------|-----------------------------------|
| Default: 0 Applicable Control Mode: ALL Unit: 0.0001 Range: 0 ~ 20000 Settings: This parameter is used to set the feed forward gain when executing speed control command. When using speed smooth command, increase gain can improve speed track deviation. When not using speed smooth command, decrease gain can improve the resonance condition of mechanical system. | | | Related Section: Section 6.3.6 |
| P2-08 | PCTL | Special Factory Setting | Communication Addr.: 0208H |
| Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 ~ 65536 This parameter can be used to reset all parameters to their original factory settings and enable some parameters functions. Settings: Reset parameters settings: 10: Users can reset all parameter values to factory defaults. All parameter values will be reset after re-power the servo drive. (Before perform this settings, ensure that the status of the servo drive is "Servo Off".) Enable parameters functions: 20: If P2-08 is set to 20, then the parameter P4-10 is enabled. 22: If P2-08 is set to 22, then the parameters P4-11 ~P4-19 are enabled. 1. Users may lock the parameters and protect parameters against change by unauthorized personnel. <ul style="list-style-type: none"> ● Parameter Lock (Password Input): Enter 5-digit password (your password should be at least five characters long). Confirm your password again and then, the password input is completed. (The highest digit of your password number should be at least set to 1). ● Set parameters: Enter correct password, and then you can unlock the parameters and change them. ● Password Decode: First, enter correct password, and set P2-08 to 0(zero) twice continuously. | | | Related Section: N/A |

| | | | |
|--------------|------------|----------------------|-----------------------------------|
| P2-09 | DRT | Bounce Filter | Communication Addr.: 0209H |
|--------------|------------|----------------------|-----------------------------------|

Default: 2

Applicable Control Mode: ALL

Unit: 2ms

Range: 0 - 20

Settings:

For example, if P2-09 is set to 5, the bounce filter time is $5 \times 2\text{ms} = 10\text{ms}$.

When there are too much vibration or noises around environment, increasing this setting value (bounce filter time) can improve reliability. However, if the time is too long, it may affect the response time.

Related Section:

Section 6.3.6

| | | | |
|--------------|------------|---------------------------------------|-----------------------------------|
| P2-10 | DI1 | Digital Input Terminal 1 (DI1) | Communication Addr.: 020AH |
|--------------|------------|---------------------------------------|-----------------------------------|

Default: 101


Applicable Control Mode: ALL

Unit: N/A

Range: 0 - 147

Settings:

This parameter is used to determine the function and status of DI1.



- A: DI Function Settings: For the setting value of P2- 10 - P2-17, please refer to Table 7.A.
- B: DI Enabled Status Settings:
 - 0: Normally closed (contact b)
 - 1: Normally open (contact a)

Please re-start the servo drive after parameters have been changed.

| | | | |
|--------------|------------|---------------------------------------|-----------------------------------|
| P2-11 | DI2 | Digital Input Terminal 2 (DI2) | Communication Addr.: 020BH |
|--------------|------------|---------------------------------------|-----------------------------------|

Default: 104

Applicable Control Mode: ALL

Unit: N/A

Range: 0 - 147

Settings: See P2-10 for explanation.


Related Section:

Table 7.A

| | | | |
|--------------------------------------|------------------------------|---------------------------------------|-----------------------------------|
| P2-12 | DI3 | Digital Input Terminal 3 (DI3) | Communication Addr.: 020CH |
| | Default: 116 | | Related Section: |
| | Applicable Control Mode: ALL | | Table 7.A |
| | Unit: N/A | | |
| | Range: 0 - 147 | | |
| Settings: See P2-10 for explanation. | | | |
| P2-13 | DI4 | Digital Input Terminal 4 (DI4) | Communication Addr.: 020DH |
| | Default: 117 | | Related Section: |
| | Applicable Control Mode: ALL | | Table 7.A |
| | Unit: N/A | | |
| | Range: 0 - 147 | | |
| Settings: See P2-10 for explanation. | | | |
| P2-14 | DI5 | Digital Input Terminal 5 (DI5) | Communication Addr.: 020EH |
| | Default: 102 | | Related Section: |
| | Applicable Control Mode: ALL | | Table 7.A |
| | Unit: N/A | | |
| | Range: 0 - 147 | | |
| Settings: See P2-10 for explanation. | | | |
| P2-15 | DI6 | Digital Input Terminal 6 (DI6) | Communication Addr.: 020FH |
| | Default: 22 | | Related Section: |
| | Applicable Control Mode: ALL | | Table 7.A |
| | Unit: N/A | | |
| | Range: 0 - 147 | | |
| Settings: See P2-10 for explanation. | | | |
| P2-16 | DI7 | Digital Input Terminal 7 (DI7) | Communication Addr.: 0210H |
| | Default: 23 | | Related Section: |
| | Applicable Control Mode: ALL | | Table 7.A |
| | Unit: N/A | | |
| | Range: 0 - 147 | | |
| Settings: See P2-10 for explanation. | | | |

| P2-17 | DI8 | Digital Input Terminal 8 (DI8) | Communication Addr.: 0211H |
|-------|-----|--|-------------------------------|
| | | Default: 21 Applicable Control Mode: ALL Unit: N/A Range: 0 - 147 Settings: See P2-10 for explanation. | Related Section: Table 7.A |

| P2-18 | DO1 | Digital Output Terminal 1 (DO1) | Communication Addr.: 0212H |
|-------|-----|---|-------------------------------|
| | | Default: 101 Applicable Control Mode: ALL Unit: N/A Range: 0 - 112 Settings: This parameter is used to determine the function and status of DO1. | Related Section: Table 7.B |



- A: DO Function Settings: For the setting value of P2- 18 - P2-22, please refer to Table 7.A.
- B: DO Enabled Status Settings:
0: Normally closed (contact b)
1: Normally open (contact a)

Please re-start the servo drive after parameters have been changed.

| P2-19 | DO2 | Digital Output Terminal 2 (DO2) | Communication Addr.: 0213H |
|-------|-----|---|-------------------------------|
| | | Default: 103 Applicable Control Mode: ALL Unit: N/A Range: 0 - 112 Settings: See P2-18 for explanation. | Related Section: Table 7.B |

| P2-20 | DO3 | Digital Output Terminal 3 (DO3) | Communication Addr.: 0214H |
|-------|-----|---|-------------------------------|
| | | Default: 109 Applicable Control Mode: ALL Unit: N/A Range: 0 - 112 Settings: See P2-18 for explanation. | Related Section: Table 7.B |

| | | | |
|--------------|--|--|-----------------------------------|
| P2-21 | DO4 | Digital Output Terminal 4 (DO4) | Communication Addr.: 0215H |
| | Default: 105 Applicable Control Mode: ALL Unit: N/A Range: 0 - 112 Settings: See P2-18 for explanation. | | Related Section: Table 7.B |
| P2-22 | DO5 | Digital Output Terminal 5 (DO5) | Communication Addr.: 0216H |
| | Default: 7 Applicable Control Mode: ALL Unit: N/A Range: 0 - 112 Settings: See P2-18 for explanation. | | Related Section: Table 7.B |
| P2-23 | NCF | Notch Filter (Resonance Suppression) | Communication Addr.: 0217H |
| | Default: 1000 Applicable Control Mode: ALL Unit: Hz Range: 50 - 1000 Settings: This parameter is used to set resonance frequency of mechanical system. It can be used to suppress the resonance of mechanical system. If P2-24 is set to 0, this parameter is disabled. | | Related Section: Section 6.3.7 |
| P2-24 | DPH | Notch Filter Attenuation Rate (Resonance Suppression) | Communication Addr.: 0218H |
| | Default: 0 Applicable Control Mode: ALL Unit: dB Range: 0 - 32 Settings: 0: Disabled | | Related Section: Section 6.3.7 |

| | | | |
|--------------|--|--|-----------------------------------|
| P2-25 | NLP | Low-pass Filter Time Constant (Resonance Suppression) | Communication Addr.: 0219H |
| | Default: 2 (1kW and below models) or 5 (above 1kW models) Applicable Control Mode: ALL Unit: ms Range: 0 - 1000 Settings: 0: Disabled This parameter is used to set low-pass filter time constant of resonance suppression. | | Related Section: Section 6.3.7 |
| P2-26 | DST | External Anti-Interference Gain | Communication Addr.: 021AH |
| | Default: 0 Applicable Control Mode: ALL Unit: 0.001 Range: 0 - 30000 (Lexium 23C series) 0 - 1023 (Lexium 23M series) Settings: 0: Disabled In AutoMode (PDF) mode (parameter P2-32 is set to 4 or 5), the value of this parameter is determined by the system automatically. | | Related Section: N/A |
| P2-27 | GCC | Gain Switching Control Selection | Communication Addr.: 021BH |
| | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 - 4 Settings: Gain Switching Condition Settings: 1: Gain switching DI signal (GAINUP) is On. (see Table 7.A) 2: In position mode, position deviation is higher than the setting value of P2-29. 3: Position command frequency is higher than the setting value of P2-29. 4: Servo motor speed is higher than the setting value of P2-29. | | Related Section: N/A |

| | | | |
|--|--|-------------------------------------|-----------------------------------|
| P2-28 | GUT | Gain Switching Time Constant | Communication Addr.: 021CH |
| | Default: 10 Applicable Control Mode: ALL Unit: 10ms Range: 0 ~ 1000 Settings: 0: Disabled This parameter is used to set the time constant when switching the smooth gain. | | Related Section: N/A |
| P2-29 | GPE | Gain Switching Condition | Communication Addr.: 021DH |
| | Default: 10000 Applicable Control Mode: ALL Unit: pulse, Kpps, r/min Range: 0 ~ 30000 Settings: 0: Disabled This parameter is used to set the value of gain switching condition (pulse error, Kpps, r/min) selected in P2-27. The setting value will be different depending on the different gain switching condition. | | Related Section: N/A |
| P2-30 | INH | Auxiliary Function | Communication Addr.: 021EH |
| | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0 ~ 5 Settings: 0: Normal operation of Digital Inputs SON, CW, and CCW. 1: Force the servo drive to be Servo On (ignore CW and CCW signal) 2: Ignore CW digital input signal 3: Ignore CCW digital input signal 4: Internal position learning function 5: After setting P2-30 to 5, the setting values of all parameters will lost (not remain in memory) at power-down. When the parameters data are no more needed, using this mode can allows users not to save parameters data into memory without damaging the EEPROM. | | Related Section: N/A |
| <p>Note: Please set P2-30 to 0 during normal operation. When the communication control function is used, ensure that P2-30 is set to 5. The setting value of P2-30 will return to 0 automatically after re-power the servo drive.</p> | | | |

| | | | |
|--------------|-------------|---------------------------------------|-----------------------------------|
| P2-31 | AUT1 | Auto Mode Responsiveness Level | Communication Addr.: 021FH |
|--------------|-------------|---------------------------------------|-----------------------------------|

Default: 44

Related Section:


Applicable Control Mode: ALL

Section 5.6, Section 6.3.6

Unit: N/A

Range: 0 ~ FF (0 ~ FF: 0 indicates the lowest setting and F indicates the highest setting (total 16 settings available))

Settings:



Lexium 23C series:

This parameter allows the users to set the stiffness setting of easy mode and the responsiveness level of auto-tuning mode. Users can control the stiffness and responsiveness according to application condition. When the setting value is higher, the stiffness and the responsiveness is higher.

A: Stiffness setting of easy mode

B: Responsiveness level of auto-tuning mode

Lexium 23M series:

This parameter allows the users to set the responsiveness level setting of auto-tuning mode. Users can control the responsiveness according to application condition. When the setting value is higher, the responsiveness is higher.

A: No function

B: Responsiveness level of auto-tuning mode

Note:

1) This parameter is activated by P2-32.

2) Please refer to Section 5.6 for the tuning procedure and the related settings.

| P2-32▲ | AUT2 | Tuning Mode Selection | Communication Addr.: 0220H |
|---------------|---|------------------------------|-----------------------------------|
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 5.6, Section 6.3.6 |
| | Unit: N/A | | |
| | Range: 0 ~ 5 | | |
| | Settings: | | |
| | 0: Manual mode | | |
| | 1: Easy mode (for Lexium 23C series only, Lexium 23M series does not support this mode) | | |
| | 2: AutoMode (PI) [Continuous adjustment] | | |
| | 3: AutoMode (PI) [Fix the ratio of Load Inertia to servo motor inertia and response level can be adjusted] | | |
| | 4: AutoMode (PDFF) [Continuous adjustment] | | |
| | 5: AutoMode (PDFF) [Fix the ratio of Load Inertia to servo motor inertia and response level can be adjusted] | | |
| | PI : Proportional - Integral control | | |
| | PDFF : Pseudo-Derivative Feedback and Feedforward | | |
| | Explanation of Auto-tuning: | | |
| | 1. When switching mode #2 or #4 to #3 or #5, the system will save the measured load inertia value automatically and memorized in P1-37. Then, set the corresponding parameters according to this measured load inertia value. | | |
| | 2. When switching mode #2 or #4 to #0, it indicates all automatically measured load inertia value will be aborted, and all setting of parameters will be returned to original setting value in #0 manual mode. | | |
| | 3. When switching mode #0 to #3 or #5, enter the appropriate load inertia value in P1-37. | | |
| | 4. When switching mode #3 to #0, the setting value of P2-00, P2-04 and P2-06 will change to the value that measured in #3 auto-tuning mode. | | |
| | 5. When switching mode #5 to #0, the setting value of P2-00, P2-04, P2-06, P2-25 and P2-26 will change to the value that measured in #5 auto-tuning mode | | |

| | | | |
|--------------|------------|-------------------------------------|-----------------------------------|
| P2-33 | INF | Easy Setting of Input Filter | Communication Addr.: 0221H |
|--------------|------------|-------------------------------------|-----------------------------------|


Default: 0

Applicable Control Mode: ALL

Unit: N/A

Range: 00 ~ 19

Settings:



- A=1: Enable this function

- B: Speed selection

B=0 ↓ Low speed

B=9 ↓ High speed

| | | | |
|--------------|-------------|------------------------------------|-----------------------------------|
| P2-34 | SDEV | Overspeed Warning Condition | Communication Addr.: 0222H |
|--------------|-------------|------------------------------------|-----------------------------------|

Default: 5000

Related Section: N/A

Applicable Control Mode: S

Unit: r/min

Range: 1 ~ 5000

Settings:

This parameter is used to set the over speed threshold that is used to determine the over speed fault condition. When the difference in speed between the desired speed and actual motor speed is over than the setting value of parameter P2-34, the servo fault, Overspeed (ALE07) will be activated.

| | | | |
|--------------|-------------|--|-----------------------------------|
| P2-35 | PDEV | Excessive Error Warning Condition | Communication Addr.: 0223H |
|--------------|-------------|--|-----------------------------------|

Default: 30000

Related Section: N/A

Applicable Control Mode: Pt, Pr

Unit: pulse (Lexium 23C series, Pr mode of Lexium 23M series)
1/10000 rev. (Pt mode of Lexium 23M series)

Range: 1 ~ 30000

Settings:

This parameter is used to set the position deviation excessive error threshold that is used to determine the excessive deviation fault condition. When the difference in pulse number between the desired position and actual motor position is over than the setting value of parameter P2-35, the servo fault, Excessive Deviation (ALE09) will be activated.


| | | | |
|--------------|--|---|-----------------------------------|
| P2-36 | POV1 | Moving Speed Setting of 1st Position | Communication Addr.: 0224H |
| | Default: 1000 Applicable Control Mode: Pr Unit: r/min Range: 1 ~ 5000 Settings: When setting value of P2-36 to P2-43 is higher than 3000 r/min, please set the setting value of P1-55 to its maximum value. | | Related Section: Section 6.2.2 |
| P2-37 | POV2 | Moving Speed Setting of 2nd Position | Communication Addr.: 0225H |
| | Default: 1000 Applicable Control Mode: Pr Unit: r/min Range: 1 ~ 5000 Settings: Please refer to P2-36. | | Related Section: Section 6.2.2 |
| P2-39 | POV3 | Moving Speed Setting of 3rd Position | Communication Addr.: 0226H |
| | Default: 1000 Applicable Control Mode: Pr Unit: r/min Range: 1 ~ 5000 Settings: Please refer to P2-36. | | Related Section: Section 6.2.2 |
| P2-38 | POV4 | Moving Speed Setting of 4th Position | Communication Addr.: 0227H |
| | Default: 1000 Applicable Control Mode: Pr Unit: r/min Range: 1 ~ 5000 Settings: Please refer to P2-36. | | Related Section: Section 6.2.2 |

| | | | |
|--------------|---|---|-----------------------------------|
| P2-40 | POV5 | Moving Speed Setting of 5th Position | Communication Addr.: 0228H |
| | Default: 1000 Applicable Control Mode: Pr Unit: r/min Range: 1 ~ 5000 Settings: Please refer to P2-36. | | Related Section: Section 6.2.2 |
| P2-41 | POV6 | Moving Speed Setting of 6th Position | Communication Addr.: 0229H |
| | Default: 1000 Applicable Control Mode: Pr Unit: r/min Range: 1 ~ 5000 Settings: Please refer to P2-36. | | Related Section: Section 6.2.2 |
| P2-42 | POV7 | Moving Speed Setting of 7th Position | Communication Addr.: 022AH |
| | Default: 1000 Applicable Control Mode: Pr Unit: r/min Range: 1 ~ 5000 Settings: Please refer to P2-36. | | Related Section: Section 6.2.2 |
| P2-43 | POV8 | Moving Speed Setting of 8th Position | Communication Addr.: 022BH |
| | Default: 1000 Applicable Control Mode: Pr Unit: r/min Range: 1 ~ 5000 Settings: Please refer to P2-36. | | Related Section: Section 6.2.2 |


| | | | |
|--------------|--|---|---|
| P2-44 | DOM | Digital Output Mode Setting | Communication Addr.: 022CH |
| | <p>Default: 0</p> <p>Applicable Control Mode: Pr</p> <p>Unit: N/A</p> <p>Range: 0 ~ 1</p> <p>Settings:</p> <p>This parameter determines that the digital output equals the setting value of P2-18 ~ P2-22 or INDEX positions when using feed step control function and in internal auto running mode (See Chapter 12 for explanation).</p> <p>0: General output mode, digital output function is defined by the setting value of P2-18 ~ P2-22.</p> <p>1: Combination output mode</p> <p>When the users want to use feed step control function, this output mode must be selected. Otherwise, the feed step control function can not be used normally. (Refer to Section 12.6) When the users want to use internal auto running mode function, this output mode must be selected. Otherwise, the output signal can not be converted to combination output signal normally. (Refer to Section 12.7)</p> | | <p>Related Section:</p> <p>Section 12.6</p> |
| P2-45 | DOD | Combination Output Signal Delay Time | Communication Addr.: 022DH |
| | <p>Default: 1</p> <p>Applicable Control Mode: Pr</p> <p>Unit: 4ms</p> <p>Range: 0 ~ 250</p> <p>Settings:</p> <p>This parameter can be used only when P2-44 is set to 1. The users can use this parameter to set the ON time delay when positioning is completed.</p> | | <p>Related Section:</p> <p>Section 12.6</p> |
| P2-46 | FSN | Feed Step Number | Communication Addr.: 022EH |
| | <p>Default: 6</p> <p>Applicable Control Mode: Pr</p> <p>Unit: sec</p> <p>Range: 2 ~ 32</p> | | <p>Related Section:</p> <p>Section 12.6</p> |

| P2-47 | PED | Position Deviation Clear Delay Time | Communication Addr.: 022FH |
|-------|-----|--|----------------------------------|
| | | Default: 0 Applicable Control Mode: Pr Unit: 20ms Range: 0 ~ 250 This function is disabled when its setting value is set to 0. | Related Section: Section 12.6 |

| P2-48 | BLAS | Backlash Compensation of Feed Step Control | Communication Addr.: 0230H |
|--|------|---|----------------------------------|
| | | Default: 0 Applicable Control Mode: Pr Unit: pulse Range: 0 ~ 10312 Settings: | Related Section: Section 12.6 |
|  | | | |
| <ul style="list-style-type: none"> ● A: Pulse Number Settings 0 ~ 312, the pulse number of backlash compensation Actual pulse number of backlash compensation of motor output shaft is equal to the number of value A x electronic gear ratio ● B: Polarity Settings B=0: Forward compensation B=1: Reverse compensation | | | |
| <p>Note: After modifying the setting value, execute the home sensor function. After executing the home sensor function, perform the control function.</p> | | | |

| P2-49 | SJIT | Speed Detection Filter and Jitter Suppression | Communication Addr.: 0231H |
|---|------|---|----------------------------|
| Default: 0 Applicable Control Mode: ALL Unit: sec Range: 0 ~ 19 Settings: | | | Related Section: N/A |
|  | | | |
| <ul style="list-style-type: none"> ● A: Speed Detection Filter Constant Range: 0 ~ 9 ● B: Enable/Disable Jitter Suppression Function B=0: Disable Jitter Suppression function B=1: Enable Jitter Suppression function When this function is enabled, it can suppress the jitter created when the motor stops at a position. | | | |

| P2-50 | DCLR | Pulse Deviation Clear Mode | Communication Addr.: 0232H |
|---|------|----------------------------|----------------------------|
| Default: 0 Applicable Control Mode: Pt, Pr Unit: N/A Range: 0 ~ 2 Settings: | | | Related Section: N/A |
| <p>For digital input function (DI function), please refer to Table 7.A.</p> <p>This pulse deviation clear function is enabled when a digital input is set to pulse clear function (CCLR mode, DI function is set to 4).</p> <p>0: Clear position pulse deviation number (available in Pt and Pr mode only) When this input is triggered, the position accumulated pulse number will be clear to 0.</p> <p>1: Clear motor feedback pulse and rotation number (available in Pt and Pr mode only) When this input is triggered, the count pulse and rotation number will be clear to 0. This zero point will be regarded as the "Home" of the motor.</p> <p>2: Clear remaining position pulses and interrupt the motor operation (available Pr mode only). If CCLR signal is ON when the motor is running, the motor will decelerate first and stop according to the deceleration time which is set by parameter P1-34 - P1-36 and the remaining pulses will be aborted. When TRIG signal is ON again, the motor will continue to move forward and reach the target position that is set currently.</p> | | | |



| | | | |
|--------------|--|-----------------------------|-----------------------------------|
| P2-51 | SRON | Servo ON | Communication Addr.: 0233H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: ALL | | |
| | Unit: N/A | | |
| | Range: 0 ~ 1 | | |
| | Settings: | | |
| | 0: Servo ON (SON) is activated via Digital Input signal | | |
| | 1: Servo ON (SON) is activated when control power is applied the servo drive (not via Digital Input signal) | | |
| | Servo ON (SON) is "ON" with control power applied to the servo drive, there may be a fault condition or not. The servo is not ready to run. Servo ready (SRDY) is "ON" where the servo is ready to run, NO fault / alarm exists. (P2-51 should turn servo ready SRDY off / on) | | |
| P2-52 | ATM0 | Timer 0 of Auto Mode | Communication Addr.: 0234H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: Pr | | |
| | Unit: sec | | |
| | Range: 0 ~ 120.00 | | |
| P2-53 | ATM1 | Timer 1 of Auto Mode | Communication Addr.: 0235H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: Pr | | |
| | Unit: sec | | |
| | Range: 0 ~ 120.00 | | |

| | | | |
|--------------|-----------------------------|-----------------------------|-----------------------------------|
| P2-54 | ATM2 | Timer 2 of Auto Mode | Communication Addr.: 0236H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: Pr | | |
| | Unit: sec | | |
| | Range: 0 ~ 120.00 | | |
| P2-55 | ATM3 | Timer 3 of Auto Mode | Communication Addr.: 0237H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: Pr | | |
| | Unit: sec | | |
| | Range: 0 ~ 120.00 | | |
| P2-56 | ATM4 | Timer 4 of Auto Mode | Communication Addr.: 0238H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: Pr | | |
| | Unit: sec | | |
| | Range: 0 ~ 120.00 | | |
| P2-57 | ATM5 | Timer 5 of Auto Mode | Communication Addr.: 0239H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: Pr | | |
| | Unit: sec | | |
| | Range: 0 ~ 120.00 | | |
| P2-58 | ATM6 | Timer 6 of Auto Mode | Communication Addr.: 023AH |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: Pr | | |
| | Unit: sec | | |
| | Range: 0 ~ 120.00 | | |
| P2-59 | ATM7 | Timer 7 of Auto Mode | Communication Addr.: 023BH |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: Pr | | |
| | Unit: sec | | |
| | Range: 0 ~ 120.00 | | |

| | | | |
|--------------|--|---|-----------------------------------|
| P2-60 | GR4 | Electronic Gear Ratio (2nd Numerator) (N2) | Communication Addr.: 023CH |
| | Default: 1 Applicable Control Mode: Pt, Pr Unit: pulse Range: 1 ~ 32767 Settings: The electronic gear numerator value can be set via GNUM0, GNUM1 (refer to Table 7.A). When the GNUM0, GNUM1 are not defined, the default of gear numerator value is set by P1-44. When the users wish to set the gear numerator value by using GNUM0, GNUM1, please set P2-60 ~ P2-62 after the servo motor has been stopped. | | Related Section: N/A |
| P2-61 | GR5 | Electronic Gear Ratio (3rd Numerator) (N3) | Communication Addr.: 023DH |
| | Default: 1 Applicable Control Mode: Pt, Pr Unit: pulse Range: 1 ~ 32767 Settings: Please refer to P2-60. | | Related Section: N/A |
| P2-62 | GR6 | Electronic Gear Ratio (4th Numerator) (N4) | Communication Addr.: 023EH |
| | Default: 1 Applicable Control Mode: Pt, Pr Unit: pulse Range: 1 ~ 32767 Settings: Please refer to P2-60. | | Related Section: N/A |

| | | | |
|--------------|-------------|---------------------------------|-----------------------------------|
| P2-63 | TSCA | Proportion Value Setting | Communication Addr.: 023FH |
|--------------|-------------|---------------------------------|-----------------------------------|


Default: 0

Applicable Control Mode: Pt, S

Unit: times

Range: 0 - 11

Settings:



A: Decimal place setting of internal speed command.

0: When value A is set to 0, the unit of P1-09-P1-11 is 1 r/min (No decimal place setting) 1: When value A is set to 1, the unit of P1-09-P1-11 is 0.1 r/min (One decimal place setting) If P1-09 is set to 1234, and value A is set to 0, and then the internal speed is 1234 r/min. If P1-09 is set to 1234, and value A is set to 1, and then the internal speed is 123.4 r/min. This setting value A is available for internal speed command only, not available for speed limit command.

B: Proportion value setting of position excessive error warning condition (P2-35)

Lexium 23C series

0: When value B is set to 0, the unit of P2-35 is 1 pulse

1: When value B is set to 1, the unit of P2-35 is 100 pulses

If P2-35 is set to 1000, and value B is set to 0, the position excessive error warning pulse is 1000 pulses.

If P2-35 is set to 1000, and value B is set to 1, the position excessive error warning pulse is 100,000 pulses.

Lexium 23M series

0: When value B is set to 0, the unit of P2-35 is 1/10000 rev.

1: When value B is set to 1, the unit of P2-35 is 1/100 rev.

If P2-35 is set to 1000, and value B is set to 0, the position excessive error warning pulse is 0.1 rev.

If P2-35 is set to 1000, and value B is set to 1, the position excessive error warning pulse is 10 rev.

| | | | |
|--------------|--------------|--------------------------------|---------------------------------------|
| P2-64 | TLMOD | Torque Limit Mixed Mode | Communication Addr.: 0240H |
|--------------|--------------|--------------------------------|---------------------------------------|

Default: 0

Related Section: N/A

Applicable Control Mode: Pt, Pr, S

Unit: N/A

Range: 0 ~ 3

Settings:



PL: Positive Limit

NL: Negative Limit

Tref: Torque Analog Input Voltage

Tpl: Actual PL value in "Torque Limit Mixed Mode"

Tnl: Actual NL value in "Torque Limit Mixed Mode"

0: Disabled

1: Torque limit mixed mode (No polarity)

If $|T_{ref}| < PL$, $T_{pl} = |T_{ref}|$ If $|T_{ref}| > PL$, $T_{pl} = PL$ If $|T_{ref}| < NL$, $T_{nl} = |T_{ref}|$ If $|T_{ref}| > NL$, $T_{nl} = NL$

2: Torque limit mixed mode (Positive)

If $0 < T_{ref} < PL$, $T_{pl} = T_{ref}$ If $T_{ref} > PL$, $T_{pl} = PL$ If $T_{ref} < 0$, $T_{pl}, T_{nl} = 0$

3: Torque limit mixed mode (Negative)

If $T_{ref} > 0$, $T_{pl}, T_{nl} = 0$ If $-NL < T_{ref} < 0$, $T_{nl} = -T_{ref}$ If $T_{ref} < -NL$, $T_{nl} = NL$

This parameter can allow the users to set two different kinds of torque limit command sources when limiting torque. We call it is "Torque Limit Mixed Mode". The torque limit function is activated by parameter P1-02 or via digital input TRQLM, TLLM or TRLM.

If the users use TRQLM or P1-02 to activate torque limit function, the torque limit command source can be analog input or internal parameters (P1-12 to P1-14) depending on which way you use to activate torque limit function. At this time, the limit of PL and NL in the figure below are specified as the torque limit that determined by the torque limit command source.

If the users use TLLM or TRLM to activate torque limit function, the torque limit command source can be parameter P1-12 (NL) or P1-13 (PL).

| | | | |
|--------------|-------------|-------------------------|-----------------------------------|
| P2-65 | GBIT | Special Function | Communication Addr.: 0241H |
|--------------|-------------|-------------------------|-----------------------------------|

Default: 0
 Applicable Control Mode: Pr, Pt, S
 Unit: N/A
 Range: 0 ~ 3

Related Section: N/A

Settings:

| | | | | | | | |
|-------|-------|-------|-------|-------|-------|------|------|
| Bit15 | Bit14 | Bit13 | Bit12 | Bit11 | Bit10 | Bit9 | Bit8 |
| Bit7 | Bit6 | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 |

| | |
|------|------|
| Bit1 | Bit0 |
|------|------|


Bit0: DI SPDO/SPD1 speed command trigger mode

- 0: by level
- 1: by rising edge

Bit1: DI TCM0/TCM1 torque command trigger mode

- 0: by level
- 1: by rising edge

When the servo drive is rising-edge triggered, the internal commands work as follows:



- A: Execute internal command 1
- B: Execute internal command 2
- C: Execute internal command 3
- D: Execute internal command 3

| | | |
|------|------|------|
| Bit4 | Bit3 | Bit2 |
|------|------|------|

Fast DI (digital input) function. When this function is activated, the function of P2-17(DI8) will become invalid and change to Fast DI (digital input) function. When Bit3 ~ Bit4 are all set to 0, this fast DI (digital input) function is disabled.

Bit2: Fast DI contact type

- 0: normal open or rising edge trigger
- 1: normal close or falling edge trigger

Bit3 ~ Bit4: Fast DI function definition

| Bit4 | Bit3 | Function |
|------|------|---|
| 0 | 0 | Disable fast DI function |
| 0 | 1 | Fast position latch for DI8 : When fast position latch function is enabled, the users can get latch position from LED display by setting P0-02=15 (latch pulses) or setting P0-02=16 (latch revolutions) . The users also can get the position through the communication by setting P0-04 ~ P0-08. |
| 1 | 0 | Fast DI INHIBIT for DI8 Response time of the normal DI is 0.4 ~ 0.6ms Response time of this fast DI is 0.0 ~ 0.1ms |

Please note that Bit3 and Bit4 cannot be activated simultaneously.

Bit5: Reserved. Must be set to 0.

| |
|------|
| Bit6 |
|------|

Bit6: Abnormal pulse command detection

0: enable abnormal pulse command detection

1: disable abnormal pulse command detection,

Bit7 ~ Bit9: Reserved. Must be set to 0.

| |
|-------|
| Bit10 |
|-------|

Bit10: DI ZCLAMP function selection

0: Locked at the position when ZCLAMP conditions are satisfied.

1: Speed command is forced to 0 r/min when ZCLAMP conditions are satisfied.

How to select these two functions?

If the users want to use the edge of a D1 signal to stop the motor at the desired position and do not care the speed deceleration curve, then set Bit10 of P2-65 to 0.

If the users want to eliminate the analog voltage offset to stop the motor at low voltage and they want to keep the acceleration and deceleration speed curve, then set Bit10 of P2-65 to 1. When the following conditions are all met, ZCLAMP function will be activated.

Condition1: Speed mode

Condition2: DI ZCLAMP is activated.

Condition3: External analog speed command or internal registers speed command is less than parameter P1-38.

Bit11: Reserved. Must be set to 0.

| | |
|-----|-----|
| B13 | B12 |
|-----|-----|

Bit 12: Undervoltage (Servo Drive Fault) clear mode selection

0: When the main circuit voltage is within its specified limit or after Servo Off (the servo drive is disabled), the fault, Undervoltage will be cleared automatically.

1: When turning ARST (DI signal) to be ON and the main circuit voltage is within its specified limit also, the fault, Undervoltage will be cleared.

Bit 13: CWL/CCWL pulse input inhibit function

0: Disable CWL/CCWL pulse input inhibit function. In Pt mode, no matter CWL or CCWL exists or not, external position pulse command will be input into the servo drive.

1: Enable CWL/CCWL pulse input inhibit function. In Pt mode, if CWL exists, the external CWL pulse input into the servo drive will be inhibited and CCWL pulse input will be accepted. On the one hand, in Pt mode, if CCWL exists, the external CCWL pulse input into the servo drive will be inhibited and CCWL pulse input will be accepted. Please note that if CWL and CCWL both exist, CWL and CCWL pulse input into the servo drive will be both inhibited.

Bit14 ~ Bit15: Reserved. Must be set to 0.

| | | |
|----------------|----------|----------------------------|
| P2 - 66 | Reserved | Communication Addr.: 0242H |
| P2 - 67 | Reserved | Communication Addr.: 0243H |
| P2 - 68 | Reserved | Communication Addr.: 0244H |

Group 3: P3-xx Communication Parameters

| P3 - 00 | ADR | Communication Address Setting | Communication Addr.: 0300H |
|---|------------|---|-----------------------------------|
| | | Default: 1 Applicable Control Mode: ALL Unit: N/A Range: 1~254 | Related Section: Section 8.2 |
| Settings: If the AC servo drive is controlled by RS-232/485/422 communication, each drive (or device) must be uniquely identified and addressed between 1 and 254. Access to program this number is via parameter P3-00. One servo drive only can set one address. If the address is duplicate, there will be a communication fault. | | | |
| Note: 1) When the address of host (external) controller is set to 0, it is with broadcast function. Then, the servo drive will receive from host (external) controller only and will not respond to host (external) controller no matter the address is matching or not. 2) When the address of host (external) controller is set to 255, it is with auto-respond function. Then, the servo drive will receive from and respond to host (external) controller both no matter the address is matching or not. | | | |

| P3-01 | BRT | Transmission Speed | Communication Addr.: 0301H |
|---|------------|---|-----------------------------------|
| | | Default: 1 Applicable Control Mode: ALL Unit: bps Range: 0~5 | Related Section: Section 8.2 |
| Settings: 0: Baud rate 4800 (data transmission speed: bits / second) 1: Baud rate 9600 (data transmission speed: bits / second) 2: Baud rate 19200 (data transmission speed: bits / second) 3: Baud rate 38400 (data transmission speed: bits / second) 4: Baud rate 57600 (data transmission speed: bits / second) 5: Baud rate 115200 (data transmission speed: bits / second) This parameter is used to set the desired transmission speed between the computer and AC servo drive. Users can set this parameter and control transmission speed to reach the maximum baud rate of 115200 bps. | | | |

| P3-02 | PTL | Communication Protocol | Communication Addr.: 0302H |
|--|------------|---|-----------------------------------|
| | | Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0-8 Settings: 0: Modbus ASCII mode, <7,N,2> 1: Modbus ASCII mode, <7,E,1 > 2: Modbus ASCII mode, <7,O,1> 3: Modbus ASCII mode, <8,N,2 > 4: Modbus ASCII mode, <8,E,1> 5: Modbus ASCII mode, <8,O,1> 6: Modbus RTU mode, <8,N,2> 7: Modbus RTU mode, <8,E,1> 8: Modbus RTU mode, <8,O,1> | Related Section: Section 8.2 |
| This parameter is used to set the communication protocol. The alphanumeric characters represent the following: 7 or 8 is the number of data bits; N, E or O refer to the parity bit, Non, Even or Odd; the 1 or 2 is the numbers of stop bits. | | | |

| P3-03 | FLT | Transmission Fault Treatment | Communication Addr.: 0303H |
|--|------------|--|-----------------------------------|
| | | Default: 0 Applicable Control Mode: P, S, T Unit: N/A Range: 0-1 Settings: | Related Section: Section 8.2 |
| | | 0: Display fault and continue operating 1: Display fault and stop operating | |
| This parameter is used to determine the operating sequence once a communication fault has been detected. If '1' is selected, the drive will stop operating upon detection the communication fault. The mode of stopping is set by parameter P1-32. | | | |

| P3-04 | CWD | Communication Time Out Detection | Communication Addr.: 0304H |
|---|------------|--|-----------------------------------|
| Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0-20 Settings: 0: Disabled | | This parameter is used to set the maximum permissible time before detecting a fault due to communication time out. When this parameter is set to a value over than 0, it indicates this function is enabled. However, if not communicating with the servo in this period of time, the servo drive will assume the communication has failed and show the communication error fault message. | Related Section: Section 8.2 |
| P3-05 | CMM | Communication Selection | Communication Addr.: 0305H |
| Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0-2 Settings: 0: RS-232 1: RS-422 2: RS-485 | | Multiple communication modes RS232, RS-485, RS-422 cannot be used within one communication ring. | Related Section: Section 8.2 |

| P3-06 | SDI | Digital Input Communication Function | Communication Addr.: 0306H |
|---|-----|--------------------------------------|--|
| Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0-FFFF | | | Related Section: P4-07, Section 8.2 |
| Settings: The setting of this parameter determines how the Digital Inputs (DI) accept commands and signals. If the Digital Input Contact Control parameter for the DI 1 - DI 8 is set to "0", command is external, and via CN1; if it is set to "1" the DI signal is via communication. Bit0 - Bit 7 corresponds with DI1 ~ DI8. The least significant bit (Bit0) shows DI1 status and the most significant bit (Bit7) shows DI8 status. The new DI9 - DI16 for software communication corresponds with CTRG / POS0 / POS1 / POS2 / ARST / SHOM / JOGU / JOGD these signals. The Digital Input Control Contact parameter, P3-06 also works in conjunction with the Multi Function Digital Input parameter P4-07 which has several functions. Please see section 8.2 for details. | | | |

| P3-07 | CDT | Communication Response Delay Time | Communication Addr.: 0307H |
|--|-----|-----------------------------------|----------------------------|
| Default: 0 Applicable Control Mode: ALL Unit: 0.5ms Range: 0-255 | | | Related Section: N/A |
| Settings: This parameter is used to delay the communication time that servo drive responds to host controller (external controller). Note: When the address of host (external) controller is set to 255, no matter what the setting value of parameter P1-37 is, the communication response delay time will be 0 always. | | | |

Group 4: P4-xx Diagnosis Parameters

| | | | |
|---------------|------------------------------|---------------------------|-----------------------------------|
| P4-00★ | ASH1 | Fault Record (N) | Communication Addr.: 0400H |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 4.4.1 |
| | Unit: N/A | | |
| | Range: N/A | | |
| | Settings: | | |
| | The latest fault record. | | |
| P4-01★ | ASH2 | Fault Record (N-1) | Communication Addr.: 0401H |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 4.4.1 |
| | Unit: N/A | | |
| | Range: N/A | | |
| P4-02★ | ASH3 | Fault Record (N-2) | Communication Addr.: 0402H |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 4.4.1 |
| | Unit: N/A | | |
| | Range: N/A | | |
| P4-03★ | ASH4 | Fault Record (N-3) | Communication Addr.: 0403H |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 4.4.1 |
| | Unit: N/A | | |
| | Range: N/A | | |
| P4-04★ | ASH5 | Fault Record (N-4) | Communication Addr.: 0404H |
| | Default: 0 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 4.4.1 |
| | Unit: N/A | | |
| | Range: N/A | | |

| P4-05 | JOG | JOG Operation | Communication Addr.: 0405H |
|-------|---|---------------|----------------------------|
| | Default: 20 | | Related Section: |
| | Applicable Control Mode: ALL | | Section 4.4.2 |
| | Unit: r/min | | |
| | Range: 0-5000 | | |
| | Settings: | | |
| | JOG operation command: | | |
| | 1. Operation Test | | |
| | (1) Press the SET key to display the JOG speed. (The default value is 20 r/min). | | |
| | (2) Press the UP or DOWN arrow keys to increase or decrease the desired JOG speed. (This also can be undertaken by using the SHIFT key to move the cursor to the desired unit column (the effected number will flash) then changed using the UP and DOWN arrow keys). | | |
| | (3) Press the SET when the desired JOG speed is displayed. The Servo Drive will display "JOG". | | |
| | (4) Press the UP or DOWN arrow keys to jog the motor either CCW or CW. The motor will only rotation while the arrow key is activated. | | |
| | (5) To change JOG speed again, press the MODE key. The servo Drive will display "P4 - 05". Press the SET key | | |
| | 2. DI Signal Control | | |
| | Set the value of DI signal as JOGU and JOGD (refer to Table 7.A). | | |
| | Users can perform JOG run forward and run reverse control. | | |
| | 3. Communication Control | | |
| | To perform a JOG Operation via communication command, use communication address 0405H | | |
| | (1) Enter 0 ~ 3000 for the desired JOG speed | | |
| | (2) Enter 4998 to JOG in the CCW direction | | |
| | (3) Enter 4999 to JOG in the CW direction | | |
| | (4) Enter 5000 to stop the JOG operation | | |

Note: If the communication write-in frequency is too high, please set P2-30 to 5.

| P4-06 ▲■ | FOT | Force Output Control | Communication Addr.: 0406H |
|--|-----|-----------------------------------|----------------------------|
| Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0-0x1F Settings: 0: Disabled. | | Related Section: Section 4.4.4 | |
| <p>When the value of P4-06 is a non-zero value, it indicates this function is enabled. This parameter is used to check if there is any damage DO terminal. This parameter is not effective when the servo drive is enabled (Servo ON).</p> | | | |

Note: When users select P4-06 and press the Set key, the display will show “OP xx” . “xx” stands for the parameter range from 00 to 1F (For the example display, refer to Section 4.4.4).

| P4-07■ | ITST | Input Status or Force Input Control | Communication Addr.: 0407H |
|--|------|--|----------------------------|
| Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0-FFFF Settings: | | Related Section: P3-06, Section 4.4.5, Section 8.2 | |
| <p>Please see P3-06 and Section 8.2 for setting method. External Control: Display the status of DI input signal Communication Control: Read the status of input signal (upon software) For the status of DI input signal, please refer to P2-10 ~ P2-17. The contents of P4-07 is "read only" via the drive keypad or the communication software and will display the state on or off of the six Digital Inputs which have been set in accordance to P3-06. The least significant bit (Bit 0) stands for Digital Inputs 1 (DI 1) and the most significant bit (Bit7) stands for Digital Inputs 8 (DI 8).</p> | | | |

| P4-08 | PKEY | Digital Keypad Input of Servo Drive | Communication Addr.: 0408H |
|---|------|-------------------------------------|----------------------------|
| Default: N/A Applicable Control Mode: ALL Unit: N/A Range: N/A | | Related Section: N/A | |

| P4-09★ | MOT | Output Status Display | Communication Addr.: 0409H |
|---|-----|-----------------------|-----------------------------------|
| Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0-0x1F Settings: External Control: Display the status of DO output signal Communication Control: Read the status of output signal The status of DO signal, please refer to P2-18 ~ P2-22. | | | Related Section: Section 4.4.6 |
| P4-10▲ | CEN | Adjustment Function | Communication Addr.: 040AH |
| Default: 0 Applicable Control Mode: ALL Unit: N/A Range: 0-6 Settings: 0: Reserved 1: Execute analog speed input drift adjustment 2: Execute analog torque input drift adjustment 3: Execute current detector (V phase) drift adjustment 4: Execute current detector (W phase) drift adjustment 5: Execute drift adjustment of the above 1-4 6: Execute IGBT NTC calibration | | | Related Section: N/A |
| This adjustment function is enabled after parameter P2-08 is set to 20. When executing any adjustment, the external wiring connected to analog speed or torque must be removed and the servo system should be off (Servo off). | | | |

| | | | |
|--------------|--|--|-----------------------------------|
| P4-11 | SOF1 | Analog Speed Input Drift Adjustment 1 | Communication Addr.: 040BH |
| | Default: Factory setting Applicable Control Mode: ALL Unit: N/A Range: 0-32767 Settings: Manual Adjustment Operation: Set parameter P2-08 to 22 and then change this parameter. This is an auxiliary adjusting function, although this parameter allows the users can execute manual adjustment, we still do not recommend users to change the default setting manually. Auto Adjustment Operation: Set parameter P2-08 to 20 first and then set parameter P4-10 to 1. When executing this auto adjustment, please short the internal circuit of the analog input voltage first or connecting to a 0V output of the external controller in advance and make sure that the status of the servo drive is | | Related Section: N/A |

Note: When P2-08 is set to 10, users cannot reset this parameter.

| | | | |
|--------------|--|--|-----------------------------------|
| P4-12 | SOF2 | Analog Speed Input Drift Adjustment 2 | Communication Addr.: 040CH |
| | Default: Factory setting Applicable Control Mode: ALL Unit: N/A Range: 0-32767 Settings: Please see P4-11 for explanation | | Related Section: N/A |

Note: When P2-08 is set to 10, users cannot reset this parameter.

| | | | |
|--------------|-------------|---|-----------------------------------|
| P4-13 | TOF1 | Analog Torque Drift Adjustment 1 | Communication Addr.: 040DH |
|--------------|-------------|---|-----------------------------------|

Default: Factory setting

Related Section: N/A

Applicable Control Mode: ALL

Unit: N/A

Range: 0-32767

Settings:

Manual Adjustment Operation:

Set parameter P2-08 to 22 and then change this parameter. This is an auxiliary adjusting function, although this parameter allows the users can execute manual adjustment, we still do not recommend users to change the default setting manually.

Auto Adjustment Operation:

Set parameter P2-08 to 20 first and then set parameter P4-10 to 2. When executing this auto adjustment, please short the internal circuit of the analog input voltage first or connecting to a 0V output of the external controller in advance and make sure that the status of the servo drive is "Servo Off" .

Note: When P2-08 is set to 10, users cannot reset this parameter.

| | | | |
|--------------|-------------|---|-----------------------------------|
| P4-14 | TOF2 | Analog Torque Drift Adjustment 2 | Communication Addr.: 040EH |
|--------------|-------------|---|-----------------------------------|

Default: Factory setting

Related Section: N/A

Applicable Control Mode: ALL

Unit: N/A

Range: 0-32767

Settings:

Please see P4-13 for explanation.

Note: When P2-08 is set to 10, users cannot reset this parameter.

| P4-15 | COF1 | Current Detector Drift Adjustment (V1 phase) | Communication Addr.: 040FH |
|--|------|---|----------------------------|
| <p>Default: Factory setting</p> <p>Applicable Control Mode: ALL</p> <p>Unit: N/A</p> <p>Range: 0-32767</p> <p>Settings:</p> <p>Manual Adjustment Operation:</p> <p>Set parameter P2-08 to 22 and then change this parameter. This is an auxiliary adjusting function, although this parameter allows the users can execute manual adjustment, we still do not recommend users to change the default setting manually.</p> <p>Auto Adjustment Operation:</p> <p>Set parameter P2-08 to 20 first and then set parameter P4-10 to 3. When executing this auto adjustment, please short the internal circuit of the analog input voltage first or connecting to a 0V output of the external controller in advance and make sure that the status of the servo drive is “Servo Off” and the servo motor has stopped.</p> <p>Note: When P2-08 is set to 10, users cannot reset this parameter.</p> | | <p>Related Section: N/A</p> | |

| P4-16 | COF2 | Current Detector Drift Adjustment (V2 phase) | Communication Addr.: 0410H |
|--|------|---|----------------------------|
| <p>Default: Factory setting</p> <p>Applicable Control Mode: ALL</p> <p>Unit: N/A</p> <p>Range: 0-32767</p> <p>Settings:</p> <p>Please see P4-15 for explanation.</p> <p>Note: When P2-08 is set to 10, users cannot reset this parameter.</p> | | <p>Related Section: N/A</p> | |

| | | | |
|--------------|--|---|-----------------------------------|
| P4-17 | COF3 | Current Detector Drift Adjustment (W1 phase) | Communication Addr.: 0411H |
| | <p>Default: Factory setting</p> <p>Applicable Control Mode: ALL</p> <p>Unit: N/A</p> <p>Range: 0-32767</p> <p>Settings:</p> <p>Manual Adjustment Operation:</p> <p>Set parameter P2-08 to 22 and then change this parameter. This is an auxiliary adjusting function, although this parameter allows the users can execute manual adjustment, we still do not recommend users to change the default setting manually.</p> <p>Auto Adjustment Operation:</p> <p>Set parameter P2-08 to 20 first and then set parameter P4-10 to 4. When executing this auto adjustment, please short the internal circuit of the analog input voltage first or connecting to a 0V output of the external controller in advance and make sure that the status of the servo drive is “Servo Off” and the servo motor has stopped.</p> | | Related Section: N/A |

Note: When P2-08 is set to 10, users cannot reset this parameter.

| | | | |
|--------------|--|---|-----------------------------------|
| P4-18 | COF4 | Current Detector Drift Adjustment (W2 phase) | Communication Addr.: 0412H |
| | <p>Default: Factory setting</p> <p>Applicable Control Mode: ALL</p> <p>Unit: N/A</p> <p>Range: 0-32767</p> <p>Settings:</p> <p>Please see P4-15 for explanation.</p> | | Related Section: N/A |

Note: When P2-08 is set to 10, users cannot reset this parameter.

| P4-19 | TIGB | IGBT NTC Calibration | Communication Addr.: 0413H |
|--|------|----------------------|----------------------------|
| Default: Factory setting | | Related Section: N/A | |
| Applicable Control Mode: ALL | | | |
| Unit: N/A | | | |
| Range: 1~7 | | | |
| Settings: | | | |
| Manual Adjustment Operation: | | | |
| Set parameter P2-08 to 22 and then change this parameter. This is an auxiliary adjusting function, although this parameter allows the users can execute manual adjustment, we still do not recommend users to change the default setting manually. | | | |
| Auto Adjustment Operation: | | | |
| Set parameter P2-08 to 20 first and then set parameter P4-10 to 6. When executing this auto adjustment, please ensure to cool the servo drive to 25°C. | | | |
| Note: When P2-08 is set to 10, users cannot reset this parameter. | | | |

| P4-20 | DOF1 | Analog Monitor Output Drift Adjustment (CH1) | Communication Addr.: 0414H |
|---|------|--|----------------------------|
| Default: Factory setting | | Related Section: | |
| Applicable Control Mode: ALL | | Section 6.4.4 | |
| Unit: mV | | | |
| Range: -800-800 | | | |
| Settings: | | | |
| When P2-08 is set to 10, users cannot reset this parameter. | | | |

| P4-21 | DOF2 | Analog Monitor Output Drift Adjustment (CH2) | Communication Addr.: 0415H |
|---|------|--|----------------------------|
| Default: Factory setting | | Related Section: N/A | |
| Applicable Control Mode: ALL | | Section 6.4.4 | |
| Unit: mV | | | |
| Range: -800-800 | | | |
| Settings: | | | |
| When P2-08 is set to 10, users cannot reset this parameter. | | | |

| | | | |
|----------------|---|-----------------------------------|-----------------------------------|
| P4-22 | SAO | Analog Speed Input Offset | Communication Addr.: 0416H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: S | | |
| | Unit: mV | | |
| | Range: -5000-5000 | | |
| | Settings: | | |
| | In speed mode, the users can use this parameter to adjust analog speed input offset value manually. Before using this function, please short the internal circuit first or connecting to a 0V output of the external controller in advance, and then use this parameter to adjust analog speed input offset value. | | |
| P4-23 | TAO | Analog Torque Input Offset | Communication Addr.: 0417H |
| | Default: 0 | | Related Section: N/A |
| | Applicable Control Mode: T | | |
| | Unit: mV | | |
| | Range: -5000-5000 | | |
| | Settings: | | |
| | In torque mode, the users can use this parameter to adjust analog torque input offset value manually. Before using this function, please short the internal circuit first or connecting to a 0V output of the external controller in advance, and then use this parameter to adjust analog torque input offset value. | | |
| P4 - 24 | Reserved | | Communication Addr.: 0418H |
| P4 - 25 | Reserved | | Communication Addr.: 0419H |
| P4 - 26 | Reserved | | Communication Addr.: 041AH |

Table 7.A Input Function Definition

| Sign | Setting Value | Digital Input Function Description |
|--------|---------------|--|
| SON | 01 | Servo On. Switch servo to "Servo Ready". Check parameter P2-51. |
| ARST | 02 | Alarm Reset. A number of Faults (Alarms) can be cleared by activating ARST. |
| GAINUP | 03 | Gain switching in speed and position mode. When GAINUP is activated (P2-27 is set to 1), the gain is switched to the gain multiplied by fluctuation |
| CCLR | 04 | <p>Pulse clear (see P2-50). When CCLR is activated, the parameter P2-50 Pulse Deviation Clear Mode is executed.</p> <p>0: Clear position pulse deviation number (available in Pt and Pr mode only)</p> <p>1: Clear motor feedback pulse and rotation number (available in Pt and Pr mode only)</p> <p>2: Clear remaining position pulses and interrupt the motor operation (available Pr mode only).</p> <p>3: Clear remaining position pulses and interrupt the motor operation. After the motor is stopped, activate TPOS signal (available Pr mode only).</p> |
| ZCLAMP | 05 | <p>Zero speed CLAMP. When this signal is On and the motor speed value is below the setting value of P1-38, it is used to lock the motor in the instant position while ZCLAMP is On.</p> |
| CMDINV | 06 | Command input reverse control. When the drive is in Pr, Speed and Torque mode, and CMDINV is activated, the motor is in reverse rotation. |
| HOLD | 07 | Position command pause (Internal position control only). When the drive is in Pr mode and HOLD is activated, the motor will pause. |
| CTRG | 08 | Command triggered (available in Pr mode only). When the drive is in Pr mode and CTRG is activated, the drive will command the motor to move the stored position which correspond the POS 0, POS 1, POS 2 settings. Activation is triggered on the rising edge of the pulse. The next internal position command will be triggered after the DO ZSPD (At Zero speed) signal is activated (ZSPD=1). |

| Sign | Setting Value | Digital Input Function Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------|---------------|---|-------------|------|----------------|------|----------------|----------------|----|-----|-----|-----|---|----------------|----|-----|-----|----|---|----------------|----|-----|----|-----|---|----------------|----|-----|----|----|---|----------------|----|----|-----|-----|---|----------------|------|----|---|----|----|-----|----|---|----------------|----|----|----|-----|---|----------------|----|----|----|----|---|----------------|
| TRQLM | 09 | Torque limit enabled. When the drive is in speed and position mode, and TRQLM is activated, it indicates the torque limit command is valid. The torque limit command source is internal parameter or analog voltage. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SPDLM | 10 | Speed limit enabled. When the drive is in torque mode and TRQLM is activated, it indicates the speed limit command is valid. The speed limit command source is internal parameter or analog voltage. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| POS0 | 11 | Position command selection 0 - 2 When the Pr mode is selected, the 8 stored positions are programmed via a combination of the POS 0, POS 1, and POS 2 commands. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| POS1 | 12 | <table border="1"> <thead> <tr> <th>Command No.</th> <th>POS2</th> <th>POS1</th> <th>POS0</th> <th>CTRG</th> <th>Parameter</th> </tr> </thead> <tbody> <tr> <td>P1</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>↑</td> <td>P1-15 P1-16</td> </tr> <tr> <td>P2</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>↑</td> <td>P1-17 P1-18</td> </tr> <tr> <td>P3</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>↑</td> <td>P1-19 P1-20</td> </tr> <tr> <td>P4</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>↑</td> <td>P1-21 P1-22</td> </tr> <tr> <td>P5</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>↑</td> <td>P1-23 P1-24</td> </tr> <tr> <td rowspan="4">POS2</td> <td rowspan="4">13</td> <td> <table border="1"> <tbody> <tr> <td>P6</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>↑</td> <td>P1-25 P1-26</td> </tr> <tr> <td>P7</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>↑</td> <td>P1-27 P1-28</td> </tr> <tr> <td>P8</td> <td>ON</td> <td>ON</td> <td>ON</td> <td>↑</td> <td>P1-29 P1-30</td> </tr> </tbody> </table> </td> </tr> </tbody> </table> | Command No. | POS2 | POS1 | POS0 | CTRG | Parameter | P1 | OFF | OFF | OFF | ↑ | P1-15 P1-16 | P2 | OFF | OFF | ON | ↑ | P1-17 P1-18 | P3 | OFF | ON | OFF | ↑ | P1-19 P1-20 | P4 | OFF | ON | ON | ↑ | P1-21 P1-22 | P5 | ON | OFF | OFF | ↑ | P1-23 P1-24 | POS2 | 13 | <table border="1"> <tbody> <tr> <td>P6</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>↑</td> <td>P1-25 P1-26</td> </tr> <tr> <td>P7</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>↑</td> <td>P1-27 P1-28</td> </tr> <tr> <td>P8</td> <td>ON</td> <td>ON</td> <td>ON</td> <td>↑</td> <td>P1-29 P1-30</td> </tr> </tbody> </table> | P6 | ON | OFF | ON | ↑ | P1-25 P1-26 | P7 | ON | ON | OFF | ↑ | P1-27 P1-28 | P8 | ON | ON | ON | ↑ | P1-29 P1-30 |
| | | Command No. | POS2 | POS1 | POS0 | CTRG | Parameter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | P1 | OFF | OFF | OFF | ↑ | P1-15 P1-16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | P2 | OFF | OFF | ON | ↑ | P1-17 P1-18 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | P3 | OFF | ON | OFF | ↑ | P1-19 P1-20 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P4 | OFF | ON | ON | ↑ | P1-21 P1-22 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P5 | ON | OFF | OFF | ↑ | P1-23 P1-24 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| POS2 | 13 | <table border="1"> <tbody> <tr> <td>P6</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>↑</td> <td>P1-25 P1-26</td> </tr> <tr> <td>P7</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>↑</td> <td>P1-27 P1-28</td> </tr> <tr> <td>P8</td> <td>ON</td> <td>ON</td> <td>ON</td> <td>↑</td> <td>P1-29 P1-30</td> </tr> </tbody> </table> | P6 | ON | OFF | ON | ↑ | P1-25 P1-26 | P7 | ON | ON | OFF | ↑ | P1-27 P1-28 | P8 | ON | ON | ON | ↑ | P1-29 P1-30 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | P6 | ON | OFF | ON | ↑ | P1-25 P1-26 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | P7 | ON | ON | OFF | ↑ | P1-27 P1-28 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | P8 | ON | ON | ON | ↑ | P1-29 P1-30 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Sign | Setting Value | Digital Input Function Description | | | | | | | |
|------|---------------|---|------------------|-----|-------------------------|---------------------|--------------------|---------|-------|
| SPDO | 14 | Speed command selection 0 - 1 | | | | | | | |
| | | Command No. | DI signal of CN1 | | Command Source | | | Content | Range |
| SPD1 | SPDO | | Mode | S | External analog command | Speed command is 0 | | | |
| SPD1 | 15 | S1 | | OFF | OFF | | Internal parameter | Sz | None |
| | | S2 | OFF | ON | P1-09 | 0-5000 r/min | | | |
| | | S3 | ON | OFF | P1-10 | +/- 5000 r/min | | | |
| | | S4 | ON | ON | P1-11 | +/- 5000 r/min | | | |
| TCMO | 16 | Torque command selection 0 - 1 | | | | | | | |
| | | Command No. | DI signal of CN1 | | Command Source | | | Content | Range |
| SPD1 | SPDO | | Mode | T | Analog command | Torque command is 0 | | | |
| TCM1 | 17 | T1 | | OFF | OFF | | Internal parameter | Tz | None |
| | | T2 | OFF | ON | P1-12 | +/- 300 % | | | |
| | | T3 | ON | OFF | P1-13 | +/- 300 % | | | |
| | | T4 | ON | ON | P1-14 | +/- 300 % | | | |
| S-P | 18 | Speed / Position mode switching (OFF: Speed, ON: Position) (see section 6.5) | | | | | | | |
| S-T | 19 | Speed / Torque mode switching (OFF: Speed, ON: Torque) (see section 6.5) | | | | | | | |
| T-P | 20 | Torque / Position mode switching (OFF: Torque, ON: Position) (see section 6.5) | | | | | | | |
| EMGS | 21 | Emergency stop. It should be contact “b” and normally ON or a fault (ALE13) will display. | | | | | | | |
| CWL | 22 | Reverse inhibit limit. It should be contact “b” and normally ON or a fault (ALE14) will display. | | | | | | | |
| CCWL | 23 | Forward inhibit limit. It should be contact “b” and normally ON or a fault (ALE15) will display. | | | | | | | |
| ORGP | 24 | Reference “Home” sensor. When ORGP is activated, the drive will command the motor to start to search the reference “Home” sensor. [see P1-47] | | | | | | | |
| TLLM | 25 | Torque limit - Reverse operation (Torque limit function is valid only when P1-02 is enabled) | | | | | | | |

| Sign | Setting Value | Digital Input Function Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------|---------------|--|--|-------------------------|--|------|--------|-----|-----|-------------|-----|---|-----|-----|-----------------|---|-----|----|-------------|---|----|-----|-------------------------|---|----|----|----------------|----|--|---|---|------------|--|-----|----|----------------------|--|----|-----|---------------------|--|---|---|------------------|
| TRLM | 26 | Torque limit - Forward operation (Torque limit function is valid only when P1-02 is enabled) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SHOM | 27 | Move to "Home". When SHOM is activated, the drive will command the motor to move to "Home" . [see P1-47] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| INDEX0 | 28 | Feed step selection input 0 (bit 0) | When the drive is in Pr mode, if users set P1-33 to 2, 3 and 4 (Feed step control mode), feed step control function are provided (1-32 steps). [see section 12.6 Feed Step Control] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| INDEX1 | 29 | Feed step selection input 1 (bit 1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| INDEX2 | 30 | Feed step selection input 2 (bit 2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| INDEX3 | 31 | Feed step selection input 3 (bit 3) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| INDEX4 | 32 | Feed step selection input 4 (bit 4) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MD0 | 33 | Feed step mode input 0 (bit 0) | Mode function: | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MD1 | 34 | Feed step mode input 1 (bit 1) | <table border="1"> <thead> <tr> <th>MDPn</th> <th>Status</th> <th>MD1</th> <th>MD0</th> <th>Explanation</th> </tr> </thead> <tbody> <tr> <td rowspan="4">OFF</td> <td>1</td> <td>OFF</td> <td>OFF</td> <td>Torque decrease</td> </tr> <tr> <td>2</td> <td>OFF</td> <td>ON</td> <td>Homing mode</td> </tr> <tr> <td>3</td> <td>ON</td> <td>OFF</td> <td>Feed step position mode</td> </tr> <tr> <td>4</td> <td>ON</td> <td>ON</td> <td>Emergency stop</td> </tr> <tr> <td rowspan="4">ON</td> <td></td> <td>X</td> <td>X</td> <td>Don't care</td> </tr> <tr> <td></td> <td>OFF</td> <td>ON</td> <td>CCW manual operation</td> </tr> <tr> <td></td> <td>ON</td> <td>OFF</td> <td>CW manual operation</td> </tr> <tr> <td></td> <td>X</td> <td>X</td> <td>Don't Don't care</td> </tr> </tbody> </table> | | | MDPn | Status | MD1 | MD0 | Explanation | OFF | 1 | OFF | OFF | Torque decrease | 2 | OFF | ON | Homing mode | 3 | ON | OFF | Feed step position mode | 4 | ON | ON | Emergency stop | ON | | X | X | Don't care | | OFF | ON | CCW manual operation | | ON | OFF | CW manual operation | | X | X | Don't Don't care |
| MDPn | Status | MD1 | MD0 | Explanation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OFF | 1 | OFF | OFF | Torque decrease | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | OFF | ON | Homing mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 | ON | OFF | Feed step position mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 4 | ON | ON | Emergency stop | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ON | | X | X | Don't care | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | OFF | ON | CCW manual operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | ON | OFF | CW manual operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | X | X | Don't Don't care | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MDP0 | 35 | Manually continuous operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MDP1 | 36 | Manually single step operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| JOGU | 37 | Forward JOG input. When JOGU is activated, the motor will JOG in forward direction. [see P4-05] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| JOGD | 38 | Reverse JOG input. When JOGD is activated, the motor will JOG in reverse direction. [see P4-05] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| STEPU | 39 | Step up input. When STEPUP is activated, the motor will run to next position. | Available when the drive is in Pr mode and users must set P1-33 to 5 and 6. (Internal auto running mode) [see section 12-7 Internal Auto Running Mode] | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Sign | Setting Value | Digital Input Function Description | |
|-------|---------------|--|--|
| STEPD | 40 | Step down input. When STEPD is activated, the motor will run to previous position. | Available when the drive is in Pr mode and users must set P1-33 to 5 and 6. (Internal auto running mode) [see section 12-7 Internal Auto Running Mode] |
| STEPB | 41 | Step back input. When STEPB is activated, the motor will return to first position. | |
| AUTOR | 42 | Auto run input. When AUTOR is activated, the motor will run automatically according to internal position command. For interval time setting (Timer 0 ~ 7), please see parameter P2-52 to P2-59. If the timer is not set, the internal position command without setting timer will be passed over and not executed. The motor will run according to the next internal position command. | |
| GNUMO | 43 | Electronic gear ratio (Numerator) selection 0 [see P2-60 ~ P2-62] | |
| GNUM1 | 44 | Electronic gear ratio (Numerator) selection 1 [see P2-60 ~ P2-62] | |


| Sign | Setting Value | Digital Input Function Description | | | | | | | | | | | | | | | |
|--|---------------|--|-----|---|-------------|---|---|---|---|---|------|---|---|------|---|---|--|
| INHP | 45 | Pulse inhibit input. When the drive is in position mode, if INHP is activated, the external pulse input command is not valid. | | | | | | | | | | | | | | | |
| STF | 46 | Enable motor forward operation. In speed mode, it is used to enable the motor forward operation. | | | | | | | | | | | | | | | |
| STB | 47 | Enable motor reverse operation. In speed mode, it is used to enable the motor reverse operation. | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>STF</th> <th>STB</th> <th>Explanation</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>0</td> <td>Forward operation of speed command (CCWL)</td> </tr> <tr> <td>1</td> <td>1</td> <td>Stop</td> </tr> <tr> <td>0</td> <td>0</td> <td>Stop</td> </tr> <tr> <td>0</td> <td>1</td> <td>Reverse operation of speed command (CWL)</td> </tr> </tbody> </table> | STF | STB | Explanation | 1 | 0 | Forward operation of speed command (CCWL) | 1 | 1 | Stop | 0 | 0 | Stop | 0 | 1 | Reverse operation of speed command (CWL) |
| | | STF | STB | Explanation | | | | | | | | | | | | | |
| | | 1 | 0 | Forward operation of speed command (CCWL) | | | | | | | | | | | | | |
| | | 1 | 1 | Stop | | | | | | | | | | | | | |
| 0 | 0 | Stop | | | | | | | | | | | | | | | |
| 0 | 1 | Reverse operation of speed command (CWL) | | | | | | | | | | | | | | | |
| 0: indicates OFF (Normally Open); 1: indicates ON (Normally Closed) Please note that never use DI STF and STB with DI SPDO and SPD1 simultaneously. | | | | | | | | | | | | | | | | | |

Note:

- 1) 11 - 17: Single control mode, 18-20: Dual control mode
- 2) When P2-10 to P2-17 is set to 0, it indicates input function is disabled.

Table 7.B Output Function Definition

| Sign | Setting Value | Digital Output Function Description |
|------|---------------|--|
| SRDY | 01 | Servo ready. SRDY is activated when the servo drive is ready to run. All fault and alarm conditions, if present, have been cleared. |
| SON | 02 | Servo On. SON is activated when control power is applied the servo drive. The drive may or may not be ready to run as a fault / alarm condition may exist. Servo ON (SON) is “ON” with control power applied to the servo drive, there may be a fault condition or not. The servo is not ready to run. Servo ready (SRDY) is “ON” where the servo is ready to run, NO fault / alarm exists. (P2-51 should turn servo ready SRDY off / on) |
| ZSPD | 03 | At Zero speed. ZSPD is activated when the drive senses the motor is equal to or below the Zero Speed Range setting as defined in parameter P1-38. For Example, at default ZSPD will be activated when the drive detects the motor rotating at speed at or below 10 r/min. ZSPD will remain activated until the motor speed increases above 10 r/min. |
| TSPD | 04 | At Speed reached. TSPD is activated once the drive has detected the motor has reached the Target Motor Speed setting as defined in parameter P1-39. TSPD will remain activated until the motor speed drops below the Target Motor Speed. |
| TPOS | 05 | At Positioning completed. When the drive is in Pt mode, TPOS will be activated when the position error is equal and below the setting value of P1-54. When the drive is in Pr mode, TPOS will be activated when the drive detects that the position of the motor is in a P1-54 to +P1-54 band of the target position. For Example, at factory default TPOS will activate once the motor is in -99 pulses range of the target position, then deactivate after it reaches +99 pulses range of the desired position. |

| Sign | Setting Value | Digital Output Function Description |
|------|---------------|--|
| TQL | 06 | At Torques limit. TQL is activated when the drive has detected that the motor has reached the torques limits set by either the parameters P1-12 - P1-14 of via an external analog voltage. |
| ALRM | 07 | Servo alarm (Servo fault) activated. ALRM is activated when the drive has detected a fault condition. (However, when Reverse limit error, Forward limit error, Emergency stop, Serial communication error, and Undervoltage these fault occur, WARN is activated first.) |
| BRKR | 08 | Electromagnetic brake control. BRKR is activated (Actuation of motor brake). (Please refer to parameters P1-42 - P1-43)  <p>The diagram shows the relationship between digital signals and motor speed during brake actuation. SON (Servo ON) is a pulse that starts before MBT1 (P1-42) and ends after MBT2 (P1-43). BRKR (Brake Release) is a pulse that starts at MBT1 and ends at MBT2. Motor speed ramps up before MBT1 and ramps down after MBT2. ZSPD (P1-38) is a signal that becomes active (ON) when the motor speed reaches zero.</p> |
| HOME | 09 | Homing completed. HOME is activated when the servo drive has detected that the "HOME" sensor (Digital Input 24) has been detected and the home conditions set in parameters P1-47, P1-50, and P1-51 have been satisfied. |

MODBUS Communications



8

At a Glance

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|---|------|
| Communication Hardware Interface | 270 |
| Communication Parameter Settings | 271 |
| MODBUS Communication Protocol | 275 |
| Communication Parameter Write-in and Read-out | 283 |


8.1 Communication Hardware Interface

The Lexium 23 series servo drives have three modes of communication: RS-232, RS-485, and RS-422. All aspects of control, operation and monitoring as well as programming of the controller can be achieved via communication. However, only one communication mode can be used at a time. Users can select the desired communication mode via parameter P3-05.


Please refer to the following sections for connections and limitations.

RS-232

- **Configuration**



- **Cable Connection**



Note:

- 1) Recommended maximum cable length is 15m (50ft.). Please note, RFI / EME noise should be kept to a minimum, communication cable should be kept apart from high voltage wires. If a transmission speed of 38400 bps or greater is required, the maximum length of the communication cable is 3m (9.84ft.) which will ensure the correct and desired baud rate.
- 2) The number shown in the previous figure indicates the terminal number of each connector.


8.2 Communication Parameter Settings

The following describes the communication addresses for the communication parameters.

For communication parameters, please refer to the Chapter 7. Communication Addresses 0301, 0302, and 0305 have to be set identically for all the drives and devices to communicate correctly.

| | |
|---|----------------------------|
| 0300H Communication Address Setting | Default: 1 Range: 1~254 |
|---|----------------------------|

If the AC servo drive is controlled by RS-232/485/422 communication, each drive (or device) must be uniquely identified and addressed between 1 and 254. Access to program this number is via parameter P3-00.



| | |
|--------------------------------|--|
| 0301H Transmission Speed | Default: 1 Range: 0~5 Settings: 0: Baud rate 4800 (data transmission speed: bits / second) 1: Baud rate 9600 (data transmission speed: bits / second) 2: Baud rate 19200 (data transmission speed: bits / second) 3: Baud rate 38400 (data transmission speed: bits / second) 4: Baud rate 57600 (data transmission speed: bits / second) 5: Baud rate 115200 (data transmission speed: bits / second) |
|--------------------------------|--|

This parameter is used to set the desired transmission speed between the computer and AC servo drive.

Users can set this parameter and control transmission speed to reach the maximum baud rate of 115200 bps.

| | |
|---|--|
| <p>0302H Communication Protocol</p> | <p>Default: 0 Range: 0-8 Settings: 0: Modbus ASCII mode, <7,N,2> 1: Modbus ASCII mode, <7,E,1 > 2: Modbus ASCII mode, <7,O,1> 3: Modbus ASCII mode, <8,N,2 > 4: Modbus ASCII mode, <8,E,1> 5: Modbus ASCII mode, <8,O,1> 6: Modbus RTU mode, <8,N,2> 7: Modbus RTU mode, <8,E,1> 8: Modbus RTU mode, <8,O,1></p> |
|---|--|

This parameter is used to set the communication protocol. The alphanumeric characters represent the following: 7 or 8 is the number of data bits; N, E or O refer to the parity bit, Non, Even or Odd; the 1 or 2 is the numbers of stop bits.

| | |
|---|---|
| <p>0303H Transmission Fault Treatment</p> | <p>Default: 0 Range: 0- 1 Settings: 0: Display fault and continue operating 1: Display fault and stop operating</p> |
|---|---|

This parameter is used to determine the operating sequence once a communication fault has been detected. If '1' is selected the drive will stop operating upon detection the communication fault. The mode of stopping is set by parameter P1-32.

| | |
|---|---|
| <p>0304H Communication Time Out Detection</p> | <p>Watch Dog Timer (It is not recommended to change the factory default setting if not necessary) Default: 0 Range: 0-20 sec. The factory default setting is set to 0 and it indicates this function is disabled.</p> |
|---|---|

When this parameter is set to any value over 0, it indicates that the timer is enabled. The value set in this parameter is the communication time and the communication time out detection should be completed within the time. Otherwise, a communication error will occur.

For example, if the value set in this parameter is 5, it indicates that the communication time out detection will be activated once in five seconds or a communication error will occur.

| | |
|--------------------------------|--|
| 0305H Communication Mode | Communication selection: Default: 0 Range: 0-2 Settings: 0: RS-232 1: RS-422 2: RS-485 |
|--------------------------------|--|

Multiple communication modes RS232, RS-485, RS-422 cannot be used within one communication ring.

| | |
|---|--|
| 0306H Digital Input Communication Function | Digital Input Contact Control: Default: 0 Range: 0-FFFF (hexadecimal number) |
|---|--|

The setting of this parameter determines how the Digital Inputs (DI) accept commands and signals.

Input commands or signals through the DI can be either from an external source, through the CN 1 interface connector, or via communication, (RS-232, RS-485, RS-422). If the Digital Input Contact Control parameter for the DI 1 ~ 8 is set to "0", command is external, and via CN1; if it is set to "1" (decimal number) the DI signal is via communication. Each of the eight Digital Inputs are accessed individually and can be set independently of each other. They can be programmed either via the drive's keypad or via communication and computer UI. If they are programmed via the keypad a hexadecimal number is entered; if programmed via communication or UI a decimal or hexadecimal number can be used. In both methods of programming, a single number is used for all eight Digital Inputs. The following example shows how each DI is addressed and converted to a single decimal or hexadecimal number.

The eight Digital Inputs are noted from the right, DI 1 to left, DI 8 with their desired input command or signal method, 0 or 1. Once all eight Digital Inputs have been noted this binary number is converted to a decimal or hexadecimal number and entered into P3-06.

| | | | | | | | | | |
|---------------|-----|-----|-----|-----|-----|-----|-----|-----|--|
| Bit | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | |
| Decimal value | 128 | 64 | 32 | 16 | 8 | 4 | 2 | 1 | |
| Input | DI8 | DI7 | DI6 | DI5 | DI4 | DI3 | DI2 | DI1 | |
| State | 1 | 1 | 0 | 1 | 1 | 0 | 0 | 0 | = D8 Hex (Keypad, Communication or UI) or = 216 Dec (Communication or UI only) |

Please see Chapter 4.4.5 DI Signal Display Diagnosis Operation for display layout of the Digital Signal selection.

The Digital Input Control Contact parameter, P3-06 also works in conjunction with the Multi Function Digital Input parameter P4-07 which has several functions. The contents of P4-07 is "read only" via the drive keypad and will display the state on or off ("blank" or "|") of the eight Digital Inputs which have been set in accordance to P3-06. For Example; if P3-06 has been set to 0 (All DI is external and via the CN 1 interface) and the P4-07 display is indicating the following:

_ | | | _ _ _ | (for the manual this picture should be similar to the one shown on page 4-8 (Ch 4.4.5))

The Digital Inputs 1, 5, 6, & 7 are "on" (high) and Digital Inputs 2, 3, 4, & 8 are "off" (low).

If the contents of P4-07 is being read via communication the output will be a decimal number that will represent the "binary" display. Therefore in the previous example the decimal number being read would be 113.

However, in the communication mode the user can write to P4-07 to turn the Digital Inputs either "on" or "off". Again this achieved by sending a decimal or hexadecimal number that corresponds to the binary representation of the Digital Inputs being addressed. Therefore in the previous example 113 or 71 hex would be sent to 407H to switch on Digital Inputs 1, 5, 6, & 7. Remember, previous to this P3-06 would have been set to either 255 / FF or 113 / 71 (This sets the Digital Inputs 1, 5, 6, & 7 to communication).

| | |
|--|----------------------------|
| 0307H Communication Response Delay Time | Default: 0 Range: 0-255 |
|--|----------------------------|

This parameter is used to delay the communication time that servo drive respond to host controller (external controller)

8.3 MODBUS Communication Protocol

When using RS-232/485/422 serial communication interface, each Lexium 23 series AC servo drive has a pre-assigned communication address specified by parameter "P3-00". The computer then controls each AC servo drive according to its communication address. Lexium 23 series AC servo drives can be set up to communicate on a MODBUS networks using one of the following modes: ASCII (American Standard Code for Information Interchange) or RTU (Remote Terminal Unit). Users can select the desired mode along with the serial port communication protocol in parameter "P3-02".

Code Description: ASCII Mode:

Each 8-bit data is the combination of two ASCII characters. For example, a 1-byte data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex). The following table shows the available hexadecimal characters and their corresponding ASCII codes.


| | | | | | | | | |
|------------|-----|-----|-----|-----|-----|-----|-----|-----|
| Character | '0' | '1' | '2' | '3' | '4' | '5' | '6' | '7' |
| ASCII code | 30H | 31H | 32H | 33H | 34H | 35H | 36H | 37H |
| Character | '8' | '9' | 'A' | 'B' | 'C' | 'D' | 'E' | 'F' |
| ASCII code | 38H | 39H | 41H | 42H | 43H | 44H | 45H | 46H |

RTU Mode:


Each 8-bit data is the combination of two 4-bit hexadecimal characters. For example, a 1-byte data: 64 Hex.

Data Format:

10-bit character frame (For 7-bit character)



11-bit character frame (For 8-bit character)



Communication Protocol:

ASCII Mode:

| | |
|------------|---|
| STX | Start character: ' (3AH) |
| ADR | Communication address: 1-byte consists of 2 ASCII codes |
| CMD | Command code: 1-byte consists of 2 ASCII codes |
| DATA (n-1) | Contents of data: n word = n x 2-byte consists of n x 4 ASCII codes, n≤12 |
| | |
| DATA (0) | |
| LRC | Command code: 1-byte consists of 2 ASCII codes |
| End 1 | End code 1: (ODH) (CR) |
| End 0 | End code 0: (OAH) (LF) |

RTU Mode:

| | |
|-----------|---|
| STX | A silent interval of more than 10ms |
| ADR | Communication address: 1-byte |
| CMD | Command code: 1-byte |
| DATA(n-1) | Contents of data: n word = n x 2-byte, n≤12 |
| | |
| DATA(0) | |
| CRC | Command code: 1-byte |
| End 1 | A silent interval of more than 10ms |

STX (Communication Start)

ASCII Mode: ':' character

RTU Mode: A silent interval of more than 10ms

ADR (Communication Address)

The valid communication addresses are in the range of 1 to 254.

For example, communication to AC servo drive with address 16 decimal:

ASCII Mode: ADR='1','0' => '1'=31H,'0'=30H

RTU Mode: ADR = 10H

CMD (Command Codes) and DATA (Data Characters)

The format of data characters depends on the command code. The available command codes and examples for AC servo drive are described as follows:

Command code: 03H, read N words. The maximum value of N is 10.

For example, reading continuous 2 words from starting address 0200H of AC servo drive with address 01H.

ASCII Mode:

Command message:

| | |
|-----------------------|------------|
| STX | ':' |
| ADR | '0' |
| | '1' |
| CMD | '0' |
| | '3' |
| Starting data address | '0' |
| | '2' |
| | '0' |
| | '0' |
| Number of data | '0' |
| | '0' |
| | '0' |
| | '2' |
| LRC Check | 'F' |
| | '8' |
| End 1 | (ODH) (CR) |
| End 0 | (0AH) (LF) |

Response message:

| | |
|--|------------|
| STX | ':' |
| ADR | '0' |
| | '1' |
| CMD | '0' |
| | '3' |
| Number of data (Count by byte) | '0' |
| | '4' |
| Contents of starting data address 0200H | '0' |
| | '0' |
| | 'B' |
| | '1' |
| Contents of second data address 0201H | '1' |
| | 'F' |
| | '4' |
| | '0' |
| LRC Check | 'E' |
| | '8' |
| End 1 | (ODH) (CR) |
| End 0 | (0AH) (LF) |

RTU Mode:

Command message:

| | |
|--------------------------------|-------------------|
| ADR | 01H |
| CMD | 03 |
| Starting data address | 02H (Upper bytes) |
| | 00H (Lower bytes) |
| Number of data (Count by word) | 00H |
| | 02H |
| CRC Check Low | C5H (Lower bytes) |
| CRC Check High | B3H (Upper bytes) |

Response message:

| | |
|---|-------------------|
| ADR | 01H |
| CMD | 03H |
| Number of data (Count by byte) | 04H |
| Contents of starting data address 0200H | 00H (Upper bytes) |
| | B1H (Lower bytes) |
| Contents of second data address 0201H | 1FH (Upper bytes) |
| | 40H (Lower bytes) |
| CRC Check Low | A3H (Lower bytes) |
| CRC Check High | D4H (Upper bytes) |

Command code: 06H, write 1 word

For example, writing 100 (0064H) to starting data address 0200H of Lexium 23 series with address 01H.

ASCII Mode:

Command message:

| | |
|-----------------------|------------|
| STX | ‘:’ |
| ADR | ‘0’ |
| | ‘1’ |
| CMD | ‘0’ |
| | ‘6’ |
| Starting data address | ‘0’ |
| | ‘2’ |
| | ‘0’ |
| | ‘0’ |
| Content of data | ‘0’ |
| | ‘0’ |
| | ‘6’ |
| | ‘4’ |
| LRC Check | ‘9’ |
| | ‘3’ |
| End 1 | (0DH) (CR) |
| End 0 | (0AH) (LF) |

Response message:

| | |
|-----------------------|------------|
| STX | ‘:’ |
| ADR | ‘0’ |
| | ‘1’ |
| CMD | ‘0’ |
| | ‘6’ |
| Starting data address | ‘0’ |
| | ‘2’ |
| | ‘0’ |
| | ‘0’ |
| Content of data | ‘0’ |
| | ‘0’ |
| | ‘6’ |
| | ‘4’ |
| LRC Check | ‘9’ |
| | ‘3’ |
| End 1 | (0DH) (CR) |
| End 0 | (0AH) (LF) |

RTU Mode:

Command message:

| | |
|-----------------------|-------------------|
| ADR | 01H |
| CMD | 06H |
| Starting data address | 02H (Upper bytes) |
| | 00H (Lower bytes) |
| Content of data | 00H (Upper bytes) |
| | 64H (Lower bytes) |
| CRC Check Low | 89H (Lower bytes) |
| CRC Check High | 99H (Upper bytes) |

Response message:

| | |
|-----------------------|-------------------|
| ADR | 01H |
| CMD | 06H |
| Starting data address | 02H (Upper bytes) |
| | 00H (Lower bytes) |
| Content of data | 00H (Upper bytes) |
| | 64H (Lower bytes) |
| CRC Check Low | 89H (Lower bytes) |
| CRC Check High | 99H (Upper bytes) |

LRC (ASCII Mode):

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, the values of the bytes from ADR to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

For example, reading 1 word from address 0201H of the Lexium 23 series servo drive with address 01H.

| | |
|-----------------------|------------|
| STX | ':' |
| ADR | '0' |
| | '1' |
| CMD | '0' |
| | '3' |
| Starting data address | '0' |
| | '2' |
| | '0' |
| | '1' |
| Number of data | '0' |
| | '0' |
| | '0' |
| | '1' |
| LRC Check | 'F' |
| | '8' |
| End 1 | (0DH) (CR) |
| End 0 | (0AH) (LF) |

$01H+03H+02H+01H+00H+01H = 08H$, the 2's complement negation of 08H is F8H. Hence, we can know that LRC CHK is 'F','8'.

CRC (RTU Mode):

CRC (Cyclical Redundancy Check) is calculated by the following steps:

- Step 1: Load a 16-bit register (called CRC register) with FFFFH.
- Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.
- Step 3: Extract and examine the LSB. If the LSB of CRC register is 0, shift the CRC register one bit to the right. If the LSB of CRC register is 1, shift the CRC register one bit to the right, then Exclusive OR the CRC register with the polynomial value A001H.
- Step 4: Repeat step 3 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed, then perform step 5.
- Step 5: Repeat step 2 to step 4 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value.

Note:

- 1) When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.
- 2) For example, reading 2 words from address 0101H of the AC servo drive with address 01H. The final content of the CRC register from ADR to last data character is 3794H, then the command message is shown as follows. What should be noticed is that 94H have to be transmitted before 37H.

Command Message:

| | |
|--------------------------------|-------------------|
| ARD | 01H |
| CMD | 03H |
| Starting data address | 01H (Upper byte) |
| | 01H (Lower bytes) |
| Number of data (Count by word) | 00H (Upper bytes) |
| | 02H (Lower bytes) |
| CRC Check Low | 94H (Lower bytes) |
| CRC Check High | 37H (Upper bytes) |

End1, End0 (Communication End)**ASCII Mode:**

In ASCII mode, (0DH) stands for character '\r' (carriage return) and (0AH) stands for character '\n' (new line), they indicate communication end.

RTU Mode:

In RTU mode, a silent interval of more than 10ms indicates communication end.

The following is an example of CRC generation using C language. The function takes two arguments:

unsigned char* data;

unsigned char length

The function returns the CRC value as a type of unsigned integer.

```
unsigned int crc_chk(unsigned char* data, unsigned char length) {
    int j;
    unsigned int reg_crc=0xFFFF;

    while( length-- ) {
        reg_crc ^= *data++;
        for (j=0; j<8; j++) {
            if( reg_crc & 0x01 ) { /*LSB(bit 0) = 1 */
                reg_crc = (reg_crc >> 1)^0xA001;
            } else {
                reg_crc = (reg_crc>>1);
            }
        }
    }
    return reg_crc;
}
```

PC communication program example:

```
#include<stdio.h>
#include<dos.h>
#include<conio.h>
#include<process.h>
#define PORT 0x03F8      /* the address of COM 1 */
#define THR 0x0000
#define RDR 0x0000
#define BRDL 0x0000
#define IER 0x0001
#define BRDH 0x0001
#define LCR 0x0003
#define MCR 0x0004
#define LSR 0x0005
#define MSR 0x0006
unsigned char rdat[60];
/* read 2 data from address 0200H of ASD with address 1 */
unsigned char tdat[60]={':','0','1','0','3','0','2','0','0','0','0','2','F','8','\r','\n'};
void main() {
```

```

int I;
outputb(PORT+MCR,0x08);    /* interrupt enable */
outputb(PORT+IER,0x01);    /* interrupt as data in */
outputb(PORT+LCR,( inportb(PORT+LCR) | 0x80 ) );
/* the BRDL/BRDH can be access as LCR.b7 == 1 */
outputb(PORT+BRDL,12);
outputb(PORT+BRDH,0x00);
outputb(PORT+LCR,0x06);    /* set protocol
                            <7,E,1> = 1AH,    <7,O,1> = 0AH
                            <8,N,2> = 07H    <8,E,1> = 1BH
                            <8,O,1> = 0BH                                     */

for( I = 0; I<=16; I++ ) {
    while( !(inportb(PORT+LSR) & 0x20) ); /* wait until THR empty */
    outputb(PORT+THR,tdat[I]);           /* send data to THR */
}
I = 0;
while( !kbhit() ) {
    if( inportb(PORT+LSR)&0x01 ) { /* b0==1, read data ready */
        rdat[I++] = inportb(PORT+RDR); /* read data from RDR */
    }
}
}
}

```

8.4 Communication Parameter Write-in and Read-out

There are following five groups for parameters:

| | |
|----------------------------------|------------------|
| Group 0: Monitor parameter | (example: P0-xx) |
| Group 1: Basic parameter | (example: P1-xx) |
| Group 2: Extension parameter | (example: P2-xx) |
| Group 3: Communication parameter | (example: P3-xx) |
| Group 4: Diagnosis parameter | (example: P4-xx) |

For a complete listing and description of all parameters, refer to Chapter 7.

Communication write-in parameters for Lexium 23 series are including:

Group 0: P0-02 ~ P0-17 (0002H to 0011H)

Group 1: P1-00 ~ P1-62 (0100H to 013EH)

Group 2: P2-00 ~ P2-65 (0200H to 0241H)

Group 3: P3-00 ~ P3-07 (0300H to 0307H)

Group 4: P4-05 ~ P4-23 (0405H to 0417H)

Note:

- 1) P3-01 After the new transmission speed is set, the next data will be written in new transmission speed.
 - 2) P3-02 After the new communication protocol is set, the next data will be written in new communication protocol.
 - 3) P4-05 JOG control of servo motor. For the description, refer to Chapter 7.
 - 4) P4-06 Force output contact control. This parameter is for the users to test if DO (Digit output) is normal. User can set 1, 2, 3, 4, 5 to test DO0, DO1, DO2, DO3, DO4, respectively. After the test has been completed, please set this parameter to 0 to inform the drive that the test has been completed.
 - 5) P4-10 Adjustment function selection. If user desires to change the settings of this parameter, user has to set the value of the parameter P2-08 to 20 (hexadecimal: 14H) first and then restart.
After restarting, the settings of parameter P4-10 can become modified.
 - 6) P4-11 ~ P4-21 These parameters are for offset adjustment. Do not change the factory default setting if not necessary. If the user desires to change the settings of these parameters, the user has to set the value of the parameter P2-08 to 22 (hexadecimal: 16H) first and then restart. After restarting, the settings of parameters P4-11 to P4-21 can become modified.
-

Communication read-out parameters for Lexium 23 series are including:

Group 0: P0-00 ~ P0-17 (0000H to 0011H)

Group 1: P1-00 ~ P1-62 (0100H to 013EH)

Group 2: P2-00 ~ P2-65 (0200H to 0241H)

Group 3: P3-00 ~ P3-07 (0300H to 0307H)

Group 4: P4-00 ~ P4-23 (0400H to 0417H)

Maintenance and Inspection

9

At a Glance

Presentation

Lexium 23 servo drives are based on solid state electronics technology. Preventive maintenance is required to operate this Lexium 23 servo drives in its optimal condition, and to ensure a long life. It is recommended to perform a periodic maintenance and inspection of the Lexium 23 servo drive by a qualified technician. Before any maintenance and inspection, always turn off the Lexium 23 input power to the unit.

Warning

RISK OF ELECTRICAL CHOC

Be sure to disconnect AC power and ensure that the internal capacitors have fully discharged before performing the maintenance and inspection!

Failure to follow this recommendation may result in death or serious injuries

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|--------------------------------|------|
| Basic Inspection | 286 |
| Maintenance | 288 |
| Life of Replacement Components | 289 |

9.1 Basic Inspection

After power is in connected to the Lexium 23 servo drive, the charge LED will be lit which indicates that the Lexium 23 servo drive is ready.

| Item | Content |
|--|--|
| General Inspection | <ul style="list-style-type: none"> ● Periodically inspect the screws of the servo drive, motor shaft, terminal block and the connection to mechanical system. Tighten screws as necessary as they may loosen due to vibration and varying temperatures. ● Ensure that oil, water, metallic particles or any foreign objects do not fall inside the servo drive, motor, control panel or ventilation slots and holes. As these will cause damage. ● Ensure the correct installation and the control panel. It should be free from airborne dust, harmful gases or liquids. ● Ensure that all wiring instructions and recommendations are followed; otherwise damage to the drive and or motor may result. |
| Inspection before operation (Control power is not applied) | <ul style="list-style-type: none"> ● Inspect the servo drive and servo motor to insure they were not damaged. ● To avoid an electric shock, be sure to connect the ground terminal of servo drive to the ground terminal of control panel. ● Before making any connection, wait 10 minutes for capacitors to discharge after the power is disconnected, alternatively, use an appropriate discharge device to discharge. ● Ensure that all wiring terminals are correctly insulated. ● Ensure that all wiring is correct or damage and or malfunction may result. ● Visually check to ensure that there are not any unused screws, metal strips, or any conductive or inflammable materials inside the drive. ● Never put inflammable objects on servo drive or close to the external regenerative resistor. ● Make sure control switch is OFF. ● If the electromagnetic brake is being used, ensure that it is correctly wired. ● If required, use an appropriate electrical filter to eliminate noise to the servo drive. ● Ensure that the external applied voltage to the drive is correct and matched to the controller. |

| Item | Content |
|---|---|
| Inspection during operation (Control power is applied)) | <ul style="list-style-type: none"> ● Ensure that the cables are not damaged, stressed excessively or loaded heavily. When the motor is running, pay close attention on the connection of the cables and notice that if they are damaged, frayed or over extended. ● Check for abnormal vibrations and sounds during operation. If the servo motor is vibrating or there are unusual noises while the motor is running, please contact the dealer or manufacturer for assistance. ● Ensure that all user-defined parameters are set correctly. Since the characteristics of various machinery are different, in order to avoid accident or cause damage, do not adjust the parameter abnormally and ensure the parameter setting is not an excessive value. ● Ensure to reset some parameters when the servo drive is off (Please refer to Chapter 7). Otherwise, it may result in malfunction. ● If there is no contact sound or there be any unusual noises when the relay of the servo drive is operating, please contact your distributor for assistance or contact with Schneider electric. ● Check for abnormal conditions of the power indicators and LED display. If there is any abnormal condition of the power indicators and LED display, please contact your distributor for assistance or contact with Schneider electric. |

9.2 Maintenance

- Use and store the product in a proper and normal environment.
 - Periodically clean the surface and panel of servo drive and motor.
 - Make sure the conductors or insulators are corroded and/or damaged.
 - Do not disassemble or damage any mechanical part when performing maintenance.
 - Clean off any dust and dirt with a vacuum cleaner. Place special emphasis on cleaning the ventilation ports and PCBs. Always keep these areas clean, as accumulation of dust and dirt can cause unforeseen failures.
-

9.3 Life of Replacement Components

- **Smooth capacitor**

The characteristics of smooth capacitor would be deteriorated by ripple current affection. The life of smooth capacitor varies according to ambient temperature and operating conditions. The common guaranteed life of smooth capacitor is ten years when it is properly used in normal air-conditioned environment.

- **Relay**

The contacts will wear and result in malfunction due to switching current. The life of relay varies according to power supply capacity. Therefore, the common guaranteed life of relay is cumulative 100,000 times of power on and power off.

- **Cooling fan**

The cooling fan life is limited and should be changed periodically. The cooling fan will reach the end of its life in 2~3 years when it is in continuous operation. However, it also must be replaced if the cooling fan is vibrating or there are unusual noises.

Troubleshooting

10

At a Glance

Presentation

If a fault is detected on the servo drive or motor a corresponding fault code will be shown on the drive's LED display. Fault codes can also be transmitted via communication, see P0-01 and P4-00 ~ P4-04 for display on controller or HMI.

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|--|------|
| Fault Messages Table | 292 |
| Potential Cause and Corrective Actions | 294 |
| Clearing Faults | 302 |

10.1 Fault Messages Table

Servo Drive Fault Messages

| Fault Messages | | |
|-----------------|--------------------------------|---|
| Display | Fault Name | Fault Description |
| <i>AL E 0 1</i> | Overcurrent | Main circuit current is higher than 1.5 multiple of motor's instantaneous maximum current value. |
| <i>AL E 0 2</i> | Overvoltage | Main circuit voltage has exceeded its maximum allowable value. |
| <i>AL E 0 3</i> | Undervoltage | Main circuit voltage is below its minimum specified value. |
| <i>AL E 0 4</i> | Reserved | |
| <i>AL E 0 5</i> | Regeneration error | Regeneration control operation is in error. |
| <i>AL E 0 6</i> | Overload | Servo motor and drive is overload. |
| <i>AL E 0 7</i> | Overspeed | Motor's control speed exceeds the limit of normal speed. |
| <i>AL E 0 8</i> | Abnormal pulse control command | Input frequency of pulse command exceeds the limit of its allowable setting value. |
| <i>AL E 0 9</i> | Excessive deviation | Position control deviation value exceeds the limit of its allowable setting value. |
| <i>AL E 1 0</i> | Watch dog execution time out | Watch dog execution time out. |
| <i>AL E 1 1</i> | Encoder error | Pulse signal is in error. |
| <i>AL E 1 2</i> | Adjustment error | Adjusted value exceeds the limit of its allowable setting value when perform electrical adjustment. |
| <i>AL E 1 3</i> | Emergency stop activated | Emergency stop switch is activated. |
| <i>AL E 1 4</i> | Reverse limit switch error | Reverse limit switch is activated. |
| <i>AL E 1 5</i> | Forward limit switch error | Forward limit switch is activated. |
| <i>AL E 1 6</i> | IGBT temperature error | The temperature of IGBT is over high. |
| <i>AL E 1 7</i> | Memory error | EE-PROM write-in and read-out is in error. |
| <i>AL E 1 8</i> | DSP communication error | The communication between DSP and MCU is in error. DSP do not respond to MCU command. The problem is on DSP side. |
| <i>AL E 1 9</i> | Serial communication error | RS232/485 communication is in error. |

| Fault Messages | | |
|-----------------|-------------------------------------|--|
| Display | Fault Name | Fault Description |
| AL E 2 0 | Serial communication time out | RS232/485 communication time out. |
| AL E 2 1 | Command write-in error | Control command write-in error. |
| AL E 2 2 | Input power phase loss | One phase of the input power is loss. |
| AL E 2 3 | Pre-overload warning | To warn that the servo motor and drive is going to overload. This alarm will display before ALM06. When the servo motor reach the setting value of P1-56, the motor will send a warning to the drive. After the drive has detected the warning, the DO signal OLW will be activated and this fault message will display. |
| AL E 9 7 | Internal command execution time out | An error occurs when internal command is executing. |
| AL E 9 8 | DSP communication error | 1. DSP do not respond to MCU command. 2. DSP has responded to MCU command but there is error in response message. Maybe the hardware is damaged. |
| AL E 9 9 | DSP communication error | 1. DSP do not respond to MCU command. 2. DSP has responded to MCU command but there is error in response message. Maybe the hardware is damaged. |

Servo Drive Fault Messages (LEXIUM 23M Series Only)

| Fault Messages | | |
|-----------------|------------------|---|
| Display | Fault Name | Fault Description |
| AL E 0 4 | "Mismatch" error | The servo drive and servo motor are not correctly match for size (power rating) |
| AL E 2 4 | Encoder error | Z pulse shift. The corresponding angle of magnetic field of Z phase is error. |
| AL E 2 5 | Encoder error | The servo drive automatically detect the servo motor is in error. |

Note: If there is any unknown fault code that is not listed on the above table, please inform the distributor or contact with your nearest Schneider electric agency for assistance.

10.2 Potential Cause and Corrective Actions

Servo Drive Fault Messages

AL E D 1 : Overcurrent

| Potential Cause | Checking Method | Corrective Actions |
|---|--|--|
| Short-circuit at drive output (U, V, W) | 1. Check the wiring connections between drive and motor. 2. Check if the wire is short-circuited. | Repair the short-circuited and avoid metal conductor being exposed. |
| Motor wiring error | Check if the wiring steps are all correct when connecting motor to drive. | Follow the wiring steps in the user manual to reconnect wiring. |
| IGBT error | Heat sink overheated | Please contact your distributor for assistance or contact your nearest Schneider electric agency. |
| Control parameter setting error | Check if the setting value exceeds the factory default setting. | Set the setting back to factory default setting and then reset and adjust the parameter setting again. |
| Control command setting error | Check if the control input command is unstable (too much fluctuation). | 1. Ensure that input command frequency is stable (too much fluctuation). 2. Activate filter function. |

AL E D 2 : Overvoltage

| Potential Cause | Checking Method | Corrective Actions |
|--|---|--|
| The main circuit voltage has exceeded its maximum allowable value. | Use voltmeter to check whether the input voltage falls within the rated input voltage. (For voltage specification, please refer to section 11.1 in Chapter 11.) | Use correct power supply or stabilizing power. |
| Input power error (Incorrect power input) | Use voltmeter to check whether the input voltage is within the specified limit. | Use correct power supply or stabilizing power. |

ALE03 : Undervoltage

| Potential Cause | Checking Method | Corrective Actions |
|--|---|---|
| The main circuit voltage is below its minimum specified value. | Check whether the wiring of main circuit input voltage is normal. | Reconfirm voltage wiring. |
| No input voltage at main circuit. | Use voltmeter to check whether input voltage at main circuit is normal. | Reconfirm power switch. |
| Input power error (Incorrect power input) | Use voltmeter to check whether the input voltage is within the specified limit. | Use correct power supply or serial stabilizing power. |

ALE04 : Reserved**ALE05** : Regeneration error

| Potential Cause | Checking Method | Corrective Actions |
|---|--|---|
| Regenerative resistor is not connected. | Check the wiring connection of regenerative resistor. | Reconnect regenerative resistor. |
| Regenerative switch transistor fault | Check if regenerative switch transistor is shortcircuited. | Please contact your distributor for assistance or contact your nearest Schneider electric agency. |
| Parameter setting is in error | Confirm the parameter setting and specifications of regenerative resistor. | Correctly reset parameter again. |

ALE06 : Overload

| Potential Cause | Checking Method | Corrective Actions |
|--|--|---|
| The drive has exceeded its rated load during continuous operation. | Check if the drive is overloaded. | Increase motor capacity or reduce load. |
| Control system parameter setting is incorrect. | Check if there is mechanical vibration | Adjust gain value of control circuit. |
| | Accel/Decel time setting is too fast. | Decrease Accel/Decel time setting. |
| The wiring of drive and encoder is in error. | Check the wiring of U, V, W and encoder. | Ensure all wiring is correct. |

AL E 0 7 : Overspeed

| Potential Cause | Checking Method | Corrective Actions |
|---|--|---|
| Speed input command is not stable (too much fluctuation). | Use signal detector to detect if input signal is abnormal. | Ensure that input command frequency is stable (not fluctuate too much) and activate filter function (P1-06, P1-07 and P1-08). |
| Over-speed parameter setting is defective. | Check if over-speed parameter setting value is too low. | Correctly set over-speed parameter setting (P2-34). |

AL E 0 8 : Abnormal pulse control command

| Potential Cause | Checking Method | Corrective Actions |
|---|--|--|
| Pulse command frequency is higher than rated input frequency. | Use pulse frequency detector to measure input frequency. | Correctly set the input pulse frequency. |

AL E 0 9 : Excessive deviation

| Potential Cause | Checking Method | Corrective Actions |
|---|---|--|
| Maximum deviation parameter setting is too small. | Check the maximum deviation parameter setting and observe the position error value when the motor is running. | Increases the parameter setting value of P2-35. |
| Gain value is too small. | Check for proper gain value. | Correctly adjust gain value. |
| Torque limit is too low. | Check torque limit value. | Correctly adjust torque limit value. |
| There is an overload. | Check for overload condition. | Reduce external applied load or reestimate the motor capacity. |

AL E 1 0 : Watch dog execution time out

| Potential Cause | Checking Method | Corrective Actions |
|----------------------------|-----------------------------------|--|
| Watch dog execution error. | Check and reset the power supply. | If there are any abnormal conditions after resetting the power supply, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

A L E 11 : Encoder error (Position detector fault)

| Potential Cause | Checking Method | Corrective Actions |
|--|--|-------------------------------|
| The wiring of encoder is in error. | 1. Check if all wiring is correct. 2. Check if the users conduct the wiring by the wiring information in the user manual. | Ensure all wiring is correct. |
| Encoder is loose | Examine the encoder connector. | Install the motor again. |
| The wiring of encoder is defective. | Check if all connections are tight. | Conduct the wiring again. |
| Encoder is damage | Check the motor for the damage. | Repair or replace the motor. |
| The circuit (loop) of Encoder is in error. | Check the drive for the damage. | Repair or replace the drive. |

A L E 12 : Adjustment error

| Potential Cause | Checking Method | Corrective Actions |
|---|---|---|
| The setting value of drift adjustment has exceeded its maximum allowable value. | 1. Remove CN1 wiring. 2. Execute the drift adjustment again. (Set P2-08 to 20 first, and then set P4-10 to 5.) | executing the drift adjustment again, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

A L E 13 : Emergency stop activated

| Potential Cause | Checking Method | Corrective Actions |
|-------------------------------------|--|---------------------------------|
| Emergency stop switch is activated. | Check if emergency stop switch is On or Off. | Activate emergency stop switch. |

A L E 14 : Reverse (CWL) limit switch error

| Potential Cause | Checking Method | Corrective Actions |
|------------------------------------|--|---|
| Reverse limit switch is activated. | Check if reverse limit switch is On or Off. | Activate reverse limit switch. |
| Servo system is not stable. | Check the value of control parameter setting and load inertia. | Modify parameter setting and reestimate motor capacity. |

A L E 15 : Forward (CCWL) limit switch error

| Potential Cause | Checking Method | Corrective Actions |
|------------------------------------|--|---|
| Forward limit switch is activated. | Check if forward limit switch is On or Off. | Activate forward limit switch. |
| Servo system is not stable. | Check the value of control parameter setting and load inertia. | Modify parameter setting and reestimate motor capacity. |

A L E 16 : IGBT temperature error

| Potential Cause | Checking Method | Corrective Actions |
|--|--|---|
| The drive has exceeded its rated load during continuous operation. | Check if there is overload or the motor current is too high. | Increase motor capacity or reduce load. |
| Short-circuit at drive output. | Check the drive input wiring. | Ensure all wiring is correct. |

A L E 17 : Memory error

| Potential Cause | Checking Method | Corrective Actions |
|---|----------------------------------|---|
| Data error in Memory read-out / write-in. | Reset parameter or power supply. | If the error does not clear after resetting the power supply, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

A L E 18 : DSP communication error

| Potential Cause | Checking Method | Corrective Actions |
|----------------------------|-------------------------------|---|
| Control power is in error. | Check and reset control power | If the error does not clear after resetting the power supply, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

A L E 19 : Serial communication error

| Potential Cause | Checking Method | Corrective Actions |
|---|--|--------------------------------------|
| Communication parameter setting is defective. | Check the communication parameter setting. | Correctly set parameter setting. |
| Communication address is incorrect. | Check the communication address. | Correctly set communication address. |
| Communication value is incorrect. | Check the communication value. | Correctly set communication value. |

A L E 20 : Serial communication time out

| Potential Cause | Checking Method | Corrective Actions |
|--|---|---|
| Setting value in time out parameter is not correct. | Check communication time out parameter setting. | Correctly set P3-07. |
| Not receiving communication command for a long time. | Check whether communication cable is loose or broken. | Tighten the communication cable, make sure the communication cable is not damaged and ensure all wiring is correct. |

A L E 21 : Command write-in error

| Potential Cause | Checking Method | Corrective Actions |
|----------------------------|-------------------------------|---|
| Control power is in error. | Check and reset control power | If the error does not clear after resetting the power supply, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

A L E 22 : Input power phase loss

| Potential Cause | Checking Method | Corrective Actions |
|-----------------------------------|--|---|
| Control power supply is in error. | Check the power cable and connections of R, S, T. Check whether the power cable is loose or the possible loss of phase on input power. | If the fault does not clear even when the three-phase power is connected correctly, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

ALE23 : Pre-overload warning

| Potential Cause | Checking Method | Corrective Actions |
|---------------------------------|--|--|
| The drive is going to overload. | <ol style="list-style-type: none"> 1. Check the load condition of the servo motor and drive. 2. Check the setting value of P1-56. Check whether the setting value of P1-56 is too small. | <ol style="list-style-type: none"> 1. Please refer to the correction actions of ALE06. 2. Increase the setting value of P1-56 or set P1-56 to 100 and above. |

ALE97 : Internal command execution time out

| Potential Cause | Checking Method | Corrective Actions |
|---|-------------------------------|---|
| An error occurs when internal command is executing. | Check and reset control power | If the error does not clear after resetting the power supply, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

ALE98 : DSP communication error

| Potential Cause | Checking Method | Corrective Actions |
|--------------------------------|-------------------------------|---|
| Maybe the hardware is damaged. | Check and reset control power | If the error does not clear after resetting the power supply, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

ALE99 : DSP communication error

| Potential Cause | Checking Method | Corrective Actions |
|--------------------------------|-------------------------------|---|
| Maybe the hardware is damaged. | Check and reset control power | If the error does not clear after resetting the power supply, please contact your distributor for assistance or contact your nearest Schneider electric agency. |

Servo Drive Fault Messages (Lexium 23M Series Only)**AL E 0 4** : "Mismatch" error

| Potential Cause | Checking Method | Corrective Actions |
|---|---|---|
| The type of the servo motor is incorrect. | Check if the servo drive and servo motor are not correctly matched for size (power rating). | Repair or replace the servo drive or the servo motor. |

AL E 2 4 : Encoder error (Position detector fault)

| Potential Cause | Checking Method | Corrective Actions |
|-------------------------------|---|--------------------|
| Maybe the Encoder is damaged. | If the error does not clear after resetting the power supply, please contact your distributor for assistance or contact your nearest Schneider electric agency. | |

AL E 2 5 : Encoder error (Position detector fault)

| Potential Cause | Checking Method | Corrective Actions |
|---|--|--|
| The servo drive automatically detect the servo motor is in error. | <ol style="list-style-type: none"> 1. Check if the servo motor is properly grounded. 2. Check if the encoder signal cables are placed in separate conduits from the cables connected to R, S, T and U, V, W terminals to prevent the interference. 3. Check if the shielded cables are used when performing Encoder wiring. | <ol style="list-style-type: none"> 1. Please connect the grounding (green color) of U, V, W terminal to the heatsink of the servo drive. 2. Ensure that the encoder signal cables are placed in separate conduits from the cables connected to R, S, T and U, V, W terminals to prevent the interference. 3. Please use shielded cables for Encoder wiring. |

10.3 Clearing Faults

| Display | Fault Name | Clearing Method |
|------------------------|--------------------------------|---|
| <i>AL E 0 1</i> | Overcurrent | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| <i>AL E 0 2</i> | Overvoltage | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| <i>AL E 0 3</i> | Undervoltage | This fault message can be removed automatically after the voltage has returned within its specification. |
| <i>AL E 0 4</i> | Reserved | |
| <i>AL E 0 5</i> | Regeneration error | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| <i>AL E 0 6</i> | Overload | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| <i>AL E 0 7</i> | Overspeed | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| <i>AL E 0 8</i> | Abnormal pulse control command | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| <i>AL E 0 9</i> | Excessive deviation | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| <i>AL E 1 0</i> | Watch dog execution time out | This fault message cannot be cleared. |
| <i>AL E 1 1</i> | Encoder error | This fault message can be removed by restarting the servo drive. |
| <i>AL E 1 2</i> | Adjustment error | This fault message can be removed after the wiring of CN1 connector (I/O signal connector) is removed and auto adjustment function is executed. |
| <i>AL E 1 3</i> | Emergency stop activated | This fault message can be removed automatically by turning off EMGS (DI signal). |
| <i>AL E 1 4</i> | Reverse limit switch error | Turn ARST (DI signal) ON to clear the fault. This fault message can be removed when the servo drive is Off (Servo Off) |
| <i>AL E 1 5</i> | Forward limit switch error | Turn ARST (DI signal) ON to clear the fault. This fault message can be removed when the servo drive is Off (Servo Off) |
| <i>AL E 1 6</i> | IGBT temperature error | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| <i>AL E 1 7</i> | Memory error | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |

| Display | Fault Name | Clearing Method |
|----------------|-------------------------------------|--|
| AL E 18 | DSP communication error | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| AL E 19 | Serial communication error | Turn ARST (DI signal) ON to clear the fault. This fault message can also be removed automatically after the communication is normal. |
| AL E 20 | Serial communication time out | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| AL E 21 | Command write-in error | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| AL E 22 | Input power phase loss | Turn ARST (DI signal) ON to clear the fault. This fault message can be removed automatically after input power phase lost problem is solved. |
| AL E 23 | Pre-overload warning | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| AL E 97 | Internal command execution time out | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| AL E 98 | DSP communication error | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |
| AL E 99 | DSP communication error | Turn ARST (DI signal) ON to clear the fault or restart the servo drive. |

Lexium 23M Series Only

| | | |
|----------------|---|--|
| AL E 01 | Overcurrent | This fault message can be removed by restarting the servo drive. |
| AL E 04 | "Mismatch" error | This fault message can be removed by restarting the servo drive. |
| AL E 24 | Encoder error (Position detector fault) | This fault message can be removed by rotating the motor shaft first and then restarting the servo drive. |
| AL E 25 | Encoder error (Position detector fault) | This fault message can be removed by restarting the servo drive. |

Specifications

11


At a Glance

What's in this Chapter?

This chapter contains the following topics:

| Topic | Page |
|---|-------------|
| Specifications of Lexium 23 Servo Drive | 306 |
| BCH servo motor specifications | 309 |
| BCH Servo Motor Speed-Torque Curves | 312 |
| Overload Characteristics | 316 |
| Dimensions of Lexium 23 Servo Drive | 318 |
| Dimensions of BCH Servo Motor | 321 |

11.1 Specifications of Lexium 23 Servo Drive

| Environmental characteristics | | |
|--|------------|--|
| Conformity to standards | | Lexium 23 servo drives have been developed to conform to the strictest international standards and the recommendations relating to electrical industrial control equipment (IEC, EN), including: low voltage, IEC/EN 61800-5-1, IEC/EN 61800-3 (conducted and radiated EMC immunity and emissions) |
| EMC immunity | | IEC/EN 61800-3, environments 1 and 2 |
| | | IEC/EN 61000-4-2 level 3 |
| | | IEC/EN 61000-4-3 level 3 |
| | | IEC/EN 61000-4-4 level 4 |
| | | IEC/EN 61000-4-5 level 3 |
| Conducted and radiated EMC emissions for servo drives | | IEC/EN 61800-3, environments 1 and 2, categories C2, C3 |
| Installation Site | | Indoor location (no direct sunlight), no corrosive liquid and gas (far away from oil mist, flammable gas, dust) |
| CE marking | | The drives are e marked in accordance with the European low voltage (73/23/EEC and 93/68/EEC) and EMC (89/336/EEC) directives |
| Product certification | | UL (USA), C-tick (1) |
| Degree of protection | | IEC/EN 61800-5-1, IEC/EN 60529 IP20 |
| Vibration resistance | | 9.80665m/s ² (1G) under 20Hz 5.88m/s ² (0.6G) 20-50 Hz |
| Relative humidity | | 0-90 %RH (without condensation) |
| Ambient air temperature | Operation | °C 0...+ 55 (if operating temperature is above specified range, forced cooling will be required) |
| | Storage | °C -20-65 |
| Type of cooling | | LXM 23 CU01M3X...04M3X Natural convection LXM 23 CU07M3X...MU75M3X Fan |
| Maximum operating altitude | m | 1000 without derating |
| Atmospheric pressure | kPA | 86 - 106 |
| Power system | | TN system(2) |
| Operating position | | 10° 10°  |
| Maximum permanent angle in relation to the normal vertical mounting position | | |

(1) For above 2 Kw type pls consult our sales branch.

(2) TN system: A power distribution having one point directly earthed, the exposed conductive parts of the installation being connected to that point by protective earth conductor.

| Control signal characteristic | | |
|--------------------------------------|--|--|
| Protective function | | Overcurrent, Overvoltage, Undervoltage, Motor Overheated, Regeneration Error, Overload, Overspeed, Abnormal pulse control command, Encoder error, memory error, Communication error, U,V,W and CN1,CN2 and CN3 terminals with short circuit protection. |
| Digital Input | | Servo ON, Reset, Gain Switching, Pulse Clear, Emergency stop, Forward /Reverse inhibit limit, Internal parameter selection, Torque limit activation, Speed limit activation, Control mode selection (Position / Speed / Torque mode selection, Dual mode selection, Position register), Internal auto running mode, Electronic gear ratio selection (1). |
| Digital Output | | Encoder Signal output (A,B,Z Line Driver) Servo ready, Servo On, Zero Speed, Speed Reached, Positionning completed, At torque limit, Servo alarm output (Servo Fault), Electromagnetic brake, Home completed, Ready, Overload Alarm, Servo Pre-alarm |
| Communication interface | | RS-232/ RS-485/ RS-422 |

(1) Lexium 23 M also have other advanced function like automatically positioning mode control.

| Driver features | | | |
|-------------------------|------------------------------------|------|--|
| Control of main Circuit | | | SVPWM Control |
| Tuning Modes | | | Auto/ Manual |
| Dynamic brake | | | Built-in |
| Electric power features | | | |
| Power | Voltage | V | 220 VAC single phase or three phase LXM 23CU01M3X...15M3X 220 VAC three phase LXM 23CU20M3X...MU75M3X |
| | Permissible Voltage Range | V | 170-255 VAC three phase, 220-255 VAC single phase LXM 23CU01M3X...15M3X 170-255 VAC three phase LXM 23CU20M3X..MU75M3X |
| | Permissible Frequency Range | Hz | 50/60 HZ +/- 5% |
| Control mode | | | |
| Position control mode | Max. Input Pulse Frequency | Kpps | Line driver : 500 Kpps, Open collector : 200 Kpps (1) |
| | Pulse Type | | Pulse/direction, A phase + B phase, CCW Pulse + CW Pulse |
| | Command Source | | External pulse train / Internal parameters |
| | Smoothing strategy | | Low Pass and P-Curve filter |
| | Electronic Gear | | Electronic gear N/M multiple N: 1-32767, M: 1:32767 (1/50<N/M<200) |
| | Torque limit operation | | Set by parameters |
| | Feedforward compensation | | Set by parameters |
| Speed control mode | Analog input command Voltage Range | VDC | 0-+/- 10 VDC |
| | Input Resistance | kΩ | 10 |
| | Time constant | μs | 2.2 |
| | Speed control range (2) | | LXM 23CU01M3X...30M3X 1:5000 LXM 23MU45M3X...MU75M3X 1:3000 |
| | Command Source | | External Analog signal/Internal parameters |
| | Smoothing strategy | | Low Pass and S-Curve filter |
| | Torque limit operation | | Set by parameters or via Analog input |
| | Band with characteristics | Hz | LXM 23CU01M3X...30M3X Maximum 450 Hz LXM 23MU45M3X...MU75M3X Maximum 550 Hz |
| | Speed Fluctuation Rate (3) | | 0,01% or less at load fluctuation 0 to 100% (rated speed) 0,01% or less at power fluctuation +/-10% (rated speed) 0,01% or less at ambient temperature fluctuation 0°C to 50°C (rated speed) |
| Torque control mode | Analog input command Voltage Range | VDC | 0-+/- 10 VDC |
| | Input Resistance | kΩ | 10 |
| | Time constant | μs | 2.2 |
| | Permissible time for overload (4) | S | LXM 23CU01M3X...30M3X 8 sec. Under 200% rated output LXM 23MU45M3X...MU75M3X 16 sec. Under 200% rated output |
| | Command Source | | External Analog signal/Internal parameters |
| | Smoothing strategy | | Low pass filter |
| | Speed limit operation | | Set by parameters or via Analog input |
| | Analog monitor output | | Monitor signal can be set by parameters (Output voltage range : +/- 8V) |

(1) 4.5 ~7.5 Kw add high speed pulse input function, max. frequency is 4 Mpps.

(2) During full load, the speed ratio is defined as min. speed (no go and stop)/rated speed.

(3) When command is rated speed, speed fluctuation rate is defined as (empty load speed -full load speed)/rated speed.

(4) Pls refer to the over load sector of the user manual.

11.2 BCH servo motor specifications

Ultra low / Low inertia

| Servo motor reference | | | BCH0401O | BCH0601O | BCH0602O | BCH0801O | |
|----------------------------|--------------------------------------|-----------------|-------------------------|----------|----------|----------|------|
| Supply power | | V | Single phase 220 | | | | |
| Torque | Continuous stall | Nm | 0.32 | 0.64 | 1.27 | | |
| | Peak stall | Nm | 0.96 | 1.92 | 3.82 | | |
| Rated work point | Rated torque | Nm | 0.32 | 0.64 | 1.27 | | |
| | Rated speed | rpm | 3000 | | | | |
| | Rated power | kW | 0.1 | 0.2 | 0.4 | | |
| Peak current | | A rms | 2.7 | 4.65 | 7.8 | | |
| Maximum speed | | rpm | 5000 | | | | |
| Constant | Torque | Nm/A rms | 0.36 | 0.41 | 0.49 | | |
| | Inertia | No brake | kgcm² | 0.037 | 0.177 | 0.277 | 0.68 |
| | | With brake | kgcm² | - | 0.192 | 0.3 | 0.73 |
| Stator (at 20°C) | Armature resistance (phase/phase) | Ω | 9.3 | 2.79 | 1.55 | 0.93 | |
| | Armature inductance (phase/phase) | mH | 24 | 12.07 | 6.71 | 7.39 | |
| | Electrical time constant | ms | 2.58 | 4.3 | 4.3 | 7.96 | |

| Servo motor reference | | | BCH0802O | BCH1001O | BCH1002O | |
|----------------------------|--------------------------------------|-----------------|-------------------------|----------|-----------------|-------|
| Supply power | | V | Single phase 220 | | Three phase 220 | |
| Torque | Continuous stall | Nm | 2.39 | 3.18 | 6.37 | |
| | Peak stall | Nm | 7.16 | 9.54 | 19.11 | |
| Rated work point | Rated torque | Nm | 2.39 | 3.18 | 6.37 | |
| | Rated speed | rpm | 3000 | | | |
| | Rated power | kW | 0.75 | 1 | 2 | |
| Peak current | | A rms | 15.3 | 21.9 | 36.15 | |
| Maximum speed | | rpm | 5000 | | | |
| Constant | Torque | Nm/A rms | 0.47 | 0.43 | 0.53 | |
| | Inertia | No brake | kgcm² | 1.13 | 2.65 | 4.45 |
| | | With brake | kgcm² | 1.18 | 3.33 | 4.953 |
| Stator (at 20°C) | Armature resistance (phase/phase) | Ω | 0.42 | 0.2 | 0.13 | |
| | Armature inductance (phase/phase) | mH | 3.53 | 1.81 | 1.5 | |
| | Electrical time constant | ms | 8.37 | 9.3 | 11.4 | |

Medium inertia

| Servo motor reference | | | BCH1301M | BCH1301N | BCH1302M | BCH1302N | |
|-----------------------|--------------------------------------|------------|-------------------|----------|----------|----------|------|
| Supply power | | V | Single phase 220 | | | | |
| Torque | Continuous stall | Nm | 2.86 | 2.39 | 5.73 | 4.77 | |
| | Peak stall | Nm | 8.59 | 7.16 | 17.19 | 14.32 | |
| Rated work point | Rated torque | Nm | 2.86 | 2.39 | 5.73 | 4.77 | |
| | Rated speed | rpm | 1000 | 2000 | 1000 | 2000 | |
| | Rated power | kW | 0.3 | 0.5 | 0.6 | 1 | |
| Peak current | | A rms | 7.5 | 8.7 | 14.4 | 16.8 | |
| Maximum speed | | rpm | 2000 | 3000 | 2000 | 3000 | |
| Constant | Torque | Nm/A rms | 1.15 | 0.83 | 1.19 | 0.85 | |
| | Inertia | No brake | kgcm ² | 8.17 | 8.17 | 8.41 | 8.41 |
| | | With brake | kgcm ² | 8.94 | 8.94 | 9.14 | 9.14 |
| Stator (at 20°C) | Armature resistance (phase/phase) | Ω | 1.06 | 0.57 | 0.82 | 0.47 | |
| | Armature inductance (phase/phase) | mH | 14.29 | 7.39 | 11.12 | 5.99 | |
| | Electrical time constant | ms | 13.55 | 12.96 | 13.5 | 12.88 | |

| Servo motor reference | | | BCH1303M | BCH1303N | BCH1304N | |
|-----------------------|--------------------------------------|------------|-------------------|----------|-----------------|-------|
| Supply power | | V | Single phase 220 | | Three phase 220 | |
| Torque | Continuous stall | Nm | 8.59 | 7.16 | 9.55 | |
| | Peak stall | Nm | 25.78 | 21.48 | 28.65 | |
| Rated work point | Rated torque | Nm | 8.59 | 7.16 | 9.55 | |
| | Rated speed | rpm | 1000 | 2000 | 2000 | |
| | Rated power | kW | 0.9 | 1.5 | 2 | |
| Peak current | | A rms | 22.5 | 24.9 | 33.03 | |
| Maximum speed | | rpm | 2000 | 3000 | 3000 | |
| Constant | Torque | Nm/A rms | 1.15 | 0.87 | 0.87 | |
| | Inertia | No brake | kgcm ² | 11.18 | | 14.59 |
| | | With brake | kgcm ² | 11.9 | | 15.88 |
| Stator (at 20°C) | Armature resistance (phase/phase) | Ω | 0.43 | 0.26 | 0.174 | |
| | Armature inductance (phase/phase) | mH | 6.97 | 4.01 | 2.76 | |
| | Electrical time constant | ms | 16.06 | 15.31 | 15.86 | |


High inertia

| Servo motor reference | | | BCH1801N | BCH1802M | BCH1802N | |
|-----------------------|--------------------------------------|------------|-------------------|----------|----------|------|
| Supply power | | V | Three phase 220 | | | |
| Torque | Continuous stall | Nm | 9.55 | 19.10 | 16.71 | |
| | Peak stall | Nm | 28.65 | 57.29 | 50.31 | |
| Rated work point | Rated torque | Nm | 9.55 | 19.10 | 16.71 | |
| | Rated speed | rpm | 2000 | 1500 | 2000 | |
| | Rated power | kW | 2 | 3 | 3.5 | |
| Peak current | | A rms | 33.66 | 58.2 | 57.6 | |
| Maximum speed | | rpm | 3000 | | | |
| Constant | Torque | Nm/A rms | 0.85 | 0.98 | 0.87 | |
| | Inertia | No brake | kgcm ² | 34.68 | 54.95 | 54.8 |
| | | With brake | kgcm ² | 37.86 | - | - |
| Stator (at 20°C) | Armature resistance (phase/phase) | Ω | 0.119 | 0.077 | 0.052 | |
| | Armature inductance (phase/phase) | mH | 2.84 | 1.27 | 1.38 | |
| | Electrical time constant | ms | 23.87 | 16.5 | 26.4 | |


| Servo motor reference | | | BCH1803M | BCH1804M | BCH1805M | |
|-----------------------|--------------------------------------|------------|-------------------|----------|----------|-------|
| Supply power | | V | Three phase 220 | | | |
| Torque | Continuous stall | Nm | 28.65 | 35.01 | 47.74 | |
| | Peak stall | Nm | 71.62 | 87.53 | 119.36 | |
| Rated work point | Rated torque | Nm | 28.65 | 35.01 | 47.74 | |
| | Rated speed | rpm | 1500 | | | |
| | Rated power | kW | 4.5 | 5.5 | 7.5 | |
| Peak current | | A rms | 81.3 | 100 | 118.8 | |
| Maximum speed | | rpm | 3000 | | | |
| Constant | Torque | Nm/A rms | 0.88 | 0.88 | 1.01 | |
| | Inertia | No brake | kgcm ² | 77.75 | 99.78 | 142.7 |
| | | With brake | kgcm ² | - | - | - |
| Stator (at 20°C) | Armature resistance (phase/phase) | Ω | 0.032 | 0.025 | 0.015 | |
| | Armature inductance (phase/phase) | mH | 0.89 | 0.6 | 0.4 | |
| | Electrical time constant | ms | 27.8 | 24 | 26.7 | |

11.3 BCH Servo Motor Speed-Torque Curves


BCH04010 servo motor




BCH06010 servo motor




BCH06020 servo motor




BCH08010 servo motor




BCH08020 servo motor




BCH10010 servo motor




BCH1002O servo motor




BCH1301N servo motor




BCH1302N servo motor




BCH1303N servo motor




BCH1304N servo motor




BCH1801N servo motor




BCH1301M servo motor




BCH1302M servo motor




BCH1303M servo motor




BCH1802M servo motor





BCH1802N servo motor



BCH1803M servo motor



BCH1804M servo motor**BCH1805M servo motor**

11.4 Overload Characteristics


- **Overload Protection Function**

Overload protection is a built-in protective function to prevent a motor from overheating.


- **Occasion of Overload**

1. Motor was operated for several seconds under a torque exceeding 100% torque.
2. Motor had driven high inertia machine and had accelerated and decelerated at high frequency.
3. Motor UVW cable or encoder cable was not connected correctly.
4. Servo gain was not set properly and caused motor hunting.
5. Motor holding brake was not released.

- **Chart of load and operating time (Low Inertia Servo Motor)**




| Load | Operating Time |
|------|----------------|
| 120% | 263.8s |
| 140% | 35.2s |
| 160% | 17.6s |
| 180% | 11.2s |
| 200% | 8s |
| 220% | 6.1s |
| 240% | 4.8s |
| 260% | 3.9s |
| 280% | 3.3s |
| 300% | 2.8s |

• Chart of load and operating time (Medium and Medium / High Inertia Servo Motor)


| Load | Operating Time |
|------|----------------|
| 120% | 527.6s |
| 140% | 70.4s |
| 160% | 35.2s |
| 180% | 22.4s |
| 200% | 16s |
| 220% | 12.2s |
| 240% | 9.6s |
| 260% | 7.8s |
| 280% | 6.6s |
| 300% | 5.6s |

11.5 Dimensions of Lexium 23 Servo Drive


LXM23CU01M3X, CU02M3X, CU04M3X



LXM23CU07M3X, CU10M3X, CU15M3X




LXM23CU20M3X, CU30M3X, MU45M3X





Unit: mm (inch)

LXM23MU55M3X



Unit: mm (inch)

LXM23MU75M3X




Unit: mm (inch)

11.6 Dimensions of BCH Servo Motor

BCH040 (Servo motor/brake and Motor Power Connector 1 and Encoder Connector 2)

Key shaft (optional)




| | c (without brake) | c (with brake) |
|----------------|-------------------|----------------|
| BCH0401 | 100.6 | - |

BCH0401 100.6

BCH060 (Servo motor/brake and Motor Power Connector 1 and Encoder Connector 2)

Key shaft (optional)




| | c (without brake) | c (with brake) |
|----------------|-------------------|----------------|
| BCH0601 | 105.5 | 141.6 |
| BCH0602 | 130.7 | 166.8 |

BCH0601 105.5 141.6
BCH0602 130.7 166.8

BCH080 (Servo motor/brake and Motor Power Connector 1 and Encoder Connector 2)


Key shaft (optional)




| | c (without brake) | c (with brake) | S | c1 | c2 | LS | RH | Wk | W | T |
|----------------|-------------------|----------------|----|----|----|------|------|----|---|---|
| BCH0801 | 112.3 | 152.8 | 14 | 30 | 20 | 24.5 | 11 | 5 | 5 | 5 |
| BCH0802 | 138.3 | 178.0 | 19 | 35 | 25 | 29.5 | 15.5 | 6 | 6 | 6 |

BCH100 (Servo motor/brake and Motor Power Connector 1 and Encoder Connector 2)


Key shaft (optional)



| | c (without brake) | c (with brake) |
|----------------|-------------------|----------------|
| BCH1001 | 153.5 | 192.5 |
| BCH1002 | 199.0 | 226.0 |

BCH130 (Servo motor/brake and Motor Power Connector 1 and Encoder Connector 2)**Key shaft (optional)**

| | c (without brake) | c (with brake) |
|-----------------|-------------------|----------------|
| BCH1301 | 147.5 | 183.5 |
| BCH1302 | 147.5 | 183.5 |
| BCH1303M | 163.5 | 198.0 |
| BCH1303N | 167.5 | 202.0 |
| BCH1304 | 187.5 | 216.0 |

BCH180 (Servo motor/brake and Motor Power Connector 1 and Encoder Connector 2)**Key shaft (optional)**

| | c (without brake) | c (with brake) | S | c1 | c2 | LS | RH | Wk | W |
|-----------------|-------------------|----------------|----|-----|----|----|----|----|----|
| BCH1801 | 169.0 | 203.1 | 35 | 79 | 63 | 73 | 30 | 10 | 10 |
| BCH1802M | 202.1 | - | 35 | 79 | 63 | 73 | 30 | 10 | 10 |
| BCH1802N | 202.1 | - | 35 | 65 | 50 | | 30 | 10 | 10 |
| BCH1803 | 235.3 | - | 35 | 79 | 63 | 73 | 30 | 10 | 10 |
| BCH1804 | 279.7 | - | 42 | 113 | 90 | | 37 | 12 | 12 |
| BCH1805 | 342.0 | - | 42 | 113 | 90 | | 37 | 12 | 12 |

Accessories

Appendix


At a Glance

What's in this Chapter?


This chapter contains the following topics:

| Topic | Page |
|---|-------------|
| Power Connectors | 326 |
| Power Cables | 327 |
| Encoder Connectors | 331 |
| Encoder Cables | 332 |
| I/O Signal Connector (CN1) | 332 |
| Communication Cable between Drive and Computer (for PC) | 333 |
| Terminal Block Module | 333 |
| Connector and cable | 334 |
| Regenerative Resistor Specifications | 338 |


Power Connectors Part Number: VW3M5111
Housing: AMP 350780-1
Terminal: AMP 350537-3



Part Number: VW3M5112
Housing: AMP 350781-1
UVW Terminal: AMP 350537-3
Brake Terminal: AMP 350570-3




Part Number: VW3M5121
CLAMP: MS3057-12A



Straight Plug MS 3106-20-18S


Part Number: VW3M5131
CLAMP: MS3057-16A
Straight Plug MS 3106-24-11S



Straight Plug MS 3106-24-11S


Power Cables

Part Number: VW3M5111R30,VW3M5111R50




| Title | Part No. | L | |
|-------|-------------|-----------|-----------|
| | | mm | inch |
| 1 | VW3M5111R30 | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5111R50 | 5000 ± 10 | 197 ± 0.4 |

Part Number: VW3M5112R30,VW3M5112R50




| Title | Part No. | L | |
|-------|-------------|-----------|-----------|
| | | mm | inch |
| 1 | VW3M5112R30 | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5112R50 | 5000 ± 10 | 197 ± 0.4 |

Part Number: VW3M5121R30,VW3M5121R50




| Title | Part No. | Straight | L | |
|-------|-------------|----------------|-----------|-----------|
| | | | mm | inch |
| 1 | VW3M5121R30 | MS 3106-20-18S | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5121R50 | MS 3106-20-18S | 5000 ± 10 | 197 ± 0.4 |

Part Number: VW3M5131R30,VW3M5131R50




| Title | Part No. | Straight | L | |
|-------|-------------|----------------|-----------|-----------|
| | | | mm | inch |
| 1 | VW3M5131R30 | MS 3106-20-18S | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5131R50 | MS 3106-20-18S | 5000 ± 10 | 197 ± 0.4 |

Part Number: VW3M5122R30,VW3M5122R50




| Title | Part No. | Straight | L | |
|-------|-------------|----------------|-----------|-----------|
| | | | mm | inch |
| 1 | VW3M5122R30 | MS 3106-20-18S | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5122R50 | MS 3106-20-18S | 5000 ± 10 | 197 ± 0.4 |

Part Number: VW3M5132R30,VW3M5132R50




| Title | Part No. | Straight | L | |
|-------|-------------|----------------|-----------|-----------|
| | | | mm | inch |
| 1 | VW3M5132R30 | MS 3106-20-18S | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5132R50 | MS 3106-20-18S | 5000 ± 10 | 197 ± 0.4 |

Part Number: VW3M5123R30,VW3M5123R50




| Title | Part No. | Straight | L | |
|-------|-------------|----------------|-----------|-----------|
| | | | mm | inch |
| 1 | VW3M5123R30 | MS 3106-24-11S | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5123R50 | MS 3106-24-11S | 5000 ± 10 | 197 ± 0.4 |

Part Number: VW3M5133R30,VW3M5133R50



| Title | Part No. | Straight | L | |
|-------|-------------|----------------|-----------|-----------|
| | | | mm | inch |
| 1 | VW3M5133R30 | MS 3106-24-11S | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5133R50 | MS 3106-24-11S | 5000 ± 10 | 197 ± 0.4 |



Part Number: VW3M5124R30,VW3M5124R50



| Title | Part No. | Straight | L | |
|-------|-------------|----------------|-----------|-----------|
| | | | mm | inch |
| 1 | VW3M5124R30 | MS 3106-24-11S | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M5124R50 | MS 3106-24-11S | 5000 ± 10 | 197 ± 0.4 |

Encoder Connectors



Part Number: VW3M8111



| Vendor Name | Vendor P/N |
|-------------|----------------|
| 3M | 10120-3000PE |
| 3M | 10320-52A0-008 |

HOUSING:AMP (1-172211-0)
 TERMINAL:AMP (170376-3)


Part Number: VW3M8112



Straight plug MS 3106-20-29S


Encoder Cables

Part Number: VW3M8111R30,VW3M8111R50



| Title | Part No. | L | |
|-------|-------------|-----------|-----------|
| | | mm | inch |
| 1 | VW3M8111R30 | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M8111R50 | 5000 ± 10 | 197 ± 0.4 |

Part Number: VW3M8112R30,VW3M8112R50




| Title | Part No. | Straight | L | |
|-------|-------------|----------------|-----------|-----------|
| | | | mm | inch |
| 1 | VW3M8112R30 | MS 3106-20-29S | 3000 ± 10 | 118 ± 0.4 |
| 2 | VW3M8112R50 | MS 3106-20-29S | 5000 ± 10 | 197 ± 0.4 |

I/O Signal Connector (CN1)


Part Number: VW3M4112

| Vendor Name | Vendor P/N |
|-------------|----------------|
| 3M | 10150-3000PE |
| 3M | 10350-52A0-008 |



**Communication
Cable between
Drive and
Computer (for PC)**


Part Number: VW3M1111R30



| Title | Part No. | L | |
|-------|-------------|-----------|-----------|
| | | mm | inch |
| 1 | VW3M1111R30 | 3000 ± 10 | 118 ± 0.4 |

**Terminal Block
Module**

Part Number: VW3M4113




Connector and cable

| Connector | | | | |
|---------------------------|--|------------|--------------|--|
| Name | Description | Reference | Weight kg | |
| Replaced connector set | Power connector set,drive side | VW3 M4 111 | - | |
| I/O connector | I/O connector of CN1 interface | VW3 M4 112 | - | |
| I/O terminal block module | Terminal block module,with 0.5 m cable | VW3 M4 113 | - | |

| Cable | | | | | |
|-------------------------------|----------------|-------------|-------------|-------------|--------------|
| Name | Description | | Length m | Reference | Weight kg |
| | From | To | | | |
| PC serial communication cable | PC serial port | Servo drive | 3 | VW3M1111R30 | - |

| Connection accessory | | | | |
|---|---|---------------|-----------|--------------|
| Connector for power cable | | | | |
| Description | For | Item no. | Reference | Weight kg |
| For motor with flying cable,no brake | BCH0401O●●A1C | 1 | VW3M5111 | - |
| | BCH0601O●●A1C | | | |
| | BCH0602O●●A1C | | | |
| | BCH0801O●●A1C | | | |
| | BCH0802O●●A1C | | | |
| For motor with flying cable,with brake | BCH0601O●●F1C | 1 | VW3M5112 | - |
| | BCH0602O●●F1C | | | |
| | BCH0801O●●F1C | | | |
| | BCH0802O●●F1C | | | |
| Military connector for motor under 2 KW | BCH1001O●●●1C | 1 | VW3M5121 | - |
| | BCH1301M●●●1C | | | |
| | BCH1301N●●●1C | | | |
| | BCH1302M●●●1C | | | |
| | BCH1302N●●●1C | | | |
| | BCH1303M●●●1C | | | |
| | BCH1303N●●●1C | | | |
| | BCH1002O●●●1C | | | |
| | BCH1304N●●●1C | | | |
| | BCH1801N●●●1C | | | |
| | Military connector for motor above 3 kW | BCH1802N●●●1C | 1 | VW3M5131 |
| BCH1802M●●●1C | | | | |
| BCH1803M●●●1C | | | | |
| BCH1804M●●●1C | | | | |
| BCH1805M●●●1C | | | | |



| Connection accessory (continue) | | | | |
|--|------------|-----------------|------------------|---------------|
| Connector for encoder cable | | | | |
| Description | For | Item no. | Reference | Weight |
| | | | | kg |
| For motor with flying cable | BCH0401O | 2 | VW3M8111 | - |
| | BCH0601O | | | |
| | BCH0602O | | | |
| | BCH0801O | | | |
| | BCH0802O | | | |
| For motor with military connector | BCH1001O | 2 | VW3M8112 | - |
| | BCH1301M | | | |
| | BCH1301N | | | |
| | BCH1302M | | | |
| | BCH1302N | | | |
| | BCH1303M | | | |
| | BCH1303N | | | |
| | BCH1002O | | | |
| | BCH1304N | | | |
| | BCH1801N | | | |
| | BCH1802M | | | |
| | BCH1803M | | | |

Connection accessory (continue)

Power cable

| Description | From servo motor | To servo drive | Composition | Length | Reference | Weight |
|--|------------------|----------------|--------------------------|--------|-------------|--------|
| | | | | m | | kg |
| Servo motor side with plastic connector | BCH0401O●●A1C | LXM23CU01M3X | 4 x 0.82 mm ² | 3 | VW3M5111R30 | - |
| | BCH0601O●●A1C | LXM23CU02M3X | | 5 | VW3M5111R50 | - |
| Drive side with flying lead,no brake | BCH0602O●●A1C | LXM23CU04M3X | | | | |
| | BCH0801O●●A1C | LXM23CU04M3X | | | | |
| | BCH0802O●●A1C | LXM23CU07M3X | | | | |
| Servo motor side with plastic connector | BCH0601O●●F1C | LXM23CU02M3X | 6 x 0.82 mm ² | 3 | VW3M5112R30 | - |
| | BCH0602O●●F1C | LXM23CU04M3X | | 5 | VW3M5112R50 | - |
| Drive side with flying lead,with brake | BCH0801O●●F1C | LXM23CU04M3X | | | | |
| | BCH0802O●●F1C | LXM23CU07M3X | | | | |
| Servo motor side with military connector | BCH1001O●●A1C | LXM23CU10M3X | 4 x 1.3 mm ² | 3 | VW3M5121R30 | - |
| | BCH1301M●●A1C | LXM23CU04M3X | | 5 | VW3M5121R50 | - |
| Drive side with flying lead,no brake | BCH1301N●●A1C | LXM23CU04M3X | | | | |
| | BCH1302M●●A1C | LXM23CU07M3X | | | | |
| | BCH1302N●●A1C | LXM23CU10M3X | | | | |
| | BCH1303M●●A1C | LXM23CU10M3X | | | | |
| | BCH1303N●●A1C | LXM23CU15M3X | | | | |
| Servo motor side with military connector | BCH1001O●●F1C | LXM23CU10M3X | 6 x 1.3 mm ² | 3 | VW3M5131R30 | - |
| | BCH1301M●●F1C | LXM23CU04M3X | | 5 | VW3M5131R50 | - |
| Drive side with flying lead,with brake | BCH1301N●●F1C | LXM23CU04M3X | | | | |
| | BCH1302M●●F1C | LXM23CU07M3X | | | | |
| | BCH1302N●●F1C | LXM23CU10M3X | | | | |
| | BCH1303M●●F1C | LXM23CU10M3X | | | | |
| | BCH1303N●●F1C | LXM23CU15M3X | | | | |
| Servo motor side with military connector | BCH1002O●●A1C | LXM23CU20M3X | 4 x 2.1 mm ² | 3 | VW3M5122R30 | - |
| | BCH1304N●●A1C | LXM23CU20M3X | | 5 | VW3M5122R50 | - |
| Drive side with flying lead,no brake | | | | | | |
| Servo motor side with military connector | BCH1002O●●F1C | LXM23CU20M3X | 6 x 2.1 mm ² | 3 | VW3M5132R30 | - |
| | BCH1304N●●F1C | LXM23CU20M3X | | 5 | VW3M5132R50 | - |
| Drive side with flying lead,with brake | | | | | | |
| Servo motor side with military connector | BCH1801N●●A1C | LXM23CU20M3X | 4 x 3.3 mm ² | 3 | VW3M5123R30 | - |
| | BCH1802M●●A1C | LXM23CU30M3X | | 5 | VW3M5123R50 | - |
| Drive side with flying lead,no brake | BCH1802M●●A1C | LXM23MU45M3X | | | | |
| | BCH1802N●●A1C | LXM23MU45M3X | | | | |
| Servo motor side with military connector | BCH1801N●●F1C | LXM23CU20M3X | 6 x 3.3 mm ² | 3 | VW3M5133R30 | - |
| | BCH1802M●●F1C | LXM23CU30M3X | | 5 | VW3M5133R50 | - |
| Drive side with flying lead,with brake | BCH1802M●●F1C | LXM23MU45M3X | | | | |
| | BCH1802N●●F1C | LXM23MU45M3X | | | | |
| Servo motor side with military connector | BCH1803M●●A1C | LXM23MU45M3X | 4 x 8.4 mm ² | 3 | VW3M5124R30 | - |
| | BCH1804M●●A1C | LXM23MU55M3X | | 5 | VW3M5124R50 | - |
| Drive side with flying lead,no brake | BCH1805M●●A1C | LXM23MU75M3X | | | | |



VW3M5 111/121/131
112/122/132/133
/124 R●●

Connection accessory (continue)**Encoder cable**

| Description | From servo motor | To servo drive | Composition | Length Reference | | Weight |
|---|------------------|----------------|-----------------|------------------|--------------------|--------|
| | | | | m | kg | |
| Servo motor side and drive side with plastic connector | BCH0401O | LXM23CU01M3X | 10 x 0.13 | 3 | VW3M8111R30 | - |
| | BCH0601O | LXM23CU02M3X | mm ² | 5 | VW3M8111R50 | - |
| | BCH0602O | LXM23CU04M3X | | | | |
| | BCH0801O | LXM23CU04M3X | | | | |
| | BCH0802O | LXM23CU07M3X | | | | |
| Servo motor side with military connector Drive side with plastic connector | BCH1001O | LXM23CU10M3X | 10 x 0.13 | 3 | VW3M8112R30 | - |
| | BCH1301M | LXM23CU04M3X | mm ² | 5 | VW3M8112R50 | - |
| | BCH1301N | LXM23CU04M3X | | | | |
| | BCH1302M | LXM23CU07M3X | | | | |
| | BCH1302N | LXM23CU10M3X | | | | |
| | BCH1303M | LXM23CU10M3X | | | | |
| | BCH1303N | LXM23CU15M3X | | | | |
| | BCH1002O | LXM23CU20M3X | | | | |
| | BCH1304N | LXM23CU20M3X | | | | |
| | BCH1801N | LXM23CU20M3X | | | | |
| | BCH1802M | LXM23CU30M3X | | | | |
| | BCH1802M | LXM23MU45M3X | | | | |
| | BCH1803M | LXM23MU45M3X | | | | |



VW3M8 111/112 R●●●

Regenerative Resistor Specifications

| Regenerative Resistor Specifications | | | | | | | | | |
|--|----------------------|-------------------|---------------|---------------|---------------|---------------|---------------|-------|------|
| | | LXM23C U01M3X | LXM23C U02M3X | LXM23C U04M3X | LXM23C U07M3X | LXM23C U10M3X | LXM23C U15M3X | | |
| Supply voltage | V | 220 | | | | | | | |
| Number of phases | | Single-phase | | | | | | | |
| Load threshold | V --- | 400 | | | | | | | |
| Energy absorption of the internal capacitors | Edrive | Joule (Ws) | | 0.15 | 0.89 | 1.68 | 5.34 | 12.86 | 17.8 |
| Internal resistor | Resistance | Ω | 40 | | | | | | |
| | Continuous power | PPr | W | | 30 | | | | |
| | Peak energy | EPk | Joule (Ws) | | 3 | 4 | 8 | 14 | 18 |
| External resistor | Min. resistance | Ω | 40 | 40 | 20 | 20 | 20 | 20 | |
| | Degree of protection | | IP21 | | | | | | |
| | | LXM23CU20M3X | LXM23CU30M3X | LXM23MU45M3X | | | | | |
| Supply voltage | V | 220 | | | | | | | |
| Number of phases | | Three-phase | | | | | | | |
| Load threshold | V --- | 400 | | | | | | | |
| Energy absorption of the internal capacitors | Edrive | Joule (Ws) | | 23.24 | 217.73 | 384.47 | | | |
| Internal resistor | Resistance | Ω | 20 | | | | | | |
| | Continuous power | PPr | W | | 60 | | | | |
| | Peak energy | EPk | Joule (Ws) | | 21 | 28 | 28 | | |
| External resistor | Min. resistance | Ω | 10 | | | | | | |
| | Degree of protection | | IP21 | | | | | | |
| External braking resistors | | | | | | | | | |
| Value | Continuous power PPr | Peak energy 220 V | EPk | Reference | | | | | |
| Ω | W | Ws | | | | | | | |
| 40 | 400 | 4000 | | VW3M7111 | | | | | |
| 20 | 1000 | 4000 | | VW3M7112 | | | | | |